

182S Skylane

Information Manual

NOTICE

AT THE TIME OF ISSUANCE, THIS INFORMATION MANUAL WAS AN EXACT DUPLICATE OF THE OFFICIAL PILOT'S OPERATING HANDBOOK AND FAA APPROVED AIRPLANE FLIGHT MANUAL AND IS TO BE USED FOR GENERAL PURPOSES ONLY.

IT WILL NOT BE KEPT CURRENT AND, THEREFORE, CANNOT BE USED AS A SUBSTITUTE FOR THE OFFICIAL PILOT'S OPERATING HANDBOOK AND FAA APPROVED AIRPLANE FLIGHT MANUAL INTENDED FOR OPERATION OF THE AIRPLANE.

CESSNA AIRCRAFT COMPANY ORIGINAL ISSUE - 3 FEBRUARY 1997

PERFORMANCE - SPECIFICATIONS

* SPEED	
Maximum at Sea Level	145 KTS
Cruise, 80% Power at 6000 Ft (Best Power Mixture)	140 KTS
CRUISE: Recommended lean mixture with fuel al	lowance for
engine start, taxi, takeoff, climb and	
reserve.	
75% Power at 6000 Ft Range	820 NM
88 Gallons Usable Fuel Time	6.05 HRS
Max Range at 10,000 Ft, 55% Power Range	968 NM
88 Gallons Usable Fuel Time	8.05 HRS
RATE OF CLIMB AT SEA LEVEL:	924 FPM
SERVICE CEILING:	
TAKEOFF PERFORMANCE:	
Ground Roll	795 FT
Total Distance Over 50 Ft. Obstacle	
LANDING PERFORMANCE:	
Ground Roll	590 FT
Total Distance Over 50 Ft. Obstacle	
STALL SPEED (KCAS):	
Flaps Up, Power Off	54 KCAS
Flaps Down, Power Off	49 KCAS
MAXIMUM WEIGHT:	
Ramp	3110 LBS
Takeoff	3100 LBS
Landing	2950 LBS
STANDARD EMPTY WEIGHT:	1925 LBS
MAXIMUM USEFUL LOAD:	1185 LBS
BAGGAGE ALLOWANCE:	200 LBS

PERFORMANCE-SPECIFICATIONS

(Continued)

WING LOADING: Lbs/Sq Ft	17.8
POWER LOADING Lbs/HP	13.5
	92 GAL
OIL CAPACITY	9 QTS
ENGINE: Textron Lycoming IO-540	-AB1A5
230 BHP at 2400 RPM	
PROPELLER: Diameter - 3-Blade	79 IN 82 IN
Diameter - 2-Blade	82 IN
NOTE	


*Speed performance and range are shown for an airplane equipped with optional speed fairings which increase the speeds by approximately 3 knots. All other performance figures are unchanged when speed fairings are removed. Performance above is based on a 2-bladed propeller. Performance with the 3-blade propeller is essentially the same as shown above.

The above performance figures are based on the indicated weights, standard atmospheric conditions, level hard-surface dry runways and no wind. They are calculated values derived from flight tests conducted by the Cessna Aircraft Company under carefully documented conditions and will vary with individual airplanes and numerous other factors affecting flight performance.

#1:	*0	
		100
ri e e e e e e e e e e e e e e e e e e e		
		200



Information Manual



Cessna Aircraft Company

Model 182S

THIS MANUAL INCORPORATES INFORMATION ISSUED THRU REVISION 04 TO THE PILOT'S OPERATING HANDBOOK AND FAA APPROVED AIRPLANE FLIGHT MANUAL DATED 3 FEBRUARY 1997.

COPYRIGHT © 1997
The Cessna Aircraft Company
Wichita, Kansas USA



P/N: 182SIM

		4	6
ĝ			÷3
			8.67
			\otimes

TABLE OF CONTENTS

SECTION	ON
GENERAL	1
LIMITATIONS	2
EMERGENCY PROCEDURES	3
NORMAL PROCEDURES	4
PERFORMANCE	5
WEIGHT & BALANCE/EQUIPMENT LIST	6
AIRPLANE & SYSTEMS DESCRIPTION	7
HANDLING, SERVICE & MAINTENANCE	8
SLIPPI EMENTS	a

				*	2.	
	F-G					÷
			9			
		d				

SECTION 1 GENERAL

TABLE OF CONTENTS	Page
Three View - Normal Ground Attitude	1-2
Introduction	1-4
Descriptive Data	1-4
Engine	1-4
Propeller (2-Bladed)	1-4
Propeller (3-Bladed)	1-4
Fuel	1-5
Oil	1-6
Maximum Certificated Weights	1-7
Standard Airplane Weights	1-7
Cabin And Entry Dimensions	1-7
Baggage Space and Entry Dimensions	1-7
Specific Loadings	1-7
Symbols, Abbreviations and Terminology	1-8
General Airspeed Terminology And Symbols	1-8
Meteorological Terminology	1-9
Engine Power Terminology	1-9
Airplane Performance And Flight Planning Terminology	1-10
Weight And Balance Terminology	1-11
Metric / Imperial / U.S. Conversion Charts	1-13
Weight Conversions	1-14
Length Conversions	1-16
Distance Conversions	1-20
Volume Conversions	1-21
Temperature Conversions	1-24
Volume to Weight Conversions	1-25
Quick Conversions	1-26

Nov 15/00





Figure 1-1. Three View - Normal Ground Attitude (Sheet 1 of 2)



NOTE 1: WING SPAN SHOWN WITH STANDARD STROBE LIGHTS INSTALLED.

NOTE 2: NORMAL GROUND ATTITUDE IS SHOWN WITH NOSE STRUT SHOWING APPROXIMATELY 2" OF STRUT, AND WINGS LEVEL.

NOTE 3: WHEEL BASE LENGTH IS 661/2".

NOTE 4: PROPELLER GROUND CLEARANCE IS 10 ".

NOTE 5: WING AREA IS 174 SQUARE FEET.

NOTE 6: MINIMUM TURNING RADIUS (*PIVOT POINT TO OUTBOARD WING TIP) IS 27' - 0".

Figure 1-1. Three View - Normal Ground Attitude (Sheet 2 of 2)

INTRODUCTION

This handbook contains 9 sections, and includes the material required to be furnished to the pilot by FAR Part 23. It also contains supplemental data supplied by The Cessna Aircraft Company.

Section 1 provides basic data and information of general interest. It also contains definitions or explanations of symbols, abbreviations, and terminology commonly used.

DESCRIPTIVE DATA

ENGINE

Number of Engines: 1.

Engine Manufacturer: Textron Lycoming. Engine Model Number: IO-540-AB1A5.

Engine Type: Normally aspirated, direct drive, air-cooled,

horizontally opposed, fuel injected, six cylinder engine with

541 cu. in. displacement.

Horsepower Rating and Engine Speed: 230 rated BHP

at 2400 RPM.

PROPELLER (2-Bladed)

Propeller Manufacturer: McCauley Propeller Systems. Propeller Model Number: B2D34C235/90DKB-8.

Number of Blades: 2.

Propeller Diameter: 82 inches.

Propeller Type: Constant speed and hydraulically actuated, with a low pitch setting of 17.0° and a high pitch setting of 31.8° (30 inch

station).

PROPELLER (3-Bladed)

Propeller Manufacturer: McCauley Propeller Systems.

Propeller Model Number: B3D36C431/80VSA-1.

Number of Blades: 3.

Propeller Diameter: 79.0 inches.

Propeller Type: Constant speed and hydraulically actuated, with a low pitch setting of 14.9° and a high pitch setting of 31.7° (30 inch

station).

FUEL

WARNING

USE OF UNAPPROVED FUELS MAY RESULT IN DAMAGE TO THE ENGINE AND FUEL SYSTEM COMPONENTS, RESULTING IN POSSIBLE ENGINE FAILURE.

Approved Fuel Grades (and Colors): 100LL Grade Aviation Fuel (Blue). 100 Grade Aviation Fuel (Green).

NOTE

Isopropyl alcohol or diethylene glycol monomethyl ether (DiEGME) may be added to the fuel supply. Additive concentrations shall not exceed 1% for isopropyl alcohol or 0.10% to 0.15% for DiEGME. Refer to Section 8 for additional information.

Fuel Capacity:

Total Capacity: 92.0 U.S. gallons. Total Usable: 88.0 U.S. gallons. Total Capacity Each Tank: 46.0 U.S. gallons. Total Usable Each Tank: 44.0 U.S. gallons.

NOTE

To ensure maximum fuel capacity and minimize crossfeeding when refueling, always park the airplane in a wingslevel, normal ground attitude and place the fuel selector in the Left or Right position. Refer to Figure 1-1 for normal ground attitude dimensions.

Nov 15/00 1-5

OIL

Oil Specification:

MIL-L-6082 Aviation Grade Straight Mineral Oil: Used when the airplane was delivered from the factory and should be used to replenish the supply during the first 25 hours. This oil should be drained and the filter changed after the first 25 hours of operation. Refill the engine with MIL-L-6082 Aviation Grade Straight Mineral Oil and continue to use until a total of 50 hours has accumulated or oil consumption has stabilized.

MIL-L-22851 Aviation Grade Ashless Dispersant Oil: Oil conforming to Textron Lycoming Service Instruction No 1014, and all revisions and supplements thereto, **must be used** after first 50 hours or once oil consumption has stabilized.

Recommended Viscosity for Temperature Range:

Temperature	MIL-L-6082 SAE Grade	MIL-L-22851 Ashless Dispersant SAE Grade
Above 27°C (80°F)	60	60
Above 16°C (60°F)	50	40 or 50
-1°C (30°F) to 32°C (90°F)	40	40
-18°C (0°F) to 21°C (70°F)	30	30, 40 or 20W-40
Below -12°C (10°F)	20	30 or 20W-30
-18°C (0°F) - 32°C (90°F)	20W-50	20W-50 or 15W-50
All Temperatures	(6464	15W-50 or 20W-50

NOTE

When operating temperatures overlap, use the lighter grade of oil.

Oil Capacity:

Sump: 8 U.S. Quarts Total: 9 U.S. Quarts

MAXIMUM CERTIFICATED WEIGHTS

Ramp Weight: 3110 lbs. Takeoff Weight: 3100 lbs. Landing Weight: 2950 lbs.

Weight in Baggage Compartment, Normal Category:

Baggage Area A (Station 82 to 109): 120 lbs. See note below. 80 lbs. See note below.

NOTE

The maximum allowable combined weight capacity for baggage in areas A, B and C is 200 pounds. The maximum allowable weight capacity for baggage in areas B and C is 80 pounds.

STANDARD AIRPLANE WEIGHTS

Standard Empty Weight: 1925 lbs. Maximum Useful Load, Normal Category: 1185 lbs.

CABIN AND ENTRY DIMENSIONS

Detailed dimensions of the cabin interior and entry door openings are illustrated in Section 6.

BAGGAGE SPACE AND ENTRY DIMENSIONS

Dimensions of the baggage area and baggage door opening are illustrated in detail in Section 6.

SPECIFIC LOADINGS

Wing Loading: 17.8 lbs./sq. ft. Power Loading: 13.5 lbs./hp.

SYMBOLS, ABBREVIATIONS AND TERMINOLOGY

GENERAL AIRSPEED TERMINOLOGY AND SYMBOLS

KCAS	Knots Calibrated Airspeed is indicated airspeed corrected for position and instrument error and expressed in knots. Knots calibrated airspeed is equal to KTAS in standard atmosphere at sea level.
KIAS	Knots Indicated Airspeed is the speed shown on the airspeed indicator and expressed in knots.
KTAS	Knots True Airspeed is the airspeed expressed in knots relative to undisturbed air which is KCAS corrected for altitude and temperature.
V_A	Maneuvering Speed is the maximum speed at which full or abrupt control movements may be used.
V_{FE}	Maximum Flap Extended Speed is the highest speed permissible with wing flaps in a prescribed extended position.
V _{NO}	Maximum Structural Cruising Speed is the speed that should not be exceeded except in smooth air, then only with caution.
V_{NE}	Never Exceed Speed is the speed limit that may not be exceeded at any time.
V _S	Stalling Speed or the minimum steady flight speed is the minimum speed at which the airplane is controllable.
V_{SO}	Stalling Speed or the minimum steady flight speed is the minimum speed at which the airplane is controllable in the landing configuration at the most forward center of gravity.

Best Angle-of-Climb Speed is the speed which results in the greatest gain of altitude in a given horizontal distance. V_X

Best Rate-of-Climb Speed is the speed which V_{Y}

results in the greatest gain in altitude in a given time.

METEOROLOGICAL TERMINOLOGY

OAT Outside Air Temperature is the free air static

temperature. It may be expressed in either degrees

Celsius or degrees Fahrenheit.

Standard Standard Temperature is 15°C at sea level

pressure altitude and decreases by 2°C for each Temperature

1000 feet of altitude.

Pressure Altitude is the altitude read from an Pressure

Altitude altimeter when the altimeter's barometric scale has

been set to 29.92 inches of mercury (1013 mb).

ENGINE POWER TERMINOLOGY

BHP Brake Horsepower is the power developed by the

engine.

RPM **Revolutions Per Minute** is engine speed.

Static Static RPM is engine speed attained during a full

RPM throttle engine runup when the airplane is on the

ground and stationary.

MP Manifold Pressure is a pressure measured in the

engine's induction system and is expressed in

inches of mercury (in Hg).

SIL

AIRPLANE PERFORMANCE AND FLIGHT PLANNING TERMINOLOGY

Demonstrated Crosswind Velocity Demonstrated Crosswind Velocity is the velocity of the crosswind component for which adequate control of the airplane during takeoff and landing was actually demonstrated during certification tests. The value shown is not considered to be limiting.

Usable Fuel

Usable Fuel is the fuel available for flight planning.

Unusable Fuel Unusable Fuel is the quantity of fuel that can not be safely used in flight.

GPH

Gallons Per Hour is the amount of fuel consumed per hour.

NMPG

Nautical Miles Per Gallon is the distance which can be expected per gallon of fuel consumed at a specific engine power setting and/or flight configuration.

g

g is acceleration due to gravity.

Course Datum

Course Datum is the compass reference used by the autopilot, along with course deviation, to provide lateral control when tracking a navigation signal.

WEIGHT AND BALANCE TERMINOLOGY

Reference Datum	Reference Datum is an imaginary vertical plane from which all horizontal distances are measured for balance purposes.
Station	Station is a location along the airplane fuselage given in terms of the distance from the reference datum.
Arm	Arm is the horizontal distance from the reference datum to the center of gravity (C.G.) of an item.
Moment	Moment is the product of the weight of an item multiplied by its arm. (Moment divided by the constant 1000 is used in this handbook to simplify balance calculations by reducing the number of digits.)
Center of Gravity (C.G.)	Center of Gravity is the point at which an airplane, or equipment, would balance if suspended. Its distance from the reference datum is found by dividing the total moment by the total weight of the airplane.
C.G. Arm	Center of Gravity Arm is the arm obtained by adding the airplane's individual moments and dividing the sum by the total weight.
C.G. Limits	Center of Gravity Limits are the extreme center of gravity locations within which the airplane must be operated at a given weight.
Standard Empty Weight	Standard Empty Weight is the weight of a standard airplane, including unusable fuel, full operating fluids and full engine oil.
Basic Empty Weight	Basic Empty Weight is the standard empty weight plus the weight of optional equipment.
Useful Load	Useful Load is the difference between ramp weight and the basic empty weight.
MAC	MAC (Mean Aerodynamic Chord) is a chord of an imaginary rectangular airfoil having the same pitching moments throughout the flight range as that of the actual wing.

Maximum Ramp Weight Maximum Ramp Weight is the maximum weight approved for ground maneuver, and includes the weight of fuel used for start, taxi and runup.

Maximum Takeoff Weight Maximum Takeoff Weight is the maximum weight approved for the start of the takeoff roll.

Maximum Landing Weight **Maximum Landing Weight** is the maximum weight approved for the landing touchdown.

Tare

Tare is the weight of chocks, blocks, stands, etc. used when weighing an airplane, and is included in the scale readings. Tare is deducted from the scale reading to obtain the actual (net) airplane weight.

METRIC / IMPERIAL / U.S. CONVERSION CHARTS

The following charts have been provided to help international operators convert U.S. measurement supplied with the Pilot's Operating Handbook into metric and imperial measurements.

The standard followed for measurement units shown, is the National Institute of Standards Technology (NIST), Publication 811, "Guide for the Use of the International System of Units (SI)."

Please refer to the following pages for these charts.

Nov 15/00 1-13

(Kilograms \times 2.205 = Pounds)

(Pounds \times .454 = Kilograms)



KILOGRAMS INTO POUNDS


kg	0	1	2	3	4	5	6	7	8	9
	lb.									
0		2.205	4.409	6.614	8.819	11.023	13.228	15.432	17.637	19.842
10	22.046	24.251	26.456	28.660	30.865	33.069	35.274	37.479	39.683	41.888
20	44.093	46.297	48.502	50.706	52.911	55.116	57.320	59.525	61.729	63.934
30	66.139	68.343	70.548	72.753	74.957	77.162	79.366	81.571	83.776	85.980
40	88.185	90.390	92.594	94.799	97.003	99.208	101.41	103.62	105.82	108.03
50	110.23	112.44	114.64	116.85	119.05	121.25	123.46	125.66	127.87	130.07
60	132.28	134.48	136.69	138.89	141.10	143.30	145.51	147.71	149.91	152.12
70	154.32	156.53	158.73	160.94	163.14	165.35	167.55	169.76	171.96	174.17
80	176.37	178.57	180.78	182.98	185.19	187.39	189.60	191.80	194.01	196.21
90	198.42	200.62	202.83	205.03	207.24	209.44	211.64	213.85	216.05	218.26
										,
100	220.46	222.67	224.87	227.08	229.28	231.49	233.69	235.90	238.10	240.30

POUNDS INTO KILOGRAMS

lb.	0	1	2	3	4	5	6	7	8	9
	kg									
0		0.454	0.907	1.361	1.814	2.268	2.722	3.175	3.629	4.082
10	4.536	4.990	5.443	5.897	6.350	6.804	7.257	7.711	8.165	8.618
20	9.072	9.525	9.979	10.433	10.886	11.340	11.793	12.247	12.701	13.154
30	13.608	14.061	14.515	14.969	15.422	15.876	16.329	16.783	17.237	17,690
40	18.144	18.597	19.051	19.504	19.958	20.412	20.865	21.319	21.772	22.226
					1					
50	22.680	23.133	23.587	24.040	24.494	24.948	25.401	25.855	26.303	26.762
60	27.216	27.669	28.123	28.576	29.030	29.484	29.937	30.391	30.844	31.298
70	31.752	32.205	32.659	33.112	33.566	34.019	34.473	34.927	35.380	35.834
80	36.287	36.741	37.195	37.648	38.102	38.555	39.009	39.463	39.916	40.370
90	40.823	41.277	41.731	42.184	42.638	43.091	43.545	43.999	44.452	44.906
100	45.359	45.813	46.266	46.720	47.174	47.627	48.081	48.534	48.988	49.442

Figure 1-2. Weight Conversions (Sheet 1 of 2)

(Kilograms \times 2.205 = Pounds) - (Pounds \times .454 = Kilograms)



Units \times 10, 100, etc.

0585T1027

Figure 1-2. Weight Conversions (Sheet 2 of 2)

 $(Meters \times 3.281 = Feet)$

 $(Feet \times .305 = Meters)$

METERS INTO FEET METRES EN PIEDS

m	0	1	2	3	4	5	6	7	8	9
	feet									
0	***	3.281	6.562	9.842	13.123	16,404	19.685	22.956	26.247	29.528
10	32.808	36.089	39.370	42.651	45.932	49,212	52.493	55.774	59.055	62.336
20	65.617	68.897	72.178	75.459	78.740	82.021	85.302	88.582	91.863	95.144
30	98.425	101.71	104.99	108.27	111.55	114.83	118.11	121.39	124.67	127.95
40	131.23	134.51	137.79	141.08	144.36	147.64	150.92	154.20	157.48	160.76
										1 1
50	164.04	167.32	170.60	173.86	177.16	180.45	183.73	187.01	190.29	193.57
60	195.85	200.13	203.41	206.69	209.97	213.25	216.53	219.82	223.10	226.38
70	229.66	232.94	236.22	239.50	242.78	246.06	249.34	252.62	255.90	259.19
80	262.47	265.75	269.03	272.31	275.59	278.87	282.15	285.43	288.71	291.58
90	295.27	298.56	301.84	305.12	308.40	311.68	314.96	318.24	321.52	324.80
100	328.08	331.36	334.64	337.93	341.21	344.49	347.77	351.05	354.33	357.61

FEET INTO METERS PIEDS EN METRES

ft	0	1	2	3	4	5	6	7	8	9
	m	m	m	m	m	m	m	m	m	m
0		0.305	0.610	0.914	1.219	1.524	1.829	2.134	2.438	2.743
10	3.048	3.353	3.658	3.962	4.267	4.572	4.877	5.182	5.486	5.791
20	6.096	6.401	6.706	7.010	7.315	7.620	7.925	8.230	8.534	8.839
30	9.144	9.449	9.754	10.058	10.363	10.668	10.973	11.278	11.582	11.887
40	12.192	12.497	12.802	13.106	13.411	13.716	14.021	14.326	14.630	14.935
			1							
50	15.240	15.545	15.850	16.154	16.459	16.754	17.069	17.374	17.678	17.983
60	18.288	18.593	18.898	19.202	19.507	19.812	20.117	20.422	20.726	21.031
70	21.336	21.641	21.946	22.250	22.555	22.860	23.165	23.470	23.774	24.079
80	24.384	24.689	24.994	25.298	25.603	25.908	26.213	26.518	26.822	27.127
90	27.432	27.737	28.042	28.346	28.651	28.956	29.261	29.566	29.870	30.175
400	00.400	00 705	n4 000	04 004	04 000	00.004	20 200	00.644	20.010	22 222
100	30.480	30.785	31.090	31.394	31.699	32.004	32.309	32.614	32.918	33.223

Figure 1-3. Length Conversions (Sheet 1 of 2)

 $(Meters \times 3.281 = Feet)$

 $(Feet \times .305 = Meters)$




Figure 1-3. Length Conversions (Sheet 2 of 2)

(Centimeters \times .394 = Inches) (Inches \times 2.54 = Centimeters)

CENTIMETERS INTO INCHES

cm	0	1	2	3	4	5	6	7	8	9
	in.									
0		0.394	0.787	1.181	1.575	1.969	2.362	2.756	3.150	3.543
10	3.937	4.331	4.724	5.118	5.512	5.906	6.299	6.693	7.087	7.480
20	7.874	8.268	8.661	9.055	9.449	9.843	10.236	10.630	11.024	11.417
30	11.811	12.205	12.598	12.992	13.386	13.780	14.173	14.567	14.961	15.354
40	15.748	16.142	16.535	16.929	17.323	17.717	18.110	18.504	18.898	19.291
50	19.685	20.079	20.472	20.866	21.260	21.654	22.047	22.441	22.835	23.228
60	23.622	24.016	24.409	24.803	25.197	25.591	25.984	26.378	26.772	27.164
70	27.559	27.953	28.346	28.740	29.134	29.528	29.921	30.315	30.709	31.102
80	31.496	31.890	32.283	32.677	33.071	33.465	33.858	34.252	34.646	35.039
90	35.433	35.827	36.220	36.614	37.008	37.402	37.795	38.189	38.583	38.976
100	39.370	39.764	40.157	40.551	40.945	41.339	41.732	42.126	42.520	42.913

INCHES INTO CENTIMETERS

in.	0	1	2	3	4	5	6	7	8	9
	cm									
0		2.54	5.08	7.62	10.16	12.70	15.24	17.78	20.32	22.96
10	25.40	27.94	30.48	33.02	35.56	38.10	40.64	43.18	45.72	48.26
20	50.80	53.34	55.88	58.42	60.96	63.50	66.04	68.58	71.12	73.66
30	76.20	78.74	81.28	83.82	86.36	88.90	91.44	93.98	96.52	99.06
40	101.60	104.14	106.68	109.22	111.76	114.30	116.84	119.38	121.92	124.46
1								l		
50	127.00	129.54	132.08	134.62	137.16	139.70	142.24	144.78	147.32	149.86
60	152.40	154.94	157.48	160.02	162.56	165.10	167.64	170.18	172.72	175.26
70	177.80	180.34	182.88	185.42	187.96	190.50	193.04	195.58	198.12	200.66
80	203.20	205.74	208.28	210.82	213.36	215.90	218.44	220.98	223.52	226.06
90	228.60	231.14	233.68	236.22	238.76	241.30	243.84	246.38	248.92	251.46
100	254.00	256.54	259.08	261.62	264.16	266.70	269.24	271.78	274.32	276.86

Figure 1-4. Length Conversions (Sheet 1 of 2)

G

(Centimeters \times .394 = Inches) - (Inches \times 2.54 = Centimeters)




Figure 1-4. Length Conversions (Sheet 2 of 2)

(Statute Miles ×1.609=Kilometers) (Statute Miles ×.869=Nautical Miles) (Nautical Miles ×1.852=Kilometers) (Kilometers ×.622=Statute Miles) (Nautical Miles ×1.15=Statute Miles) (Kilometers ×.54=Nautical Miles)




Figure 1-5. Distance Conversions

(Imperial Gallons × 4.546 = Liters)

(Liters \times .22 = Imperial Gallons)



LITERS INTO IMPERIAL GALLONS

	_
۲.	
-	

Lt	0	1	2	3	4	5	6	7	8	9
	IG									
0		0.220	0.440	0.660	0.880	1.100	1.320	1.540	1.760	1.980
10	2.200	2.420	2.640	2.860	3.080	3.300	3.520	3.740	3.960	4.180
20	4.400	4.620	4.840	5.059	5.279	5.499	5.719	5.939	6.159	6.379
30	6.599	6.819	7.039	7.259	7.479	7.699	7.919	8.139	8.359	8.579
40	8.799	9.019	9.239	9.459	9.679	9.899	10.119	10.339	10.559	10.779
50	10.999	11.219	11.439	11.659	11.879	12.099	12.319	12.539	12.759	12.979
60	13.199	13.419	13.639	13.859	14.078	14.298	14.518	14.738	14.958	15.178
70	15.398	15.618	15.838	16.058	16.278	16.498	16.718	16.938	17.158	17.378
80	17.598	17.818	18.038	18.258	18.478	18.698	18.918	19.138	19.358	19.578
90	19.798	20.018	20.238	20.458	20.678	20.898	21.118	21.338	21.558	21.778
100	21.998	22.218	22.438	22.658	22.878	23.098	23.318	23.537	23.757	23.977


IMPERIAL GALLONS INTO LITERS



IG	0	1	2	3	4	5	6	7	8	9
	Lt									
0		4.546	9.092	13.638	18.184	22.730	27.276	31.822	36.368	40.914
10	45.460	50.006	54.552	59.097	63.643	68.189	72.735	77.281	81.827	86.373
20	90.919	95.465	100.01	104.56	109.10	113.65	118.20	122.74	127.29	131.83
30	136.38	140.93	145.47	150.02	154.56	159.11	163.66	168.20	172.75	177,29
40	181.84	186.38	190.93	195.48	200.02	204.57	209.11	213.66	218.21	222.75
50	227.30	231.84	236.39	240.94	245.48	250.03	254.57	259.12	263.67	268.21
60	272.76	277.30	281.85	286.40	290.94	295.49	300.03	304.58	309.13	313.67
70	318.22	322.76	327.31	331.86	336.40	340.95	345.49	350.04	354.59	359.13
80	363.68	368.22	372.77	377.32	381.86	386.41	390.95	395.50	400.04	404.59
90	409.14	413.68	418.23	422.77	427.32	431.87	436.41	440.96	445.50	450.05
100	454.60	459.14	463.69	468.23	472.78	477.33	481.87	486.42	490.96	495.51

Figure 1-6. Volume Conversions (Sheet 1 of 3)

Nov 15/00 1-21



Units \times 10, 100, etc.

0585T1032

Figure 1-6. Volume Conversions (Sheet 2 of 3)

1




Figure 1-6. Volume Conversions (Sheet 3 of 3)

Nov 15/00 1-23

TEMPERATURE CONVERSIONS




Figure 1-7. Temperature Conversions




Figure 1-8. Volume to Weight Conversion




Figure 1-9. Quick Conversions

SECTION 2 LIMITATIONS

TABLE OF CONTENTS									
	0.0								
Introduction	2-3								
Airspeed Limitations	2-4								
Airspeed Indicator Markings	2-5								
Powerplant Limitations	2-5								
Powerplant Instrument Markings	2-6								
Weight Limits	2-7								
Center Of Gravity Limits	2-7								
Maneuver Limits	2-8								
Flight Load Factor Limits	2-8								
Kinds Of Operation Limits	2-8								
Fuel Limitations	2-8								
Other Limitations	2-9								
Flap Limitations	2-9								
Placards	2-13								

			80

٠

.

INTRODUCTION

Section 2 includes operating limitations, instrument markings, and basic placards necessary for the safe operation of the airplane, its engine, standard systems and standard equipment. The limitations included in this section have been approved by the Federal Aviation Administration. Observance of these operating limitations is required by Federal Aviation Regulations.

NOTE

Refer to Supplements, Section 9 of this Handbook for amended operating limitations, operating procedures, performance data and other necessary information for airplanes equipped with specific options.

NOTE

The airspeeds listed in the Airspeed Limitations chart (Figure 2-1) and the Airspeed Indicator Markings chart (Figure 2-2) are based on Airspeed Calibration data shown in Section 5 with the normal static source. If the alternate static source is being used, ample margins should be observed to allow for the airspeed calibration variations between the normal and alternate static sources as shown in Section 5.

Your Cessna is certificated under FAA Type Certificate No. 3A13 as Cessna Model No. 182S.

Nov 15/00 2-3

AIRSPEED LIMITATIONS

Airspeed limitations and their operational significance are shown in Figure 2-1.

SYMBOL	SPEED	KCAS	KIAS	REMARKS
V _{NE}	Never Exceed Speed	170	175	Do not exceed this speed in any operation.
V _{NO}	Maximum Structural Cruising Speed	137	140	Do not exceed this speed except in smooth air, and then only with caution.
VA	Maneuvering Speed: 3100 Pounds 2600 Pounds 2000 Pounds	109 101 89	110 101 88	Do not make full or abrupt control movements above this speed.
V _{FE}	Maximum Flap Extended Speed: 0° to 10° Flaps 10° to 20° Flaps 20° to FULL Flaps	137 118 100	140 120 100	Do not exceed this speed with flaps down.
	Maximum Window Open Speed	170	175	Do not exceed this speed with windows open.

Figure 2-1. Airspeed Limitations

AIRSPEED INDICATOR MARKINGS

Airspeed indicator markings and their color code significance are shown in Figure 2-2.

MARKING	KIAS VALUE OR RANGE	SIGNIFICANCE
White Arc	36 - 100	Full Flap Operating Range.
Green Arc	43 -140	Normal Operating Range.
Yellow Arc	140-175	Operations must be conducted with caution and only in smooth air.
Red Line	175	Maximum speed for all operations.

Figure 2-2. Airspeed Indicator Markings

POWERPLANT LIMITATIONS

Engine Manufacturer: Textron Lycoming. Engine Model Number: IO-540-AB1A5. Maximum Power: 230 BHP rating.

Engine Operating Limits for Takeoff and Continuous Operations:

Maximum Engine Speed: 2400 RPM.

Maximum Cylinder Head Temperature: 500°F (260°C). Maximum Oil Temperature: 245°F (118°C).

Oil Pressure, Minimum:

Minimum: 20 PSI. Maximum: 115 PSI.

Fuel Grade: See Fuel Limitations.

Oil Grade (Specification):

MIL-L-6082 Aviation Grade Straight Mineral Oil or MIL-L-22851

Ashless Dispersant Oil.

Propeller Manufacturer: McCauley Propeller Systems.

Propeller Model Number: 2-Bladed: B2D34C235/90DKB-8.

3-Bladed: B3D36C431/80VSA-1

Propeller Diameter,

2-Bladed Maximum: 82 0 inches.

2-Bladed Minimum: 80.5 inches. 3-Bladed Maximum: 79.0 inches.

3-Bladed Minimum: 77.5 inches.

Propeller Blade Angle at 30 Inch Station:

2-Bladed Low Pitch: 17.0°. 2-Bladed High Pitch: 31.8°. 3-Bladed Low Pitch: 14.9°. 3-Bladed High Pitch: 31.7°.

POWERPLANT INSTRUMENT MARKINGS

Powerplant instrument markings and their color code significance are shown in Figure 2-3.

INSTRUMENT	RED LINE (MINIMUM)	GREEN ARC (NORMAL OPERATING)	RED LINE (MAX)
Tachometer:		2000 - 2400 RPM	2400
Manifold Pressure		15 - 23 ln. Hg.	
Cylinder Head Temperature		200 - 500°F	500°F
Oil Temperature		100 - 245°F	245°F
Oil Pressure	20 PSI	50 - 90 PSI	115 PSI
Fuel Quantity	0 (2.0 Gal. Unusable Each Tank)	(-111	1444
Fuel Flow (Pressure)		0 to 15 GPH	
Vacuum Gauge		4.5 - 5.5 in.Hg	

Figure 2-3. Powerplant Instrument Markings

WEIGHT LIMITS

Maximum Ramp Weight: 3110 lbs. Maximum Takeoff Weight: 3100 lbs. Maximum Landing Weight: 2950 lbs.

Maximum Weight in Baggage Compartment:

Baggage Area A - Station 82 to 109: 120 lbs. See note below. Baggage Area B - Station 109 to 124: 80 lbs. See note below. Baggage Area C - Station 124 to 134: 80 lbs. See note below.

NOTE

The maximum allowable combined weight capacity for baggage in areas A, B and C is 200 pounds. The maximum allowable weight capacity for baggage in areas B and C is 80 pounds.

CENTER OF GRAVITY LIMITS

Center of Gravity Range:

Forward: 33.0 inches aft of datum at 2250 lbs. or less, with

straight line variation to 40.9 inches aft of datum at

3100 lbs.

Aft: 46.0 inches aft of datum at all weights.

Reference Datum: Front face of firewall.

MANEUVER LIMITS

This airplane is certificated in the normal category. The normal category is applicable to aircraft intended for non-aerobatic operations. These include any maneuvers incidental to normal flying, stalls (except whip stalls), lazy eights, chandelles, and steep turns in which the angle of bank is not more than 60°.

Aerobatic maneuvers, including spins, are not approved.

FLIGHT LOAD FACTOR LIMITS

Flight Load Factors:	
*Flaps Up	+3.8g, -1.52g
*Flaps Down	+2.0g

^{*}The design load factors are 150% of the above, and in all cases, the structure meets or exceeds design loads.

KINDS OF OPERATION LIMITS

The airplane as delivered is equipped for day, night, VFR, IFR and may be equipped for night VFR and/or IFR operations. FAR Part 91 establishes the minimum required instrumentation and equipment for these operations. The reference to types of flight operations on the operating limitations placard reflects equipment installed at the time of Airworthiness Certificate issuance.

Flight into known icing conditions is prohibited.

FUEL LIMITATIONS

Total Fuel: 92 U.S. gallons (2 tanks at 46.0 gallons each).

Usable Fuel (all flight conditions): 88.0 U.S. gallons.

Unusable Fuel: 4.0 U.S. gallons (2.0 gallons each tank).

NOTE

To ensure maximum fuel capacity and minimize crossfeeding when refueling, always park the airplane in a wingslevel, normal ground attitude and place the fuel selector in the Left or Right position. Refer to Figure 1-1 for normal ground attitude definition.

Takeoff and land with the fuel selector valve handle in the BOTH position.

Operation on either LEFT or RIGHT tank limited to level flight only.

With 1/4 tank or less, prolonged uncoordinated flight is prohibited when operating on either left or right tank.

Approved Fuel Grades (and Colors):

100LL Grade Aviation Fuel (Blue). 100 Grade Aviation Fuel (Green).

OTHER LIMITATIONS

FLAP LIMITATIONS

Approved Takeoff Range:	 0° to 20°
Approved Landing Range:	 0° to FULL

Feb 3/97 2-9

PLACARDS

The following information must be displayed in the form of composite or individual placards.

1. In full view of the pilot: (The "DAY-NIGHT-VFR-IFR" entry, shown on the example below, will vary as the airplane is equipped).

The markings and placards installed in this airplane contain operating limitations which must be complied with when operating this airplane in the Normal Category. Other operating limitations which must be complied with when operating this airplane in this category are contained in the Pilot's Operating Handbook and FAA Approved Airplane Flight Manual.

No acrobatic maneuvers, including spins, approved.

Flight into known icing conditions prohibited.

This airplane is certified for the following flight operations as of date of original airworthiness certificate:

DAY-NIGHT-VFR-IFR

2. On control lock:

CAUTION
CONTROL LOCK
REMOVE BEFORE STARTING ENGINE

3. On the fuel selector valve:

BOTH 88.0 GAL. TAKEOFF LANDING ALL FLIGHT ATTITUDES

> FUEL SELECTOR

PUSH DOWN ROTATE

LEFT 44.0 GAL. LEVEL FLIGHT ONLY RIGHT 44.0 GAL LEVEL FLIGHT ONLY

OFF

4. Near the fuel tank filler cap:

FUEL 100LL/100 MIN. GRADE AVIATION GASOLINE CAP 44.0 U.S. GAL USABLE CAP 32.5 U.S. GAL. USABLE TO BOTTOM OF FILLER INDICATOR

5. On flap control indicator:

0° to 10°	140 KIAS	(Partial flap range with dark blue color code; also, mechanical detent at 10°.)
10° to 20°	120 KIAS	(Light blue color code; also mechanical detent at 20°)
20° to FULL	100 KIAS	(White color code)

6. On baggage door:

120 POUNDS MAXIMUM BAGGAGE FORWARD OF BAGGAGE DOOR LATCH AND

80 POUNDS MAXIMUM BAGGAGE AFT OF BAGGAGE DOOR LATCH

MAXIMUM 200 POUNDS COMBINED

FOR ADDITIONAL LOADING INSTRUCTIONS SEE WEIGHT AND BALANCE DATA

- 7. A calibration card must be provided to indicate the accuracy of the magnetic compass in 30° increments.
- 8. On the oil filler cap:

OIL 9 QTS

9. Near airspeed indicator:

MANEUVER SPEED - 110 KIAS

10. On the upper right instrument panel:

SMOKING PROHIBITED

11. On auxiliary power plug door and second placard on battery box:

CAUTION 24 VOLTS D.C.
THIS AIRCRAFT IS EQUIPPED WITH ALTERNATOR AND A
NEGATIVE GROUND SYSTEM. OBSERVE PROPER POLARITY.
REVERSE POLARITY WILL DAMAGE ELECTRICAL
COMPONENTS.

12. On Upper Right Side of the Aft Cabin Partition:

EMERGENCY LOCATOR TRANSMITTER
INSTALLED AFT OF THIS PARTITION
MUST BE SERVICED IN ACCORDANCE
WITH FAR PART 91.207

13. Near the fuel flow gauge:

MAXIMUM POWER FUEL FLOW			
ALTITUDE S.L. 2000' 4000' 6000' 8000' 10000' 12000'	FUEL FLOW 20.5 GPH 19.0 GPH 17.5 GPH 16.5 GPH 15.5 GPH 14.5 GPH 13.5 GPH		

		3

SECTION 3 EMERGENCY PROCEDURES

TABLE OF CONTENTS	Page
Introduction	3-3
AIRSPEEDS	
Airspeeds For Emergency Operation	3-3
EMERGENCY PROCEDURES CHECKLIST	
Engine Failures	3-4
Engine Failure During Takeoff Roll	3-4
Engine Failure Immediately After Takeoff	3-4
Engine Failure During Flight (Restart Procedures)	
Forced Landings	3-5
Emergency Landing Without Engine Power	3-5
Precautionary Landing With Engine Power	3-5
Ditching	3-5
Fires	3-6
During Start On Ground	3-6
Engine Fire In Flight	3-7
Electrical Fire In Flight	3-7
Cabin Fire	3-8
Wing Fire	3-8
Icing	3-9
Inadvertent Icing Encounter	3-9
Static Source Blockage	3-10
Landing With A Flat Main Tire	3-10

Feb 3/97

TABLE OF CONTENTS (Continued)

Landing With A Flat Nose Tire Electrical Power Supply System Malfunctions Ammeter Shows Excessive Rate of Charge	Page 3-10 3-11
(Full Scale Deflection)	3-11 3-11
(Ammeter Indicates Discharge)	3-12
AMPLIFIED EMERGENCY PROCEDURES	
Engine Failure	3-13
Forced Landings	3-15
Landing Without Elevator Control	3-15
Fires	3-16
Emergency Operation In Clouds (Vacuum System Failure)	3-16
Executing A 180° Turn In Clouds	3-16
Emergency Descent Through Clouds	3-17
Recovery From Spiral Dive In The Clouds	3-18
Inadvertent Flight Into Icing Conditions	3-18
Static Source Blocked	3-18
Spins	3-19
Rough Engine Operation Or Loss Of Power	3-20
Spark Plug Fouling	3-20
Magneto Malfunction	3-20
Low Oil Pressure	3-20
Electrical Power Supply System Malfunctions	3-21
Excessive Rate of Charge	3-21
Insufficient Rate Of Charge	3-22
Other Emergencies	3-22
Windshield Damage	3-22

Feb 3/97

INTRODUCTION

Section 3 provides checklist and amplified procedures for coping with emergencies that may occur. Emergencies caused by airplane or engine malfunctions are extremely rare if proper preflight inspections and maintenance are practiced. Enroute weather emergencies can be minimized or eliminated by careful flight planning and good judgment when unexpected weather is encountered. However, should an emergency arise, the basic guidelines described in this section should be considered and applied as necessary to correct the problem. Emergency procedures associated with standard avionics, the ELT, or any optional systems can be found in the Supplements, Section 9.

AIRSPEEDS

AIRSPEEDS FOR EMERGENCY OPERATION

Engine Failure After Takeoff:	
Wing Flaps Up	75 KIAS
Wing Flaps Down	70 KIAS
Maneuvering Speed:	
3100 Lbs	110 KIAS
2600 Lbs	101 KIAS
2000 Lbs	88 KIAS
Maximum Glide:	
3100 Lbs	75 KIAS
2600 Lbs	70 KIAS
2000 Lbs	62 KIAS
Precautionary Landing With Engine Power	70 KIAS
Landing Without Engine Power:	
Wing Flaps Up	75 KIAS
Wing Flaps Down	70 KIAS

Nov 15/00 3-3

EMERGENCY PROCEDURES CHECKLIST

Procedures in the Emergency Procedures Checklist portion of this section shown in **bold faced** type are immediate action items which should be committed to memory.

ENGINE FAILURES

ENGINE FAILURE DURING TAKEOFF ROLL

- 1. Throttle -- IDLE.
- 2. Brakes-- APPLY.
- 3. Wing Flaps -- RETRACT.
- 4. Mixture -- IDLE CUT OFF.
- 5. Ignition Switch -- OFF.
- 6. Master Switch -- OFF.

ENGINE FAILURE IMMEDIATELY AFTER TAKEOFF

- Airspeed -- 75 KIAS (flaps UP).
 70 KIAS (flaps DOWN).
- 2. Mixture -- IDLE CUT OFF.
- 3. Fuel Selector Valve -- PUSH DOWN and ROTATE TO OFF.
- 4. Ignition Switch -- OFF.
- 5. Wing Flaps -- AS REQUIRED (FULL recommended).
- 6. Master Switch -- OFF.
- 7. Cabin Door -- UNLATCH.
- 8. Land -- STRAIGHT AHEAD.

ENGINE FAILURE DURING FLIGHT (Restart Procedures)

- 1. Airspeed -- 75 KIAS (Best glide speed).
- 2. Fuel Selector Valve -- BOTH.
- 3. Auxiliary Fuel Pump Switch -- ON.
- 4. Mixture -- RICH (if restart has not occurred).
- 5. Ignition Switch -- BOTH (or START if propeller is stopped).

FORCED LANDINGS

EMERGENCY LANDING WITHOUT ENGINE POWER

- Passenger Seat Backs -- MOST UPRIGHT POSITION.
- 2. Seats and Seat belts -- SECURE.
- Airspeed -- 75 KIAS (flaps UP).
 70 KIAS (flaps DOWN).
- 4. Mixture -- IDLE CUT OFF.
- 5. Fuel Selector Valve -- PUSH DOWN and ROTATE TO OFF.
- 6. Ignition Switch -- OFF.
- 7. Wing Flaps -- AS REQUIRED (FULL recommended).
- 8. Master Switch -- OFF (when landing is assured).
- 9. Doors -- UNLATCH PRIOR TO TOUCHDOWN.
- 10. Touchdown -- SLIGHTLY TAIL LOW.
- 11. Brakes -- APPLY HEAVILY.

PRECAUTIONARY LANDING WITH ENGINE POWER

- 1. Passenger Seat Backs -- MOST UPRIGHT POSITION.
- 2. Seats and Seat Belts -- SECURE.
- 3. Airspeed -- 75 KIAS
- 4. Wing Flaps -- 20°.
- 5. Selected Field -- FLY OVER, noting terrain and obstructions, then retract flaps upon reaching a safe altitude and airspeed.
- 6. Avionics Master Switch and Electrical Switches -- OFF.
- 7. Wing Flaps -- FULL (on final approach).
- 8. Airspeed -- 70 KIAS.
- 9. Master Switch -- OFF.
- 10. Doors -- UNLATCH PRIOR TO TOUCHDOWN.
- 11. Touchdown -- SLIGHTLY TAIL LOW.
- 12. Ignition Switch -- OFF.
- 13. Brakes -- APPLY HEAVILY.

DITCHING

- 1. Radio -- TRANSMIT MAYDAY on 121.5 MHz, giving location and intentions and SQUAWK 7700.
- 2. Heavy Objects (in baggage area) -- SECURE OR JETTISON (if possible).

Nov 15/00 3-5

- 3. Passenger Seat Backs -- MOST UPRIGHT POSITION.
- 4. Seats and Seat Belts -- SECURE.
- 5. Wing Flaps -- 20° to FULL.
- 6. Power -- ESTABLISH 300 FT/MIN DESCENT AT 65 KIAS.

NOTE

If no power is available, approach at 70 KIAS with flaps up or at 65 KIAS with 10° flaps.

- 7. Approach -- High Winds, Heavy Seas -- INTO THE WIND. Light Winds, Heavy Swells -- PARALLEL TO SWELLS.
- 8. Cabin Doors -- UNLATCH.
- 9. Touchdown -- LEVEL ATTITUDE AT ESTABLISHED RATE OF DESCENT.
- 10. Face -- CUSHION at touchdown with folded coat.
- 11. ELT -- Activate.
- 12. Airplane -- EVACUATE through cabin doors. If necessary, open window and flood cabin to equalize pressure so doors can be opened.
- 13. Life Vests and Raft -- INFLATE WHEN CLEAR OF AIRPLANE.

FIRES

DURING START ON GROUND

1. Cranking -- CONTINUE to get a start which would suck the flames and accumulated fuel into the engine.

If engine starts:

- 2. Power -- 1700 RPM for a few minutes.
- 3. Engine -- SHUTDOWN and inspect for damage.

If engine fails to start:

- 4. Throttle -- FULL OPEN.
- 5. Mixture -- IDLE CUT OFF.
- 6. Cranking -- CONTINUE.
- 7. Fuel Selector Valve -- PUSH DOWN and ROTATE TO OFF.
- 8. Auxiliary Fuel Pump -- OFF.

- 9. Fire Extinguisher -- OBTAIN (have ground attendants obtain if not installed).
- 10. Engine -- SECURE.
 - a. Master Switch -- OFF.
 - b. Ignition Switch -- OFF
- 11. Parking Brake -- RELEASE.
- 12. Airplane -- EVACUATE.
- Fire -- EXTINGUISH using fire extinguisher, wool blanket, or dirt.
- 14. Fire Damage -- INSPECT, repair damage or replace damaged components or wiring before conducting another flight.

ENGINE FIRE IN FLIGHT

- 1. Mixture -- IDLE CUT OFF.
- 2. Fuel Selector Valve -- PUSH DOWN and ROTATE TO OFF.
- 3. Auxiliary Fuel Pump Switch -- OFF.
- 4. Master Switch -- OFF.
- 5. Cabin Heat and Air -- OFF (except overhead vents).
- 6. Airspeed -- 100 KIAS (If fire is not extinguished, increase glide speed to find an airspeed within airspeed limitations which will provide an incombustible mixture).
- 7. Forced Landing -- EXECUTE (as described in Emergency Landing Without Engine Power).

ELECTRICAL FIRE IN FLIGHT

- 1. Master Switch -- OFF.
- 2. Vents, Cabin Air, Heat -- CLOSED.
- 3. Fire Extinguisher -- ACTIVATE (if available).
- 4. Avionics Master Switch -- OFF.
- 5. All Other Switches (except ignition switch) -- OFF.

A WARNING

AFTER DISCHARGING FIRE EXTINGUISHER AND ASCERTAINING THAT THE FIRE HAS BEEN EXTINGUISHED, VENTILATE THE CABIN.

6. Vents/Cabin Air/Heat -- OPEN when it is ascertained that fire is completely extinguished.

If fire has been extinguished and electrical power is necessary for continuance of flight to nearest suitable airport or landing area:

- 7. Master Switch -- ON.
- 8. Circuit Breakers -- CHECK for faulty circuit, do not reset.
- 9. Radio Switches -- OFF.
- 10. Avionics Master Switch -- ON.
- 11. Radio/Electrical Switches -- ON one at a time, with delay after each until short circuit is localized.

CABIN FIRE

- 1. Master Switch -- OFF.
- Vents/Cabin Air/Heat -- CLOSED (to avoid drafts).
- 3. Fire Extinguisher -- ACTIVATE (if available).

WARNING

AFTER DISCHARGING FIRE EXTINGUISHER AND ASCERTAINING THAT FIRE HAS BEEN EXTINGUISHED, VENTILATE THE CABIN.

- 4. Vents/Cabin Air/Heat -- Open when it is ascertained that fire is completely extinguished.
- 5. Land the airplane as soon as possible to inspect for damage.

WING FIRE

- 1. Landing/Taxi Light Switches -- OFF.
- 2. Navigation Light Switch -- OFF.
- 3. Strobe Light Switch -- OFF.
- 4. Pitot Heat Switch OFF.

NOTE

Perform a sideslip to keep the flames away from the fuel tank and cabin. Land as soon as possible using flaps only as required for final approach and touchdown.

ICING

INADVERTENT ICING ENCOUNTER

- 1. Turn pitot heat switch ON.
- 2. Turn back or change altitude to obtain an outside air temperature that is less conducive to icing.
- 3. Pull cabin heat control full out and rotate defroster control clockwise to obtain maximum defroster airflow.
- 4. Increase engine speed to minimize ice build-up on propeller blades.
- 5. Watch for signs of induction air filter icing. An unexplained loss of manifold pressure could be caused by ice blocking the air intake filter. Adjust the throttle as desired to set manifold pressure. Adjust mixture, as required for any change in power settings.
- 6. Plan a landing at the nearest airport. With an extremely rapid ice build up, select a suitable "off airport" landing site.
- 7. With an ice accumulation of 1/4 inch or more on the wing leading edges, be prepared for significantly higher stall speed.
- 8. Leave wing flaps retracted. With a severe ice build up on the horizontal tail, the change in wing wake airflow direction caused by wing flap extension could result in a loss of elevator effectiveness.
- 9. Open left window and, if practical, scrape ice from a portion of the windshield for visibility in the landing approach.
- 10. Perform a landing approach using a forward slip, if necessary, for improved visibility.
- 11. Approach at 80 to 90 KIAS depending upon the amount of the accumulation.
- 12. Perform a landing in level attitude.

Feb 3/97 3-9

STATIC SOURCE BLOCKAGE (Erroneous Instrument Reading Suspected)

- 1. Static Pressure Alternate Source Valve -- PULL ON.
- 2. Airspeed -- Consult appropriate calibration table in Section 5.
- 3. Altitude -- Consult altimeter correction table in Section 5.

LANDING WITH A FLAT MAIN TIRE

- 1. Approach -- NORMAL.
- 2. Wing Flaps -- FULL DOWN.
- 3. Touchdown -- GOOD MAIN TIRE FIRST, hold airplane off flat tire as long as possible with aileron control.
- 4. Directional Control -- MAINTAIN using brake on good wheel as required.

LANDING WITH A FLAT NOSE TIRE

- 1. Approach -- NORMAL.
- 2. Flaps -- AS REQUIRED.
- 3. Touchdown -- ON MAINS, hold nose wheel off the ground as long as possible.
- 4. When nose wheel touches down, maintain full up elevator as airplane slows to stop.

ELECTRICAL POWER SUPPLY SYSTEM MALFUNCTIONS

AMMETER SHOWS EXCESSIVE RATE OF CHARGE (Full Scale Deflection)

- 1. Alternator -- OFF.
- 2. Nonessential Electrical Equipment -- OFF.
- 3. Flight -- TERMINATE as soon as practical.

LOW VOLTAGE ANNUNCIATOR (VOLTS) ILLUMINATES DURING FLIGHT (Ammeter Indicates Discharge)

NOTE

Illumination of "VOLTS" on the annunciator panel may occur during low RPM conditions with an electrical load on the system such as during a low RPM taxi. Under these conditions, the light will go out at higher RPM. The master switch need not be recycled since an overvoltage condition has not occurred to deactivate the alternator system.

- 1. Avionics Master Switch -- OFF.
- 2. Alternator Circuit Breaker -- CHECK IN.
- 3. Master Switch -- OFF (both sides).
- 4. Master Switch -- ON.
- 5. Low Voltage Annunciator -- CHECK OFF.
- 6. Avionics Master Switch -- ON.

Nov 15/00

If low voltage light illuminates again:

- 7. Alternator-- OFF.
- 8. Nonessential Radio and Electrical Equipment -- OFF.
- 9. Flight -- TERMINATE as soon as practical.

VACUUM SYSTEM FAILURE

Left Vacuum or Right Vacuum Annunciator Light (L VAC R) Illuminates.

A CAUTION

IS NOT NORMAL **VACUUM** WITHIN FAILURE HAS OPERATING LIMITS, Α OCCURRED IN THE VACUUM SYSTEM AND PROCEDURES BE MAY PARTIAL PANEL REQUIRED FOR CONTINUED FLIGHT.

 Vacuum Gauge – CHECK to ensure vacuum within normal operating limits.

AMPLIFIED EMERGENCY PROCEDURES

The following Amplified Emergency Procedures elaborate upon information contained in the Emergency Procedures Checklists portion of this section. These procedures also include information not readily adaptable to a checklist format, and material to which a pilot could not be expected to refer in resolution of a specific emergency. This information should be reviewed in detail prior to flying the airplane, as well as reviewed on a regular basis to keep pilot's knowledge of procedures fresh.

ENGINE FAILURE

If an engine failure occurs during the takeoff roll, the most important thing to do is stop the airplane on the remaining runway. Those extra items on the checklist will provide added safety after a failure of this type.

Prompt lowering of the nose to maintain airspeed and establish a glide attitude is the first response to an engine failure after takeoff. In most cases, the landing should be planned straight ahead with only small changes in direction to avoid obstructions. Altitude and airspeed are seldom sufficient to execute a 180° gliding turn necessary to return to the runway. The checklist procedures assume that adequate time exists to secure the fuel and ignition systems prior to touchdown.

Feb 3/97 3-13

After an engine failure in flight, the most important course of action is to continue flying the airplane. Best glide speed as shown in Figure 3-1 should be established as quickly as possible. While gliding toward a suitable landing area, an effort should be made to identify the cause of the failure. If time permits, an engine restart should be attempted as shown in the checklist. If the engine cannot be restarted, a forced landing without power must be completed.




Figure 3-1. Maximum Glide

FORCED LANDINGS

If all attempts to restart the engine fail and a forced landing is imminent, select a suitable field and prepare for the landing as discussed under the Emergency Landing Without Engine Power checklist. Transmit Mayday message on 121.5 MHz giving location and intentions and squawk 7700.

Before attempting an "off airport" landing with engine power available, one should fly over the landing area at a safe but low altitude to inspect the terrain for obstructions and surface conditions, proceeding as discussed under the Precautionary Landing With Engine Power checklist.

Prepare for ditching by securing or jettisoning heavy objects located in the baggage area and collect folded coats for protection of occupants' face at touchdown. Transmit Mayday message on 121.5 MHz giving location and intentions and squawk 7700. Avoid a landing flare because of difficulty in judging height over a water surface. The checklist assumes the availability of power to make a precautionary water landing. If power is not available, use of the airspeeds noted with minimum flap extension will provide a more favorable attitude for a power off ditching.

In a forced landing situation, do not turn off the AVIONICS MASTER switch or the airplane MASTER switch until a landing is assured. Premature deactivation of the switches will disable the airplane electrical systems.

Before performing a forced landing, especially in remote and mountainous areas, activate the ELT transmitter by positioning the cockpit-mounted switch to the ON position. For complete information on ELT operation, refer to the Supplements, Section 9.

LANDING WITHOUT ELEVATOR CONTROL

Trim for horizontal flight with an airspeed of approximately 80 KIAS by using throttle and elevator trim controls. Then **do not change the elevator trim control setting**; control the glide angle by adjusting power exclusively.

Nov 15/00 3-15

At flare out, the nose down moment resulting from power reduction is an adverse factor and the airplane may hit on the nose wheel. Consequently, at flare out, the elevator trim control should be adjusted toward the full nose-up position and the power adjusted so that the airplane will rotate to the horizontal attitude for touchdown. Close the throttle at touchdown.

FIRES

Although engine fires are extremely rare in flight, the steps of the appropriate checklist should be followed if one is encountered. After completion of this procedure, execute a forced landing. Do not attempt to restart the engine.

The initial indication of an electrical fire is usually the odor of burning insulation. The checklist for this problem should result in elimination of the fire.

EMERGENCY OPERATION IN CLOUDS (Total Vacuum System Failure)

If both the vacuum pumps fail in flight, the directional indicator and attitude indicator will be disabled, and the pilot will have to rely on the turn coordinator if he inadvertently flies into clouds. If an autopilot is installed, it too may be affected. Refer to Section 9, Supplements, for additional details concerning autopilot operation. The following instructions assume that only the electrically powered turn coordinator is operative, and that the pilot is not completely proficient in instrument flying.

EXECUTING A 180° TURN IN CLOUDS

Upon inadvertently entering the clouds, an immediate plan should be made to turn back as follows:

1. Note the compass heading.

2. Using the clock, initiate a standard rate left turn, holding the turn coordinator symbolic airplane wing opposite the lower left index mark for 60 seconds. Then roll back to level flight by leveling the miniature airplane.

- 3. Check accuracy of the turn by observing the compass heading which should be the reciprocal of the original heading.
- 4. If necessary, adjust heading primarily with skidding motions rather than rolling motions so that the compass will read more accurately.
- 5. Maintain altitude and airspeed by cautious application of elevator control. Avoid over controlling by keeping the hands off the control wheel as much as possible and steering only with rudder.

EMERGENCY DESCENT THROUGH CLOUDS

If conditions preclude reestablishment of VFR flight by a 180° turn, a descent through a cloud deck to VFR conditions may be appropriate. If possible, obtain radio clearance for an emergency descent through clouds. To guard against a spiral dive, choose an easterly or westerly heading to minimize compass card swings due to changing bank angles. In addition, keep hands off the control wheel and steer a straight course with rudder control by monitoring the turn coordinator. Occasionally check the compass heading and make minor corrections to hold an approximate course. Before descending into the clouds, set up a stabilized letdown condition as follows:

- 1. Apply full rich mixture.
- 2. Reduce power to set up a 500 to 800 ft/min rate of descent.
- 3. Adjust the elevator trim and rudder trim for a stabilized descent at 80 KIAS.
- 4. Keep hands off the control wheel.
- 5. Monitor turn coordinator and make corrections by rudder alone.
- 6. Adjust rudder trim to relieve unbalanced rudder force, if present.
- 7. Check trend of compass card movement and make cautious corrections with rudder to stop the turn.
- 8. Upon breaking out of clouds, resume normal cruising flight.

RECOVERY FROM SPIRAL DIVE IN THE CLOUDS

If a spiral is encountered in the clouds, proceed as follows:

- 1. Retard throttle to idle position.
- 2. Stop the turn by using coordinated aileron and rudder control to align the symbolic airplane in the turn coordinator with the horizon reference line.
- 3. Cautiously apply elevator back pressure to slowly reduce the airspeed to 80 KIAS.
- 4. Adjust the elevator trim control to maintain an 80 KIAS glide.
- Keep hands off the control wheel, using rudder control to hold a straight heading. Adjust rudder trim to relieve unbalanced rudder force.
- 6. Clear engine occasionally, but avoid using enough power to disturb the trimmed glide.
- 7. Upon breaking out of clouds, resume normal cruising flight.

INADVERTENT FLIGHT INTO ICING CONDITIONS

Flight into icing conditions is prohibited and can be extremely dangerous. An inadvertent encounter with these conditions can best be handled using the checklist procedures. The best procedure, of course, is to turn back or change altitude to escape icing conditions.

STATIC SOURCE BLOCKED

If erroneous readings of the static source instruments (airspeed, altimeter and vertical speed) are suspected, the static pressure alternate source valve should be pulled on, thereby supplying static pressure to these instruments from the cabin.

With the alternate static source on and the heater on and vents closed, fly an indicated airspeed 1 to 2 knots higher than normal during climb. During approach fly and indicated airspeed 1 to 2 knots lower than normal. Refer to the Alternate Static Source Airspeed Calibration chart in Section 5 for additional detail. Altimeter errors in these conditions are less than 50 feet.

3-18 Feb 3/97

With the alternate static air source on in crusing flight, refer to the Alternate Static Source Airspeed Calibration and Alternate Static Source Altimeter Correction charts in Section 5 for the somewhat larger incremental errors which exist.

SPINS

Should an inadvertent spin occur, the following recovery procedure should be used:

- 1. RETARD THROTTLE TO IDLE POSITION.
- 2. PLACE AILERONS IN NEUTRAL POSITION.
- 3. APPLY AND HOLD FULL RUDDER OPPOSITE TO THE DIRECTION OF ROTATION.
- 4. JUST AFTER THE RUDDER REACHES THE STOP, MOVE THE CONTROL WHEEL BRISKLY FORWARD FAR ENOUGH TO BREAK THE STALL.
- 5. HOLD THESE CONTROL INPUTS UNTIL ROTATION STOPS. Premature relaxation of the control inputs may extend the recovery.
- 6. AS ROTATION STOPS, NEUTRALIZE RUDDER, AND MAKE A SMOOTH RECOVERY FROM THE RESULTING DIVE.

NOTE

If disorientation precludes a visual determination of the direction of rotation, the symbolic airplane in the turn coordinator may be referred to for this information.

Feb 3/97 3-19

ROUGH ENGINE OPERATION OR LOSS OF POWER

SPARK PLUG FOULING

A slight engine roughness in flight may be caused by one or more spark plugs becoming fouled by carbon or lead deposits. This may be verified by turning the ignition switch momentarily from BOTH to either L or R position. An obvious power loss in single ignition operation is evidence of spark plug or magneto trouble. Assuming that spark plugs are the more likely cause, lean the mixture to the recommended lean setting for cruising flight. If the problem does not clear up in several minutes, determine if a richer mixture setting will produce smoother operation. If not, proceed to the nearest airport for repairs using the BOTH position of the ignition switch unless extreme roughness dictates the use of a single ignition position.

MAGNETO MALFUNCTION

A sudden engine roughness or misfiring is usually evidence of magneto problems. Switching from BOTH to either L or R ignition switch position will identify which magneto is malfunctioning. Select different power settings and enrichen the mixture to determine if continued operation on BOTH magnetos is practicable. If not, switch to the good magneto and proceed to the nearest airport for repairs.

LOW OIL PRESSURE

If the low oil pressure annunciator illuminates, check the oil pressure gauge to confirm low oil pressure condition. If gauge oil pressure and oil temperature remains normal, it is possible the oil pressure sending unit or relief valve is malfunctioning. However, land at the nearest airport to inspect the source of trouble.

If a total loss of oil pressure is accompanied by a rise in oil temperature, there is good reason to suspect an engine failure is imminent. Reduce engine power immediately and select a suitable forced landing field. Use only the minimum power required to reach the desired touchdown spot.

ELECTRICAL POWER SUPPLY SYSTEM MALFUNCTIONS

Malfunctions in the electrical power supply system can be detected by periodic monitoring of the ammeter and low voltage annunciator; however, the cause of these malfunctions is usually difficult to determine. A broken alternator drive belt or wiring is most likely the cause of alternator failures, although other factors could cause the problem. A defective alternator control unit can also cause malfunctions. Problems of this nature constitute an electrical emergency and should be dealt with immediately. Electrical power malfunctions usually fall into two categories: excessive rate of charge and insufficient rate of charge. The following paragraphs describe the recommended remedy for each situation.

EXCESSIVE RATE OF CHARGE

After engine starting and heavy electrical usage at low engine speeds (such as extended taxiing) the battery condition will be low enough to accept above normal charging during the initial part of a flight. However, after thirty minutes of cruising flight, the ammeter should be indicating less than two needle widths of charging current. If the charging rate were to remain above this value on a long flight, the battery would overheat and evaporate the electrolyte at an excessive rate.

Electronic components in the electrical system can be adversely affected by higher than normal voltage. The alternator control unit includes an overvoltage sensor which normally will automatically shut down the alternator if the charge voltage reaches approximately 31.5 volts. If the overvoltage sensor malfunctions, as evidenced by an excessive rate of charge shown on the ammeter, the alternator should be turned off, nonessential electrical equipment turned off and the flight terminated as soon as practical.

Feb 3/97 3-21

INSUFFICIENT RATE OF CHARGE

NOTE

Illumination of the low voltage (VOLTS) annunciator and ammeter discharge indications may occur during low RPM conditions with an electrical load on the system, such as during a low RPM taxi. Under these conditions, the light will go out at higher RPM.

If the overvoltage sensor should shut down the alternator and trip the ALT FLD circuit breaker, or if the alternator output is low, a discharge rate will be shown on the ammeter followed by illumination of the low voltage (VOLTS) annunciator. Since this may be a "nuisance" trip out, an attempt should be made to reactivate the alternator system. To do this, turn the AVIONICS MASTER switch off, check that the alternator field circuit breaker is in (ALT FLD), then turn both sides of the MASTER switch off and then on again. If the problem no longer exists, normal alternator charging will resume and the low voltage (VOLTS) annunciator will go off. The AVIONICS MASTER switch may then be turned back on.

If the light illuminates again, a malfunction is confirmed. In this event, the flight should be terminated and/or the current drain on the battery minimized because the battery can supply the electrical system for only a limited period of time. Battery power must be conserved for later operation of the wing flaps and, if the emergency occurs at night, for possible use of the landing lights during landing.

OTHER EMERGENCIES

WINDSHIELD DAMAGE

If a bird strike or other incident should damage the windshield in flight to the point of creating an opening, a significant loss in performance may be expected. This loss may be minimized in some cases (depending on amount of damage, altitude, etc.) by opening the side windows while the airplane is maneuvered for a landing at the nearest airport. If airplane performance or other adverse conditions preclude landing at an airport, prepare for an "off airport" landing in accordance with the Precautionary Landing With Engine Power or Ditching checklists.

SECTION 4 NORMAL PROCEDURES

TABLE OF CONTENTS	Page
Introduction	4-5
AIRSPEEDS	
Airspeeds For Normal Operation	4-5
CHECKLIST PROCEDURES	
Preflight Inspection	4-7
Cabin	4-7
Empennage	4-8
Right Wing, Trailing Edge	4-8
Right Wing	4-8
Nose	4-9
Left Wing	4-10
Left Wing, Leading Edge	4-11
Left Wing, Trailing Edge	4-11
Before Starting Engine	4-11
Starting Engine (With Battery)	4-12
Starting Engine (With External Power)	4-13
Before Takeoff	4-14
Takeoff	4-15
Normal Takeoff	4-15
Short Field Takeoff	4-15
Enroute Climb	4-15
Normal Climb	4-15
Maximum Performance Climb	4-16

SECTION 4 NORMAL PROCEDURES

TABLE OF CONTENTS (Continued)	Page
Cruise	4-16
Descent	4-16
Before Landing	4-16
Landing	4-17
Normal Landing	4-17
Short Field Landing	4-17
Balked Landing	4-17
After Landing	4-17
Securing Airplane	4-18
AMPLIFIED PROCEDURES	
Preflight Inspection	4-19
Starting Engine	4-20
Starting (General)	4-20
Taxiing	4-21
Before Takeoff	4-23
Warm Up	4-23
Magneto Check	4-23
Alternator Check	4-23
Landing Lights	4-24
Takeoff	4-24
Power Check	4-24
Wing Flap Settings	4-24
Crosswind Takeoff	4-25
Enroute Climb	4-25
Cruise	4-26
Fuel Savings Procedures for Normal Operations	
Fuel Vapor Procedures	4-29
Stalls	4-30

4-2 Nov 15/00

TABLE OF CONTENTS (Continued)

	Page
Landing	4-30
Normal Landing	4-30
Short Field Landing	4-31
Crosswind Landing	4-31
Balked Landing	4-31
Cold Weather Operation	4-32
Starting	4-32
Winterization Kit	4-33
Hot Weather Operation	4-34
Noise Characteristics And Noise Reduction	4-34

6		

INTRODUCTION

Section 4 provides checklist and amplified procedures for the conduct of normal operation. Normal procedures associated with optional systems can be found in the Supplements, Section 9.

AIRSPEEDS


Takaa#

AIRSPEEDS FOR NORMAL OPERATION

Unless otherwise noted, the following speeds are based on a maximum weight and may be used for any lesser weight. To achieve the performance specified in Section 5 for takeoff distance the speed appropriate to the particular weight must be used.

lakeoπ:		
Normal Climb Out	70-80	KIAS,
Short Field Takeoff, Flaps 20°, Speed at 50 Feet	. 58	KIAS
Enroute Climb, Flaps Up:		
Normal, Sea Level	85-95	KIAS
Best Rate of Climb, Sea Level	80	KIAS
Best Rate of Climb, 10,000 Feet	. 72	KIAS
Best Angle of Climb, Sea Level	63	KIAS
Best Angle of Climb, 10,000 Feet	66	KIAS
Landing Approach (2950 lbs):		
Normal Approach, Flaps Up	70-80	KIAS
Normal Approach, Flaps FULL	60-70	KIAS
Short Field Approach, Flaps FULL	60	KIAS
Balked Landing (2950 lbs):		
Maximum Power, Flaps 20°	55	KIAS
Maximum Recommended Turbulent Air Penetration Spee	d:	
3100 Lbs	110	KIAS
2600 Lbs	101	KIAS
2000 Lbs	88	KIAS
Maximum Demonstrated Crosswind Velocity:		
Takeoff or Landing	15 KN	OTS
<u>-</u>		

Nov 1/01 4-5



Visually check airplane for general condition during walk-around inspection. Airplane should be parked in a normal ground attitude (refer to Figure 1-1) to ensure that fuel drain valves allow for accurate sampling. Use of the refueling steps and assist handles will simplify access to the upper wing surfaces for visual checks and refueling operations. In cold weather, remove even small accumulations of frost, ice or snow from wing, tail and control surfaces. Also, make sure that control surfaces contain no internal accumulations of ice or debris. If a night flight is planned, check operation of all lights, and make sure a flashlight is available.

Figure 4-1. Preflight Inspection

CHECKLIST PROCEDURES

PREFLIGHT INSPECTION

1 CABIN

- 1. Pitot Tube Cover -- REMOVE. Check for pitot stoppage.
- 2. Pilot's Operating Handbook -- AVAILABLE IN THE AIRPLANE.
- 3. Airplane Weight and Balance -- CHECKED.
- 4. Parking Brake -- SET.
- 5. Control Wheel Lock -- REMOVE.
- 6. Ignition Switch -- OFF.
- 7. Avionics Master Switch -- OFF.

A WARNING

WHEN TURNING ON THE MASTER SWITCH, USING AN EXTERNAL POWER SOURCE, OR PULLING THE PROPELLER THROUGH BY HAND, TREAT THE PROPELLER AS IF THE IGNITION SWITCH WERE ON. DO NOT STAND, NOR ALLOW ANYONE ELSE TO STAND, WITHIN THE ARC OF THE PROPELLER, SINCE A LOOSE OR BROKEN WIRE OR A COMPONENT MALFUNCTION COULD CAUSE THE PROPELLER TO ROTATE.

- 8. Master Switch -- ON.
- Fuel Quantity Indicators -- CHECK QUANTITY AND ENSURE LOW FUEL ANNUNCIATORS (L LOW FUEL R) are EXTINGUISHED.
- 10. Avionics Master Switch -- ON.
- 11. Avionics Cooling Fan -- CHECK AUDIBLY FOR OPERATION.
- 12. Avionics Master Switch -- OFF.
- 13. Static Pressure Alternate Source Valve -- OFF.

- 14. Annunciator Panel Switch -- PLACE AND HOLD IN TST POSITION and ensure all annunciators illuminate.
- 15. Annunciator Panel Test Switch -- RELEASE. Check that appropriate annunciators remain on.

NOTE

When Master Switch is turned ON, some annunciators will flash for approximately 10 seconds before illuminating steadily. When panel TST switch is toggled up and held in position, all remaining lights will flash until the switch is released.

- 16. Fuel Selector Valve -- BOTH.
- 17. Flaps -- EXTEND.
- 18. Pitot Heat -- ON (Carefully check that pitot tube is warm to the touch within 30 seconds).
- 19. Pitot Heat -- OFF.
- 20. Master Switch -- OFF.
- 21. Baggage Door -- CHECK, lock with key.

(2) EMPENNAGE

- Rudder Gust Lock (if installed) -- REMOVE.
 - 2. Tail Tie-Down -- DISCONNECT.
 - Control Surfaces -- CHECK freedom of movement and security.
 - 4. Trim Tab -- CHECK security.
 - 5. Antennas -- CHECK for security of attachment and general condition.

3 RIGHT WING Trailing Edge

- 1. Aileron -- CHECK freedom of movement and security.
- 2. Flap -- CHECK for security and condition.

(4) RIGHT WING

- 1. Wing Tie-Down -- DISCONNECT.
- 2. Fuel Tank Vent Opening -- CHECK for stoppage.
- 3. Main Wheel Tire -- CHECK for proper inflation and general condition (weather checks, tread depth and wear, etc...).

4. Fuel Tank Sump Quick Drain Valves -- DRAIN at least a cupful of fuel (using sampler cup) from each sump location to check for water, sediment, and proper fuel grade before each flight and after each refueling. If water is observed, take further samples until clear and then gently rock wings and lower tail to the ground to move any additional contaminants to the sampling points. Take repeated samples from all fuel drain points until all contamination has been removed. If contaminants are still present, refer to WARNING below and do not fly airplane.

WARNING

IF, AFTER REPEATED SAMPLING, EVIDENCE OF CONTAMINATION STILL EXISTS, THE AIRPLANE SHOULD NOT BE FLOWN. TANKS SHOULD BE DRAINED AND SYSTEM PURGED BY QUALIFIED MAINTENANCE PERSONNEL. ALL EVIDENCE OF CONTAMINATION MUST BE REMOVED BEFORE FURTHER FLIGHT.

- 5. Fuel Quantity -- CHECK VISUALLY for desired level.
- 6. Fuel Filler Cap -- SECURE and VENT UNOBSTRUCTED.

5 NOSE

- 1. Static Source Opening (right side of fuselage) -- CHECK for blockage.
- 2. Fuel Strainer Quick Drain Valve (Located on bottom of fuselage) -- DRAIN at least a cupful of fuel (using sampler cup) from valve to check for water, sediment, and proper fuel grade before each flight and after each refueling. If water is observed, take further samples until clear and then gently rock wings and lower tail to the ground to move any additional contaminants to the sampling points. Take repeated samples from all fuel drain points, including the fuel selector, until all contamination has been removed. If contaminants are still present, refer to WARNING above and do not fly airplane.

- Engine Oil Dipstick/Filler Cap -- CHECK oil level, then check dipstick/filler cap SECURE. Do not operate with less than four quarts. Fill to nine quarts for extended flight.
- 4. Engine Cooling Air Inlets -- CLEAR of obstructions.

5. Propeller and Spinner -- CHECK for nicks and security.

- 6. Air Filter -- CHECK for restrictions by dust or other foreign matter.
- 7. Nose Wheel Strut and Tire -- CHECK for proper inflation of strut and general condition (weather checks, tread depth and wear, etc...) of tire.
- 8. Static Source Opening (left side of fuselage) -- CHECK for blockage.

6 LEFT WING

- 1. Fuel Quantity -- CHECK VISUALLY for desired level.
- 2. Fuel Filler Cap -- SECURE and VENT UNOBSTRUCTED.
- 3. Fuel Tank Sump Quick Drain Valves -- DRAIN at least a cupful of fuel (using sampler cup) from each sump location to check for water, sediment, and proper fuel grade before each flight and after each refueling. If water is observed, take further samples until clear and then gently rock wings and lower tail to the ground to move any additional contaminants to the sampling points. Take repeated samples from all fuel drain points until all contamination has been removed. If contaminants are still present, refer to WARNING on page 4-9 and do not fly airplane.
- 4. Main Wheel Tire -- CHECK for proper inflation and general condition (weather checks, tread depth and wear, etc...).

7 LEFT WING Leading Edge

1. Pitot Tube Cover -- REMOVE and check opening for stoppage.

2. Fuel Tank Vent Opening -- CHECK for stoppage.

3. Stall Warning Vane -- CHECK for freedom of movement. To check the system, place the vane upward; a sound from the warning horn with the Master Switch on will confirm system operation.

4. Wing Tie-Down -- DISCONNECT.

Landing/Taxi Light(s) -- CHECK for condition and cleanliness of cover.

8 LEFT WING Trailing Edge

- 1. Aileron -- CHECK for freedom of movement and security.
- 2. Flap -- CHECK for security and condition.

BEFORE STARTING ENGINE

- 1. Preflight Inspection -- COMPLETE.
- 2. Passenger Briefing -- COMPLETE.
- 3. Seats, Seat Belts, Shoulder Harnesses -- ADJUST and LOCK. Ensure inertia reel locking.
- 4. Brakes -- TEST and SET.
- 5. Circuit Breakers -- CHECK IN.
- 6. Electrical Equipment -- OFF.

A WARNING

THE AVIONICS MASTER SWITCH MUST BE OFF DURING ENGINE START TO PREVENT POSSIBLE DAMAGE TO AVIONICS.

- 7. Avionics Master Switch -- OFF.
- 8. Autopilot (if installed) -- OFF.
- 9. Cowl Flaps -- OPEN.
- 10. Fuel Selector Valve -- BOTH.
- 11. Avionics Circuit Breakers -- CHECK IN.

STARTING ENGINE (With Battery)

- 1. Throttle -- OPEN 1/4 INCH.
- 2. Propeller -- HIGH RPM.
- 3. Mixture -- IDLE CUT OFF.
- 4. Propeller Area -- CLEAR.
- 5. Master Switch -- ON.
- 6. Auxiliary Fuel Pump Switch -- ON.
- 7. Mixture -- ADVANCE until fuel flow just starts to rise, then return to IDLE CUT OFF position.
- 8. Auxiliary Fuel Pump -- OFF.

NOTE

- If engine is warm, omit priming procedure of step 6, 7 and 8 above.
 - 9. Ignition Switch -- START (release when engine starts).
 - 10. Mixture -- ADVANCE smoothly to RICH when engine fires.

NOTE

- If engine floods, place mixture in idle cut off, open throttle 1/2 to full, and crank engine. When engine fires, advance mixture to full rich and retard throttle promptly.
 - 11. Oil Pressure -- CHECK.
 - 12. Flashing Beacon and Navigation Lights -- ON as required.
 - 13. Avionics Master Switch -- ON.
 - 14. Radios -- ON.
 - 15. Flaps -- RETRACT.

STARTING ENGINE (With External Power)

- 1. Throttle -- OPEN 1/4 INCH.
- 2. Propeller -- HIGH RPM.
- 3. Mixture -- IDLE CUT OFF.
- 4. Propeller Area -- CLEAR.
- 5. External Power -- CONNECT to airplane receptacle.
- 6. Master Switch -- ON.
- 7. Auxiliary Fuel Pump Switch -- ON.
- Mixture -- ADVANCE until fuel flow just starts to rise, then return to IDLE CUT OFF position.
- 9. Auxiliary Fuel Pump -- OFF.

NOTE

If engine is warm, omit priming procedure of steps 7, 8 and 9 above.

- 10. Ignition Switch -- START (release when engine starts).
- 11. Mixture -- ADVANCE smoothly to RICH when engine fires.

NOTE

If engine floods, place mixture in idle cut off, open throttle 1/2 to full, and crank engine. When engine fires, advance mixture to full rich and retard throttle promptly.

- 12. Oil Pressure -- CHECK.
- 13. External Power -- DISCONNECT from airplane receptacle.
- 14. Flashing Beacon and Navigation Lights -- ON as required.
- 15. Avionics Master Switch -- ON.
- 16. Radios -- ON.
- 17. Flaps -- RETRACT.

BEFORE TAKEOFF

- 1. Parking Brake -- SET.
- Passenger Seat Backs -- MOST UPRIGHT POSITION.
- 3. Seats and Seat Belts -- CHECK SECURE.
- 4. Cabin Doors -- CLOSED and LOCKED.
- 5. Flight Controls -- FREE and CORRECT.
- Flight Instruments -- CHECK and SET.
- 7. Fuel Quantity -- CHECK.
- 8. Mixture -- RICH.
- 9. Fuel Selector Valve -- RECHECK BOTH.
- 10. Throttle -- 1800 RPM.
 - a. Magnetos -- CHECK (RPM drop should not exceed 150 RPM on either magneto or 50 RPM differential between magnetos).
 - b. Propeller -- CYCLE from high to low RPM; return to high RPM (full in).
 - c. Vacuum Gauge -- CHECK.
 - d. Engine Instruments and Ammeter -- CHECK.
- 11. Annunciator Panel -- Ensure no annunciators are illuminated.
- 12. Throttle -- CHECK IDLE.
- 13. Throttle -- 1000 RPM or less.
- 14. Throttle Friction Lock -- ADJUST.
- 15. Strobe Lights -- AS DESIRED.
- 16. Radios and Avionics -- SET.
- 17. NAV/GPS/HSI Switch (if installed) -- SET.
- 18. Autopilot (if installed) -- OFF.
- 19. Elevator Trim and Rudder Trim -- SET for takeoff.
- 20. Wing Flaps -- SET for takeoff (0° TO 20°).
- 21. Cowl Flaps -- OPEN.
- Brakes -- RELEASE.

TAKEOFF

NORMAL TAKEOFF

- 1. Wing Flaps -- 0° 20°.
- 2. Power -- FULL THROTTLE and 2400 RPM.
- 3. Mixture -- RICH (mixture may be leaned to Maximum Power Fuel Flow placard value).
- 4. Elevator Control -- LIFT NOSE WHEEL (at 50-60 KIAS).
- 5. Climb Speed -- 70 KIAS (flaps 20°). 80 KIAS (flaps 0°).
- 6. Wing Flaps -- RETRACT.

SHORT FIELD TAKEOFF

- 1. Wing Flaps -- 20°.
- 2. Brakes -- APPLY.
- 3. Power -- FULL THROTTLE and 2400 RPM.
- 4. Mixture -- Lean to obtain Maximum Power Fuel Flow placard value.
- 5. Brakes -- RELEASE.
- Elevator Control -- MAINTAIN SLIGHTLY TAIL LOW ATTITUDE.
- 7. Climb Speed -- 58 KIAS (until all obstacles are cleared).
- 8. Wing Flaps -- RETRACT slowly after reaching 70 KIAS.

ENROUTE CLIMB

NORMAL CLIMB

- 1. Airspeed -- 85-95 KIAS.
- 2. Power -- 23 in. Hg or FULL THROTTLE (whichever is less) and 2400 RPM.
- 3. Mixture -- 15 GPH or FULL RICH (whichever is less).
- 4. Fuel Selector Valve -- BOTH.
- 5. Cowl Flaps -- OPEN as required.

MAXIMUM PERFORMANCE CLIMB

- 1. Airspeed -- 80 KIAS at sea level to 72 KIAS at 10,000 feet. (Refer to Section 5).
- 2. Power -- FULL THROTTLE and 2400 RPM.
- 3. Mixture -- LEAN in accordance with Maximum Power Fuel Flow placard value.
- 4. Cowl Flaps -- OPEN.
- 5. Fuel Selector Valve -- BOTH.

CRUISE

- 1. Power -- 15 23 in. Hg, 2000 2400 RPM (no more than 80%).
- 2. Elevator and Rudder Trim -- ADJUST.
- 3. Mixture -- LEAN.
- 4. Cowl Flaps -- CLOSED.

DESCENT

- 1. Power -- AS DESIRED.
- 2. Mixture -- ENRICHEN as required.
- 3. Cowl Flaps -- CLOSED.
- 4. Fuel Selector Valve -- BOTH.
- 5. NAV/GPS/HSI Switch (if installed) -- SET.
- 6. Wing Flaps -- AS DESIRED (0°-10° below 140 KIAS; 10°-20° below 120 KIAS; 20°- FULL below 100 KIAS).

BEFORE LANDING

- Pilot and Passenger Seat Backs -- MOST UPRIGHT POSITION.
- 2. Seats and Seat Belts -- SECURED and LOCKED.
- 3. Fuel Selector Valve -- BOTH.
- 4. Mixture -- RICH.
- 5. Propeller -- HIGH RPM.
- 6. Landing/Taxi Lights -- ON.
- 7. Autopilot (if installed) -- OFF.

LANDING

NORMAL LANDING

- 1. Airspeed -- 70-80 KIAS (flaps UP).
- 2. Wing Flaps -- AS DESIRED (0° 10° below 140 KIAS; 10° 20° below 120 KIAS; 20° FULL below 100 KIAS).
- 3. Airspeed -- 60-70 KIAS (flaps FULL).
- 4. Power -- REDUCE to idle as obstacle is cleared.
- 5. Trim -- ADJUST as desired.
- 6. Touchdown -- MAIN WHEELS FIRST.
- 7. Landing Roll -- LOWER NOSE WHEEL GENTLY.
- 8. Braking -- MINIMUM REQUIRED.

SHORT FIELD LANDING

- 1. Airspeed -- 70-80 KIAS (flaps UP).
- 2. Wing Flaps -- FULL (below 100 KIAS).
- 3. Airspeed -- 60 KIAS (until flare).
- 4. Trim -- ADJUST as desired.
- 5. Touchdown -- MAIN WHEELS FIRST.
- 6. Brakes -- APPLY HEAVILY.
- 7. Wing Flaps -- RETRACT for maximum brake effectiveness.

BALKED LANDING

- 1. Power -- FULL THROTTLE and 2400 RPM.
- 2. Wing Flaps -- RETRACT TO 20°.
- 3. Climb Speed -- 55 KIAS.
- Wing Flaps -- RETRACT slowly after reaching a safe altitude and 70 KIAS.
- 5. Cowl Flaps -- OPEN.

AFTER LANDING

- 1. Wing Flaps -- UP.
- 2. Cowl Flaps -- OPEN.

SECURING AIRPLANE

- 1. Parking Brake -- SET.
- 2. Throttle -- IDLE.
- 3. Electrical Equipment, Avionics Master Switch, Autopilot (if installed) -- OFF.
 - 4. Mixture -- IDLE CUT-OFF (pulled full out).
 - 5. Ignition Switch -- OFF.
 - 6. Master Switch -- OFF.
 - 7. Control Lock -- INSTALL.
 - 8. Fuel Selector Valve -- LEFT or RIGHT to prevent cross feeding.

AMPLIFIED PROCEDURES

PREFLIGHT INSPECTION

The Preflight Inspection, described in Figure 4-1 and adjacent checklist, is required prior to each flight. If the airplane has been in extended storage, has had recent major maintenance, or has been operated from marginal airports, a more extensive exterior inspection is recommended.

After major maintenance has been performed, the flight and trim tab controls should be double checked for free and correct movement and security. The security of all inspection plates on the airplane should be checked following periodic inspections. If the airplane has been waxed or polished, check the external static pressure source hole for stoppage.

If the airplane has been exposed to much ground handling in a crowded hangar, it should be checked for dents and scratches on wings, fuselage, and tail surfaces, damage to navigation and anticollision lights, damage to nose wheel as a result of exceeding tow limits, and avionics antennas.

Outside storage for long periods may result in dust and dirt accumulation on the induction air filter, obstructions in airspeed system lines, water contaminants in fuel tanks and insect/bird/rodent nests in any opening. If any water is detected in the fuel system, the fuel tank sump quick drain valves, fuel reservoir quick drain valve, and fuel strainer quick drain valve should all be thoroughly drained again. Then, the wings should be gently rocked and the tail lowered to the ground to move any further contaminants to the sampling points. Repeated samples should then be taken at **all** quick drain points until **all** contamination has been removed. If, after repeated sampling, evidence of contamination still exists, the fuel tanks should be completely drained and the fuel system cleaned.

Additionally, if the airplane has been stored outside in windy or gusty areas, or tied down adjacent to taxiing airplanes, special attention should be paid to control surface stops, hinges, and brackets to detect the presence of potential wind damage.

Feb 3/97 4-19

If the airplane has been operated from muddy fields or in snow or slush, check the main and nose gear wheel fairings for obstructions and cleanliness. Operation from a gravel or cinder field will require extra attention to propeller tips and abrasion on leading edges of the horizontal tail. Stone damage to the propeller can seriously reduce the fatigue life of the blades.

Airplanes that are operated from rough fields, especially at high altitudes, are subjected to abnormal landing gear abuse. Frequently check all components of the landing gear, shock strut, tires, and brakes. If the shock strut is insufficiently extended, undue landing and taxi loads will be subjected on the airplane structure.

To prevent loss of fuel in flight, make sure the fuel tank filler caps are tightly sealed after any fuel system check or servicing. Fuel system vents should also be inspected for obstructions, ice or water, especially after exposure to cold, wet weather.

STARTING ENGINE

STARTING (GENERAL)

In cooler weather, the engine compartment temperature drops off rapidly following engine shutdown and the injector nozzle lines remain nearly full of fuel.

However, in warmer weather, engine compartment temperatures may increase rapidly following engine shutdown, and fuel in the lines will vaporize and escape into the intake manifold. Hot weather starting procedures depend considerably on how soon the next engine start is attempted. Within the first 20 to 30 minutes after shutdown, the fuel manifold is adequately primed and the empty injector nozzle lines will fill before the engine dies. However, after approximately 30 minutes, the vaporized fuel in the manifold will have nearly dissipated and some "priming" could be required to refill the nozzle lines and keep the engine running after the initial start. Starting a hot engine is facilitated by advancing the mixture control promptly to 1/3 open when the engine fires, and then smoothly to full rich as power develops.

Should the engine tend to die after starting, turn on the auxiliary fuel pump temporarily and adjust the throttle and/or mixture as necessary to keep the engine running. In the event of over priming or flooding, turn off the auxiliary fuel pump, open the throttle from 1/2 to full open, and continue cranking with the mixture full lean. When the engine fires, smoothly advance the mixture control to full rich and retard the throttle to desired idle speed.

If the engine is under primed (most likely in cold weather with a cold engine) it will not fire at all, and additional priming will be necessary.

After starting, if the oil pressure indicator does not begin to show pressure within 30 seconds in the summer time and approximately one minute in very cold weather, stop the engine and investigate. Lack of oil pressure can cause serious engine damage.

NOTE


Additional details concerning cold weather starting and operation may be found under COLD WEATHER OPERATION paragraphs in this section.

Recommended starter duty cycle. Crank the starter for 10 seconds followed by a 20 second cool down period. This cycle can be repeated two additional times, followed by a ten minute cool down period before resuming cranking. Repeat cranking procedures above one more time. If the engine still fails to start, an investigation to determine the cause should be initiated.

TAXIING

When taxiing, it is important that speed and use of brakes be held to a minimum and that all controls be utilized (Refer to Figure 4-2, Taxiing Diagram) to maintain directional control and balance.

Taxiing over loose gravel or cinders should be done at low engine speed to avoid abrasion and stone damage to the propeller tips.



NOTE

Strong quartering tail winds require caution. Avoid sudden bursts of the throttle and sharp braking when the airplane is in this attitude. Use the steerable nose wheel and rudder to maintain direction.

0785T1012

Figure 4-2. Taxiing Diagram

BEFORE TAKEOFF

WARM UP

If the engine idles (approximately 650 RPM) and accelerates smoothly, the airplane is ready for takeoff. Since the engine is closely cowled for efficient in-flight cooling, precautions should be taken to avoid overheating during prolonged engine operation on the ground. Also, long periods of idling may cause fouled spark plugs.

MAGNETO CHECK

The magneto check should be made at 1800 RPM as follows. Move ignition switch first to R position and note RPM. Next move switch back to BOTH to clear the other set of plugs. Then move switch to the L position, note RPM and return the switch to the BOTH position. RPM drop should not exceed 150 RPM on either magneto or show greater than 50 RPM differential between magnetos. If there is a doubt concerning operation of the ignition system, RPM checks at higher engine speeds will usually confirm whether a deficiency exists.

An absence of RPM drop may be an indication of faulty grounding of one side of the ignition system or should be cause for suspicion that the magneto timing is set in advance of the setting specified.

ALTERNATOR CHECK

Prior to flights where verification of proper alternator and alternator control unit operation is essential (such as night or instrument flights), a positive verification can be made by loading the electrical system momentarily (3 to 5 seconds) with the landing light or by operating the wing flaps during the engine runup (1800 RPM). The ammeter will remain within a needle width of its initial reading if the alternator and alternator control unit are operating properly.

Nov 1/01 4-23

LANDING LIGHTS

If landing lights are to be used to enhance the visibility of the airplane in the traffic pattern or enroute, it is recommended that only the taxi light be used. This will extend the service life of the landing light appreciably.

TAKEOFF

POWER CHECK

It is important to check full throttle engine operation early in the takeoff roll. Any sign of rough engine operation or sluggish engine acceleration is good cause for discontinuing the takeoff. If this occurs, you are justified in making a thorough full throttle static runup before another takeoff is attempted. The engine should run smoothly and turn approximately 2350 - 2400 RPM.

Full throttle run ups over loose gravel are especially harmful to propeller tips. When takeoffs must be made over a gravel surface, it is very important that the throttle be advanced slowly. This allows the airplane to start rolling before high RPM is developed, and the gravel will be blown back of the propeller rather than pulled into it.

Prior to takeoff from fields which require maximum performance, the mixture should be leaned to the fuel flow values provided on the Maximum Power Fuel Flow placard in a full throttle, static runup.

After full throttle is applied, adjust the throttle friction lock clockwise to prevent the throttle from creeping back from a maximum power position. Similar friction lock adjustments should be made as required in other flight conditions to maintain a fixed throttle setting.

WING FLAP SETTINGS

Normal takeoffs are accomplished with wing flaps 0° to 20°. Using 20° wing flaps reduces the ground roll and total distance over an obstacle by approximately 20 percent. Flap deflections greater than 20° are not approved for takeoff.

On a short field, 20° wing flaps and an obstacle clearance speed of 58 KIAS should be used. If 20° wing flaps are used for takeoff, they should be left down until all obstacles are cleared and a safe flap retraction speed of 70 KIAS is reached.

Soft or rough field takeoffs are performed with 20° flaps by lifting the airplane off the ground as soon as practical in a slightly tail low attitude. If no obstacles are ahead, the airplane should be leveled off immediately to accelerate to a higher climb speed.

CROSSWIND TAKEOFF

Takeoffs into strong crosswind conditions normally are performed with the minimum flap setting necessary for the field length, to minimize the drift angle immediately after takeoff. With the ailerons partially deflected into the wind, the airplane is accelerated to a speed slightly higher than normal, then pulled off briskly to prevent possible settling back to the runway while drifting. When clear of the ground, make a coordinated turn into the wind to correct for drift.

ENROUTE CLIMB

Normal climbs are performed at 85-95 KIAS with flaps up, 23 In. Hg. or full throttle (whichever is less) and 2400 RPM for the best combination of performance, visibility and engine cooling. The mixture should be set to 15 GPH or full rich (whichever is less) until reaching the altitude at which full throttle is reached, after which no further adjustment of the mixture control is needed.

If it is necessary to climb rapidly to clear mountains or reach favorable winds at higher altitudes, the best rate of climb speed should be used with maximum power. This speed (shown in Section 5) is 80 KIAS at sea level, decreasing to 72 KIAS at 10,000 feet.

If an obstruction ahead requires a steep climb angle, a best angle of climb air speed should be used with flaps up and maximum power. This speed is 63 KIAS at sea level, increasing to 66 KIAS at 10,000 feet. This type of climb should be of minimum duration and engine temperatures should be carefully monitored due to the low climb speed.

For maximum power, the mixture should be set in accordance with the Maximum Power Fuel Flow placard.

CRUISE

Normal cruising is performed between 55% and 80% rated power with the mixture set to peak EGT. Manifold pressures and engine speed should normally be kept within the green arc ranges on the manifold pressure gauge and tachometer. However, at lower altitudes and at high allowable cruise powers, it is permissible to use any manifold pressure note in the cruise performance charts in Section 5.

NOTE

Cruising should be done at 75% power as much as practicable until a total of 50 hours has accumulated or oil consumption has stabilized. Operation at this higher power will ensure proper seating of the rings and is applicable to new engines, and engines in service following cylinder replacement or top overhaul of one or more cylinders.

The Cruise Performance charts in Section 5 provide the pilot with detailed information concerning the cruise performance of the Model 182S in still air. Power and altitude, as well as winds aloft, have a strong influence on the time and fuel needed to complete any flight. The Cruise Performance table of Figure 4-3 illustrates some of these effects and may be used as a guide along with winds aloft information in selecting an altitude and power setting for a given trip. The selection of cruise altitude on the basis of most favorable wind conditions and the use of the lower power settings consistent with trip needs are significant factors which should be considered on every trip to reduce fuel consumption.

For reduced noise levels, it is desirable to select the lowest RPM in the green arc range for a given percent power that will provide smooth engine operation. The cowl flaps should be opened, if necessary, to maintain the cylinder head temperature at approximately two-thirds of the normal operating range (green arc).

	80% POWER		75% POWER		65% POWER		75% POWER 65% POWER 55% POW		65% POWER 55% POWER		OWER
ALTITUDE	KTAS	NMPG	KTAS	NMPG	KTAS	NMPG	KTAS	NMPG			
4000 feet	137	10.2	133	10.6	125	11.3	116	12.0			
6000 feet	140	10.4	136	10.8	127	11.5	118	12.2			
8000 feet		•••			130	11.7	120	12.4			
10000 feet	n		F-55-50	515.51	132	11.9	121	12.6			

Figure 4-3. Cruise Performance Table

Cruise performance data in this handbook is based on a recommended lean mixture setting which may be established using the EGT indicator at powers of 80% MCP and lower as follows:

- 1. Lean the mixture slowly until the EGT peaks and begins to drop.
- 2. Enrichen as needed to ensure operation at peak.
- 3. If engine operation is rough at peak EGT, further enrichen for smooth operation.

Any change in altitude or power setting will require a change in the recommended lean mixture setting and a recheck of the EGT setting.

Operation at peak EGT provides the best fuel economy. Operating at best power mixture strength (125°F rich of peak EGT) results in approximately 8% less range and a 3 knot increase in speed.

The EGT table of Figure 4-4 summarizes the defined mixture strengths available for the 182S.

MIXTURE DESCRIPTION	EXHAUST GAS TEMPERATURE
RECOMMENDED LEAN (Pilot's Operating Handbook)	Peak EGT
BEST POWER	125°F Rich

Figure 4-4. EGT Table

FUEL SAVINGS PROCEDURES FOR NORMAL OPERATIONS

For best fuel economy during normal operations, the following procedures are recommended.

- After engine start and for all ground operations, set the throttle
 to 1200 RPM and lean the mixture for maximum RPM. Leave
 the mixture at this setting until beginning the BEFORE
 TAKEOFF checklist. After the BEFORE TAKEOFF checklist is
 complete re-lean the mixture as described above until ready
 for TAKEOFF.
- 2. Adjust the mixture for placarded fuel flows during maximum continuous power climbs.
- 3. Adjust the mixture at any altitude for RECOMMENDED LEAN fuel flow with power settings at 80% or less.

Using the above recommended procedures can provide fuel savings in excess of 5% when compared to typical operations at full rich mixture. In addition, the above procedures will minimize spark plug fouling since the reduction in fuel consumption results in a proportional reduction in tetraethyl lead passing through the engine.

FUEL VAPOR PROCEDURES

The engine fuel system can become susceptible to fuel vapor formation on the ground during warm weather. This will generally occur when the outside ambient air temperature is above 80°F. The situation is further aggravated by the fact that the engine fuel flows are lower at idle and taxi engine speeds. When vapor occurs as evidenced by idle engine speed and fuel flow fluctuations, the following procedures are recommended.

- 1. With the mixture full rich, set the throttle at 1800 RPM to 2000 RPM. Maintain this power setting for 1 to 2 minutes or until smooth engine operation returns.
- 2. Retard the throttle to idle to verify normal engine operation.
- Advance the throttle to 1200 RPM and lean the mixture as described under FUEL SAVINGS PROCEDURES FOR NORMAL OPERATIONS.
- Just prior to TAKEOFF, apply full throttle, for approximately 10 seconds to verify smooth engine operation for takeoff.

NOTE

When the engine is operated above 1800 RPM, the resulting increased fuel flow also makes for lower fuel temperatures throughout the engine fuel system. This increased flow purges the fuel vapor and the cooler fuel minimizes vapor formation.

STALLS

The stall characteristics are conventional and aural warning is provided by a stall warning horn which sounds between 5 and 10 knots above the stall in all configurations.

Power off stall speeds at maximum weight for both forward and aft C.G. positions are presented in Section 5.

LANDING

NORMAL LANDING

Normal landing approaches can be made with power on or power off with any flap setting desired. Surface winds and air turbulence are usually the primary factors in determining the most comfortable approach speeds.

Actual touchdown should be made with power off and on the main wheels first to reduce the landing speed and subsequent need for braking in the landing roll. The nose wheel is lowered to the runway gently after the speed has diminished to avoid unnecessary nose gear loads. This procedure is especially important in rough or soft field landings.

SHORT FIELD LANDING

For a short field landing in smooth air conditions, make power off approach at 60 KIAS with full flaps. (Slightly higher approach speeds should be used under turbulent air conditions.) If power is added to adjust glide path, it should be again reduced to idle after all approach obstacles are cleared, the approach speed maintained by lowering the nose of the airplane. Touchdown should be made with power off and on the main wheels first. Immediately after touchdown, lower the nose wheel and apply heavy braking as required. For maximum brake effectiveness, retract the flaps, hold the control wheel full back, and apply maximum brake pressure without sliding the tires.

CROSSWIND LANDING

When landing in a strong crosswind, use the minimum flap setting required for the field length. Although the crab or combination method of drift correction may be used, the wing low method gives the best control. After touchdown, hold a straight course with the steerable nose wheel and occasional braking if necessary.

The maximum allowable crosswind velocity is dependent upon pilot capability as well as airplane limitations. Operation in direct crosswinds of 15 knots has been demonstrated.

BALKED LANDING

In a balked landing (go-around) climb, reduce the flap setting to 20° immediately after full power is applied. After all obstacles are cleared and a safe altitude and airspeed are obtained, the wing flaps should be retracted.

COLD WEATHER OPERATION

Special consideration should be given to the operation of the airplane fuel system during the winter season or prior to any flight in cold temperatures. Proper preflight draining of the fuel system is especially important and will eliminate any free water accumulation. The use of additives such as isopropyl alcohol or diethylene glycol monomethyl ether may also be desirable. Refer to Section 8 for information on the proper use of additives.

Cold weather often causes conditions which require special care during airplane operations. Even small accumulations of frost, ice, or snow must be removed, particularly from wing, tail and all control surfaces to assure satisfactory flight performance and handling. Also, control surfaces must be free of any internal accumulations of ice or snow.

If snow or slush covers the takeoff surface, allowance must be made for takeoff distances which will be increasingly extended as the snow or slush depth increases. The depth and consistency of this cover can, in fact, prevent takeoff in many instances.

STARTING

WARNING

WHEN PULLING THE PROPELLER THROUGH BY HAND, TREAT IT AS IF THE IGNITION SWITCH IS TURNED ON. A LOOSE OR BROKEN GROUND WIRE ON EITHER MAGNETO COULD CAUSE THE ENGINE TO FIRE.

Prior to starting on cold mornings, it is advisable to pull the propeller through several times by hand to "break loose" or "limber" the oil, thus conserving battery energy.

When air temperatures are below 20°F (-6°C), the use of an external preheater and an external power source are recommended whenever possible to obtain positive starting and to reduce wear and abuse to the engine and electrical system. Preheat will thaw the oil trapped in the oil cooler, which probably will be congealed prior to starting in extremely cold temperatures.

When using an external power source, the master switch must be in the OFF position before connecting the external power source to the airplane receptacle. See Section 7, Ground Service Plug Receptacle, for external power source operations.

Cold weather starting procedures are the same as the normal starting procedures. Use caution to prevent inadvertent forward movement of the airplane during starting when parked on snow or ice.

NOTE

If the engine does not start during the first few attempts, or if engine firing diminishes in strength, it is probable that the spark plugs have been frosted over. Preheat must be used before another start is attempted.

During cold weather operations, no indication will be apparent on the oil temperature gage prior to takeoff if outside air temperatures are very cold. After a suitable warm up period (2 to 5 minutes at 1000 RPM), accelerate the engine several times to higher engine RPM. If the engine accelerates smoothly and the oil pressure remains normal and steady, the airplane is ready for takeoff.

WINTERIZATION KIT

A winterization kit is provided and may be utilized when cold weather operations are conducted. Refer to WINTERIZATION KIT in the Supplements, Section 9 for installation and operational details.

HOT WEATHER OPERATION

Refer to the general warm temperature starting information under Starting Engine in this section. Avoid prolonged engine operation on the ground.

NOISE CHARACTERISTICS AND NOISE REDUCTION

The certificated noise level for the Model 182S at 3100 pounds maximum weight is 79.7 dB(A) with a 2-bladed propeller and 77.7 dB(A) with a three-bladed propeller. No determination has been made by the Federal Aviation Administration that the noise levels of this airplane are or should be acceptable or unacceptable for operation at, into, or out of, any airport.

The following procedures are suggested to minimize the effect of airplane noise on the public:

- 1. Pilots operating airplanes under VFR over outdoor assemblies of persons, recreational and park areas, and other noise sensitive areas should make every effort to fly not less than 2000 feet above the surface, weather permitting, even though flight at a lower level may be consistent with the provisions of government regulations.
- 2. During departure from or approach to an airport, climb after takeoff and descent for landing should be made so as to avoid prolonged flight at low altitude near noise sensitive areas.

NOTE

The above recommended procedures do not apply where they would conflict with Air Traffic Control clearances or instructions, or where, in the pilot's judgment, an altitude of less than 2000 feet is necessary to adequately exercise the duty to see and avoid other airplanes.

SECTION 5 PERFORMANCE

TABLE OF CONTENTS	Page
Introduction	5-3
Use of Performance Charts	5-3
Sample Problem	5-3
Takeoff	5-4
Cruise	5-5
Fuel Required	5-6
Landing	5-8
Demonstrated Operating Temperature	5-8
Figure 5-1, Airspeed Calibration - Normal Static Source	
Airspeed Calibration - Alternate Static Source	
Figure 5-2, Altimeter Correction	5-11
Figure 5-3, Temperature Conversion Chart	5-12
Figure 5-4, Stall Speeds	5-13
Figure 5-5, Crosswind Components	5-14
Figure 5-6, Short Field Takeoff Distance - 3100 Lbs	5-15
Short Field Takeoff Distance - 2700 Lbs	5-16
Short Field Takeoff Distance - 2300 Lbs	5-17
Figure 5-7, Maximum Rate Of Climb	5-18
Figure 5-8, Time, Fuel, And Distance To Climb	5-19
Figure 5-9, Cruise Performance	5-21
Figure 5-10, Range Profile	5-31
Figure 5-11, Endurance Profile	5-33
Figure 5-12, Short Field Landing Distance	5-35

Dec 1/97

+

INTRODUCTION

Performance data charts on the following pages are presented so that you may know what to expect from the airplane under various conditions, and also, to facilitate the planning of flights in detail and with reasonable accuracy. The data in the charts has been computed from actual flight tests with the airplane and engine in good condition and using average piloting techniques.

It should be noted that performance information presented in the range and endurance profile charts allows for 45 minutes reserve fuel at the specified cruise power. Fuel flow data for cruise is based on the recommended lean mixture setting at all altitudes. Some indeterminate variables such as mixture leaning technique, fuel metering characteristics, engine and propeller condition, and air turbulence may account for variations of 10% or more in range and endurance. Therefore, it is important to utilize all available information to estimate the fuel required for the particular flight and to flight plan in a conservative manner.

USE OF PERFORMANCE CHARTS

Performance data is presented in tabular or graphical form to illustrate the effect of different variables. Sufficiently detailed information is provided in the tables so that conservative values can be selected and used to determine the particular performance figure with reasonable accuracy.

SAMPLE PROBLEM

The following sample flight problem utilizes information from the various charts to determine the predicted performance data for a typical flight. Assume the following information has already been determined:

AIRPLANE CONFIGURATION:

Takeoff weight Usable fuel

3100 Pounds 88.0 Gallons

TAKEOFF CONDITIONS

Field pressure altitude Temperature

1500 Feet 28°C (16°C Above Standard) 12 Knot Headwind

3500 Feet

Wind component along runway Field length

CRUISE CONDITIONS:

Total distance 450 Nautical Miles

Pressure altitude 7500 Feet

Temperature 16°

Expected wind enroute 10 Knot Headwind

LANDING CONDITIONS:

Field pressure altitude 2000 Feet

Temperature 25°C

Field length 3000 Feet

TAKEOFF

The takeoff distance chart, Figure 5-5, should be consulted, keeping in mind that distances shown are based on the short field technique. Conservative distances can be established by reading the chart at the next higher value of weight, altitude and temperature. For example, in this particular sample problem, the takeoff distance information presented for a weight of 3100 pounds, pressure altitude of 2000 feet and a temperature of 30°C should be used and results in the following:

Ground roll 1055 Feet Total distance to clear a 50-foot obstacle 2035 Feet

These distances are well within the available takeoff field length. However, a correction for the effect of wind may be made based on Note 3 of the takeoff chart. The correction for a 12 knot headwind is:

12 Knots X 10% = 13% Decrease 9 Knots

This results in the following distances, corrected for wind:

Ground roll, zero wind 1055
Decrease in ground roll -137
(1055 feet X 13%)

Corrected ground roll 918 Feet

CESSNA MODEL 182S

SECTION 5 PERFORMANCE

Total distance to clear a 50-foot obstacle, zero wind

Decrease in total distance (2035 feet X 13%)

-265

2035

Corrected total distance to clear 50-foot obstacle

1770 Feet

CRUISE

The cruising altitude should be selected based on a consideration of trip length, winds aloft, and the airplane's performance. A typical cruising altitude and the expected wind enroute have been given for this sample problem. However, the power setting selection for cruise must be determined based on several considerations. These include the cruise performance characteristics presented in Figure 5-9, the range profile chart presented in Figure 5-10, and the endurance profile chart presented in Figure 5-11.

The relationship between power and range is illustrated by the range profile chart. Considerable fuel savings and longer range result when lower power settings are used. For this sample problem, a cruise power of approximately 60% will be used.

The cruise performance chart, Figure 5-9, is entered at 8000 feet altitude and 20°C above standard temperature. These values most nearly correspond to the planned altitude and expected temperature conditions. The engine speed chosen is 2400 RPM and 21 inches of manifold pressure, which results in the following:

Power 66%
True airspeed 134 Knots
Cruise fuel flow 11.3 GPH

Nov 15/00 5-5

FUEL REQUIRED

The total fuel requirement for the flight may be estimated using the performance information in Figure 5-8 and Figure 5-9. For this sample problem, Figure 5-8 shows that a normal climb from 2000 feet to 8000 feet requires 2.7 gallons of fuel. The corresponding distance during the climb is 18 nautical miles. These values are for a standard temperature and are sufficiently accurate for most flight planning purposes. However, a further correction for the effect of temperature may be made as noted on the climb chart. The approximate effect of a non-standard temperature is to increase the time, fuel, and distance by 10% for each 10°C above standard temperature, due to the lower rate of climb. In this case, assuming a temperature 16°C above standard the correction would be:

$$\frac{16^{\circ}}{10^{\circ}}$$
 X 10% = 16% Increase

With this factor included, the fuel estimate would be calculated as follows:

Fuel to climb, standard temperature	2.7
Increase due to non-standard temperature	0.4
(2.7 X 16%)	

Corrected fuel to climb

3.1 Gallons

Using a similar procedure for the distance to climb results in 21 nautical miles.

The resultant cruise distance is:

l otal distance	450
Climb distance	-21
Cruise distance	429
	Nautical Miles

With an expected 10 knot headwind, the ground speed for cruise is predicted to be:

134 -10 124 Knots

Therefore, the time required for the cruise portion of the trip is:

The fuel required for cruise is:

3.5 hours X 11.3 gallons/hour = 39.1 Gallons

A 45-minute reserve requires:

$$\frac{45}{60}$$
 X 11.3 gallons / hour = 8.5 Gallons

The total estimated fuel required is as follows:

Engine start, taxi, and takeoff	1.7
Climb	3.1
Cruise	39.1
Reserve	<u>8.5</u>

Total fuel required 52.4 Gallons

Once the flight is underway, ground speed checks will provide a more accurate basis for estimating the time enroute and the corresponding fuel required to complete the trip with ample reserve.

LANDING

A procedure similar to takeoff should be used for estimating the landing distance at the destination airport. Figure 5-12 presents landing distance information for the short field technique. The distances corresponding to 2000 feet and 30°C are as follows:

Ground roll 670 Feet
Total distance to clear a 50-foot obstacle 1480 Feet

A correction for the effect of wind may be made based on Note 2 of the landing chart, using the same procedure as outlined for takeoff.

DEMONSTRATED OPERATING TEMPERATURE

Satisfactory engine cooling has been demonstrated for this airplane with an outside air temperature 23°C above standard. This is not to be considered as an operating limitation. Reference should be made to Section 2 for engine operating limitations.

Nov 15/00

AIRSPEED CALIBRATION

NORMAL STATIC SOURCE

CONDITION:

Power required for level flight or maximum power descent.

FLAPS UP												
KIAS	55	60	70	80	90	100	110	120	130	140	150	160
KCAS	62	65	73	82	90	100	109	118	127	137	146	156
FLAPS 20°												
KIAS	40	50	60	70	80	90	100	110	120			
KCAS	53	58	64	72	81	91	100	110	119			
FLAPS FULL												
KIAS	40	50	60	70	80	90	95					
KCAS	51	56	64	72	81	91	95					-:-:-

Figure 5-1. Airspeed Calibration (Sheet 1 of 2)

AIRSPEED CALIBRATION

ALTERNATE STATIC SOURCE

NOTE:

Windows closed, ventilators closed, cabin heater, cabin air, and defroster on maximum.

CONDITION:

Power required for level flight or maximum power descent.

FLAPS UP											
KIAS	60	70	80	90	100	110	120	130	140	150	160
ALT KIAS	62	72	82	92	103	114	124	133	143	153	164
FLAPS 20°											
KIAS	50	60	70	80	90	100	110	120			
ALT KIAS	50	60	70	81	92	102	112	121			
FLAPS FULL											
KIAS	50	60	70	80	90	95					- (5)(5)
ALT KIAS	43	57	68	79	89	93					- 808



Figure 5-1. Airspeed Calibration (Sheet 2 of 2)

ALTIMETER CORRECTION

ALTERNATE STATIC SOURCE

NOTE:

Add correction to desired altitude to obtain indicated altitude to fly. Windows closed, ventilators closed, cabin heater, cabin air, and defroster on maximum.

CONDITIONS:

Power required for level flight or maximum power descent cruise configuration. Altimeter corrections for the takeoff and landing configuration are less than 50 feet.

CONDITION FLAPS	CORRECTION TO BE ADDED-FEET KIAS - alternate static source ON									
UP	60	80	100	120	140	160				
S.L.	20	-10	-30	-60	-90	-120				
2000 ft.	20	-10	-30	-60	-90	-130				
4000 ft.	20	-10	-30	-70	-100	-140				
6000 ft.	30	-10	-40	-70	-110	-140				
8000 ft.	30	-10	-40	-80	-110	-150				
10,000 ft.	30	-10	-40	-80	-120	-160				
12,000 ft.	30	-10	-40	-80	-120	-170				
14,000 ft.	30	-10	-50	-90	-120	-180				

Figure 5-2. Altimeter Correction

Feb 3/97 5-11

TEMPERATURE CONVERSION CHART




Figure 5-3. Temperature Conversion Chart

STALL SPEEDS AT 3100 POUNDS

Conditions: Power Off

MOST REARWARD CENTER OF GRAVITY

		ANGLE OF BANK											
FLAP SETTING	0°		30°		4	5°	60°						
		KCAS	KIAS	KCAS	KIAS	KCAS	KIAS	KCAS					
UP	40	54	43	58	48	64	57	76					
20°	29	50	31	54	34	59	41	71					
FULL	35	49	38	53	42	58	49	69					

MOST FORWARD CENTER OF GRAVITY

F. 45		ANGLE OF BANK											
FLAP SETTING	0°		30°		45°		60°						
		KCAS	KIAS	KCAS	KIAS	KCAS	KIAS	KCAS					
UP 20°	43	56	46	60	51	67	61	79					
FULL	35 36	52 50	38 39	56 54	42 43	62 59	49 51	74 71					

NOTES:


- Altitude loss during a stall recovery may be as much as 250 feet.
 KIAS values are approximate.

Figure 5-4. Stall Speeds

Feb 3/97 5-13

WIND COMPONENTS

NOTE






Figure 5-5. Crosswind Components

5-14 Nov 15/00

SHORT FIELD TAKEOFF DISTANCE **AT 3100 POUNDS**

CONDITIONS:


Flaps 20° 2400 RPM, Full Throttle and Mixture Set Prior to Brake Release Cowl Flaps Open Paved, Level, Dry Runway Zero Wind

Lift Off: 49 KIAS Speed at 50 Ft: 58 KIAS

		0°C	1	0°C	2	0°C	3	0°C	4	0°C
Press Alt In Feet	Grnd Roll Ft	Total Ft To Clear 50 Ft Obst								
S. L.	715	1365	765	1460	825	1570	885	1680	945	1800
1000	775	1490	835	1600	900	1720	965	1845	1030	1980
2000	850	1635	915	1760	980	1890	1055	2035	1130	2190
3000	925	1800	995	1940	1070	2090	1150	2255	1235	2435
4000	1015	1990	1090	2150	1175	2325	1260	2515	1355	2720
5000	1110	2210	1195	2395	1290	2595	1385	2820	1485	3070
6000	1220	2470	1315	2690	1415	2930	1520	3200	1635	3510
7000	1340	2785	1445	3045	1560	3345	1675	3685	***	
8000	1480	3175	1595	3500	1720	3880				

NOTES:

1. Short field technique as specified in Section 4.



- Prior to takeoff, the mixture should be leaned to the Maximum Power Fuel Flow placard value in a full throttle, static runup.
- Decrease distances 10% for each 9 knots headwind. For operation with tail winds up to 10 knots, increase distances by 10% for each 2 knots.
- 4. For operation on dry, grass runway, increase distances by 15% of the "ground roll" figure.

Figure 5-6. Short Field Takeoff Distance (Sheet 1 of 3)

SHORT FIELD TAKEOFF DISTANCE **AT 2700 POUNDS**

CONDITIONS:

Flaps 20° 2400 RPM, Full Throttle and Mixture Set Prior to Brake Release Cowl Flaps Open Paved, Level, Dry Runway Zero Wind

Lift Off:

45 KIAS

Speed at 50 Ft: 54 KIAS

		0°C	10	0°C	2	0°C	3	0°C	4	0°C
Press Alt In Feet	Grnd Roll Ft	Total Ft To Clear 50 Ft Obst								
S. L.	520	995	560	1065	600	1135	645	1215	690	1295
1000	565	1080	610	1155	655	1235	700	1320	750	1410
2000	615	1180	665	1260	710	1350	765	1445	820	1545
3000	675	1285	725	1380	775	1480	835	1585	895	1695
4000	735	1410	790	1510	850	1625	910	1740	975	1870
5000	805	1550	865	1665	930	1790	1000	1920	1070	2065
6000	880	1705	950	1840	1020	1980	1095	2135	1175	2300
7000	965	1890	1040	2040	1120	2205	1200	2380	1290	2575
8000	1060	2100	1145	2275	1230	2465	1320	2675	1420	2910

NOTES:

- 1. Short field technique as specified in Section 4.
- 2. Prior to takeoff, the mixture should be leaned to the Maximum Power Fuel Flow placard value in a full throttle, static runup.
 - 3. Decrease distances 10% for each 9 knots headwind. For operation with tail winds up to 10 knots, increase distances by 10% for each 2 knots.
 - 4. For operation on dry, grass runway, increase distances by 15% of the "ground roll" figure.

Figure 5-6. Short Field Takeoff Distance (Sheet 2 of 3)

SHORT FIELD TAKEOFF DISTANCE AT 2300 POUNDS

CONDITIONS:

Flaps 20°
2400 RPM, Full Throttle and Mixture Set Prior to Brake Release
Cowl Flaps Open
Paved, Level, Dry Runway
Zero Wind

Lift Off: 42 KIAS Speed at 50 Ft: 50 KIAS

		0°C	1	0°C	2	20°C		0°C	4	0°C
Press Alt In Feet	Grnd Roll Ft	Total Ft To Clear 50 Ft Obst	Grnd Roll Ft	Total Ft To Clear 50 Ft Obst		Total Ft To Clear 50 Ft Obst	Grnd Roll Ft	Total Ft To Clear 50 Ft Obst	Grnd Roll Ft	Total Ft To Clear 50 Ft Obst
S. L.	365	705	390	750	420	800	450	850	480	905
1000	395	765	425	815	455	870	490	925	520	985
2000	430	830	460	885	495	940	530	1005	565	1070
3000	470	900	505	960	540	1025	580	1090	620	1165
4000	510	980	550	1045	590	1115	630	1190	675	1270
5000	555	1065	600	1140	640	1220	690	1305	735	1390
6000	610	1165	655	1250	700	1335	755	1430	805	1530
7000	665	1275	715	1370	770	1470	825	1570	885	1685
8000	730	1405	785	1510	845	1620	905	1735	970	1865

NOTES:

- 1. Short field technique as specified in Section 4.
- 2. Prior to takeoff, the mixture should be leaned to the Maximum Power Fuel Flow placard value in a full throttle, static runup.
 - Decrease distances 10% for each 9 knots headwind. For operation with tail winds up to 10 knots, increase distances by 10% for each 2 knots.
 - 4. For operation on dry, grass runway, increase distances by 15% of the "ground roll" figure.

Figure 5-6. Short Field Takeoff Distance (Sheet 3 of 3)

MAXIMUM RATE-OF-CLIMB AT 3100 POUNDS

CONDITIONS:

Flaps Up 2400 RPM, Full Throttle, Mixture Set to Maximum Power Fuel Flow placard value Cowl Flaps Open

PRESS	CLIMB	RATE OF CLIMB - FPM						
ALT FT	SPEED KIAS	-20°C	0°C	20°C	40°C			
S.L.	80	1055	980	905	835			
2000	79	945	875	805	735			
4000	78	840	770	705	635			
6000	77	735	670	605	535			
8000	75	625	560	495	430			
10,000	74	520	455	390	330			
12,000	73	410	350	285	225			
14,000	72	310	250	190	130			

Figure 5-7. Maximum Rate of Climb

TIME, FUEL AND DISTANCE TO CLIMB **AT 3100 POUNDS**

MAXIMUM RATE OF CLIMB

CONDITIONS:

Flaps Up 2400 RPM, Full Throttle, Mixture Set to Maximum Power Fuel Flow placard value Cowl Flaps Open Standard Temperature

PRESS	CLIMB	RATE	FR	OM SEA L	EVEL
ALT FT	SPEED KIAS	OF CLIMB FPM	TIME IN MIN	FUEL USED GAL	DIST NM
S.L.	80	925	0	0.0	0
2000	79	835	2	0.8	3
4000	78	750	5	1.5	7
6000	77	660	8	2.3	11
8000	75	565	11	3.2	16
10,000	74	470	15	4.2	21
12,000	73	375	20	5.2	29
14,000	72	285	26	6.5	38

NOTES:

 Add 1.7 gallons of fuel for engine start, taxi and takeoff allowance.
 Mixture leaned to Maximum Power Fuel Flow placard value for smooth engine operation and increased power.

3. Increase time, fuel and distance by 10% for each 10°C above

standard temperature.

Distances shown are based on zero wind.

Figure 5-8. Time, Fuel and Distance to Climb (Sheet 1 of 2)

12:535

TIME, FUEL AND DISTANCE TO CLIMB AT 3100 POUNDS

NORMAL CLIMB - 90 KIAS

CONDITIONS:

Flaps Up 2400 RPM, 23 in. Hg. or Full Throttle (whichever is less), Mixture 15 GPH or Full Rich (whichever is less) Cowl Flaps As Required. Standard Temperature

PRESS	CLIMB	RATE	FRO	M SEA L	EVEL
ALT FT	SPEED KIAS	OF CLIMB FPM	TIME IN MIN	FUEL USED GAL	DIST NM
S.L.	90	665	0	0.0	0
2000	90	625	3	0.8	5
4000	90	580	6	1.6	10
6000	90	540	10	2.5	16
8000	90	455	14	3.5	23
10,000	90	370	19	4.6	31

NOTES:

- Add 1.7 gallons of fuel for engine start, taxi and takeoff allowance.
- Mixture leaned to Maximum Power Fuel Flow placard value for smooth engine operation and increased power.
 - 3. Increase time, fuel and distance by 10% for each 10°C above standard temperature.
 - 4. Distances shown are based on zero wind.

Figure 5-8. Time, Fuel and Distance to Climb (Sheet 2 of 2)

CRUISE PERFORMANCE PRESSURE ALTITUDE SEA LEVEL

CONDITIONS:

3100 Pounds Recommended Lean Mixture Cowl Flaps Closed

NOTE: Maximum cruise power is 80% MCP. Those powers above that value in the table are for interpolation purposes only.

RPM	MP		°C BEL IDARD -5°C			ΓANDA IPERA 15°C		20°C ABOVE STANDARD TEMP 35°C		
111 101	IVII	% BHP	KTAS	GPH	% BHP	KTAS	GPH	% BHP	KTAS	GPH
2400	27		***					83	137	14.0
1 1	26			***	82	134	13.7	79	135	13.3
1	25	80	130	13.4	77	131	13.0	75	131	12.6
	24	76	127	12.7	73	127	12.3	71	128	11.9
	23	71	123	12.0	69	124	11.6	66	125	11.3
	22	67	120	11.3	64	121	10.9	62	121	10.6
	21	62	117	10.6	60	117	10.3	58	117	10.0
	20	57	112	10.0	55	113	9.7	54	113	9.4
2300	27				83	134	13.9	80	135	13.4
	26	82	131	13.7	79	132	13.2	76	132	12.8
	25	77	128	12.9	75	129	12.5	72	129	12.1
	24	73	125	12.3	70	126	11.9	68	127	11.5
	23	69	122	11.6	66	123	11.2	64	123	10.9
	22	64	119	10.9	62	119	10.6	60	119	10.3
	21	60	115	10.3	58	115	10.0	56	115	9.8
	20	56	111	9.7	54	111	9.4	52	111	9.2
2200	27	83	131	13.8	80	132	13.3	77	133	12.9
	26	78	129	13.1	76	129	12.7	73	130	12.3
	25	74	126	12.5	72	126	12.1	69	128	11.7
	24	70	123	11.8	68	124	11.5	66	124	11.1
	23	66	120	11.2	64	121	10.9	62	121	10.6
	22	62	117	10.6	60	117	10.3	58	117	10.0
1 1	21	58	113	10.0	56	113	9.7	54	113	9.5
	20	54	109	9.4	52	109	9.2	50	109	8.9



Figure 5-9. Cruise Performance (Sheet 1 of 10)

CRUISE PERFORMANCE PRESSURE ALTITUDE SEA LEVEL

CONDITIONS:

3100 Pounds Recommended Lean Mixture Cowl Flaps Closed

NOTE: Maximum cruise power is 80% MCP. Those powers above that value in the table are for interpolation purposes only.



RPM	MP		°C BEL IDARD -5°C	12.1		ANDA IPERA 15°C		20°C ABOVE STANDARD TEMP 35°C		
		% BHP	KTAS	GPH	% BHP	KTAS	GPH	% BHP	KTAS	GPH
2100	27	79	129	13.2	76	130	12.7	73	130	12.3
	26	75	126	12.5	72	127	12.1	70	128	11.8
	25	71	123	11.9	68	124	11.5	66	125	11.2
1	24	67	120	11.3	64	121	11.0	62	121	10.7
	23	63	118	10.7	61	117	10.4	59	118	10.2
	22	59	114	10.2	57	114	9.9	55	114	9.6
	21	55	110	9.6	53	111	9.4	51	111	9.1
2000	27	74	126	12.5	72	127	12.1	70	128	11.7
	26	71	123	11.9	68	124	11.5	66	125	11.2
	25	67	121	11.4	65	122	11.0	63	121	10.7
	24	63	118	10.8	61	118	10.5	59	118	10.2
	23	60	114	10.3	58	115	10.0	56	115	9.7
	22	56	111	9.8	54	111	9.5	52	112	9.2
	21	52	108	9.2	50	108	9.0	49	108	8.8

Figure 5-9. Cruise Performance (Sheet 2 of 10)

CRUISE PERFORMANCE PRESSURE ALTITUDE 2000 FEET

CONDITIONS:

3100 Pounds Recommended Lean Mixture Cowl Flaps Closed

NOTE: Maximum cruise power is 80% MCP. Those powers above that value in the table are for interpolation purposes only.

RPM	MP		°C BEL IDARD -9°C			ANDA IPERA 11°C		20°C ABOVE STANDARD TEMP 31°C		
		% BHP	KTAS	GPH	% BHP	KTAS	GPH	% BHP	KTAS	GPH
2400	26			72628211	1			82	139	13.7
	25	83	134	13.9	80	135	13.4	77	135	12.9
	24	78	131	13.1	75	131	12.7	73	132	12.3
	23	74	127	12.4	71	128	12.0	69	129	11.6
	22	69	124	11.6	67	125	11.3	64	125	10.9
	21	64	121	10.9	62	120	10.6	60	121	10.3
	20	60	116	10.3	58	117	10.0	56	117	9.7
2300	26	 -		***	81	136	13.6	78	136	13.1
	25	80	132	13.3	77	132	12.9	74	133	12.5
	24	75	129	12.6	73	129	12.2	70	131	11.8
1	23	71	125	11.9	68	126	11.6	66	127	11.2
	22	66	122	11.3	64	123	10.9	62	123	10.6
1 1	21	62	118	10.6	60	119	10.3	58	119	10.0
	20	58	114	10.0	56	115	9.7	54	115	9.5
2200	26	81	132	13.5	78	133	13.1	75	134	12.6
	25	77	130	12.8	74	130	12.4	71	131	12.0
	24	72	126	12.2	70	127	11.8	68	128	11.4
	23	68	124	11.5	66	124	11.2	64	124	10.9
	22	64	120	10.9	62	120	10.6	60	121	10.3
	21	60	116	10.3	58	117	10.0	56	117	9.7
	20	56	113	9.7	54	113	9.4	52	113	9.2



Figure 5-9. Cruise Performance (Sheet 3 of 10)

Nov 15/00 5-23

CRUISE PERFORMANCE PRESSURE ALTITUDE 2000 FEET

CONDITIONS:

3100 Pounds Recommended Lean Mixture Cowl Flaps Closed

NOTE: Maximum cruise power is 80% MCP. Those powers above that value in the table are for interpolation purposes only.



RPM	MP	20°C BELOW STANDARD TEMP -9°C			STANDARD TEMPERATURE 11°C			20°C ABOVE STANDARD TEMP 31°C		
		% BHP	KTAS	GPH	% BHP	KTAS	GPH	% BHP	KTAS	GPH
2100	26	77	130	12.9	74	130	12.4	72	131	12.1
	25	73	127	12.2	70	128	11.8	68	128	11.5
	24	69	124	11.6	66	125	11.3	64	125	10.9
	23	65	121	11.0	63	121	10.7	61	122	10.4
	22	61	117	10.5	59	118	10.2	57	118	9.9
	21	57	114	9.9	55	114	9.6	53	114	9.4
	20	53	110	9.3	51	110	9.1	49	110	8.8
2000	26	73	127	12.2	70	128	11.8	68	128	11.5
	25	69	124	11.7	67	125	11.3	64	125	11.0
1	24	65	122	11.1	63	121	10.8	61	122	10.5
	23	62	118	10.6	59	118	10.2	57	119	10.0
	22	58	115	10.0	56	115	9.7	54	115	9.5
	21	54	111	9.5	52	111	9.2	50	111	9.0

Figure 5-9. Cruise Performance (Sheet 4 of 10)

CRUISE PERFORMANCE PRESSURE ALTITUDE 4000 FEET

CONDITIONS:

•3100 Pounds •Recommended Lean Mixture •Cowl Flaps Closed

NOTE: Maximum cruise power is 80% MCP. Those powers above that value in the table are for interpolation purposes only.

value in the table are for interpolation purposes only.											
RPM	MP	20° STAN	C BEL IDARD -13°C	OW TEMP		ANDA IPERA 7°C			°C ABC IDARD 27°C		
		% BHP	KTAS	GPH	% BHP	KTAS	GPH	% BHP	KTAS	GPH	
2400	25		5.57		82	139	13.8	80	140	13.3	
	24	81	135	13.5	78	135	13.0	75	137	12.6	
	23	76	131	12.8	73	132	12.3	71	133	11.9	
	22	71	128	12.0	69	129	11.6	67	129	11.3	
	21	67	125	11.3	64	124	10.9	62	125	10.6	
	20	62	120	10.6	60	121	10.3	58	121	10.0	
2300	25	82	136	13.8	79	136	13.3	77	137	12.8	
	24	78	133	13.0	75	133	12.6	72	135	12.2	
	23	73	129	12.3	71	130	11.9	68	130	11.5	
	22	69	126	11.6	66	126	11.2	64	127	10.9	
1 1	21	64	122	10.9	62	123	10.6	60	123	10.3	
	20	60	118	10.3	58	119	10.0	56	119	9.7	
2200	25	79	133	13.2	76	134	12.7	73	135	12.3	
	24	75	130	12.5	72	131	12.1	70	132	11.7	
1	23	70	127	11.9	68	128	11.5	66	128	11.1	
	22	66	124	11.2	64	124	10.9	62	125	10.6	
	21	62	120	10.6	60	121	10.3	58	121	10.0	
1	20	58	116	10.0	56	116	9.7	54	117	9.4	
2100	25	75	130	12.6	72	132	12.2	70	132	11.8	
	24	71	128	11.9	68	129	11.6	66	128	11.2	
	23	67	125	11.3	65	125	11.0	62	125	10.7	
	22	63	121	10.7	61	122	10.4	59	122	10.1	
	21	59	117	10.2	57	118	9.9	55	118	9.6	
	20	55	114	9.6	53	114	9.3	51	113	9.1	
2000	25	71	128	12.0	69	129	11.6	66	129	11.2	
	24	67	125	11.4	65	125	11.0	63	126	10.7	
	23	63	121	10.8	61	122	10.5	59	122	10.2	
	22	60	118	10.3	58	118	10.0	56	119	9.7	
	21	56	115	9.7	54	115	9.5	52	115	9.2	



Figure 5-9. Cruise Performance (Sheet 5 of 10)

Nov 15/00 5-25

CRUISE PERFORMANCE PRESSURE ALTITUDE 6000 FEET

CONDITIONS:

RPM	MP		C BEL IDARD -17°C			ANDA IPERA 3°C			°C ABC IDARD 23°C	
		% BHP	KTAS	GPH	% BHP	KTAS	GPH	% BHP	KTAS	GPH
2400	23	79	135	13.2	76	136	12.7	73	137	12.3
1	22	74	132	12.4	71	133	12.0	69	133	11.6
	21	69	129	11.7	67	128	11.3	64	129	10.9
	20	64	124	10.9	62	125	10.6	60	125	10.3
	19	60	120	10.3	57	120	10.0	55	120	9.7
2300	23	76	133	12.7	73	134	12.2	70	135	11.9
	22	71	130	12.0	68	130	11.6	66	131	11.2
	21	66	126	11.3	64	127	10.9	62	127	10.6
	20	62	122	10.6	60	122	10.3	58	123	10.0
	19	57	118	10.0	55	118	9.7	53	118	9.4
2200	23	73	131	12.2	70	132	11.8	68	132	11.4
	22	68	128	11.5	66	128	11.2	64	129	10.8
	21	64	124	10.9	62	124	10.6	60	124	10.3
	20	60	120	10.3	57	120	10.0	56	120	9.7
	19	55	116	9.7	53	116	9.4	52	115	9.1
2100	23	69	129	11.6	66	128	11.3	64	129	10.9
	22	65	125	11.0	63	125	10.7	60	125	10.4
	21	61	121	10.4	59	121	10.1	57	121	9.9
	20	57	117	9.9	55	117	9.6	53	117	9.3
1	19	53	113	9.3	51	113	9.0	49	112	8.8
2000	23	65	125	11.1	63	126	10.8	61	126	10.5
	22	62	122	10.5	59	122	10.2	57	122	10.0
	21	58	118	10.0	56	118	9.7	54	118	9.4
	20	54	114	9.5	52	114	9.2	50	113	8.9
	19	50	110	8.9	48	109	8.7	47	108	8.4



Figure 5-9. Cruise Performance (Sheet 6 of 10)

CRUISE PERFORMANCE PRESSURE ALTITUDE 8000 FEET

CONDITIONS:



RPM	MP		°C BEL IDARD -21°C			ANDA IPERA -1°C		20°C ABOVE STANDARD TEMP 19°C			
		% BHP	KTAS	GPH	% BHP	KTAS	GPH	% BHP	KTAS	GPH	
2400	21	71	133	12.0	69	133	11.6	66	134	11.3	
1 1	20	67	128	11.3	64	129	10.9	62	129	10.6	
	19	62	124	10.6	59	124	10.3	57	124	10.0	
	18	57	119	9.9	55	119	9.6	53	119	9.3	
2300	21	69	130	11.6	66	131	11.2	64	131	10.9	
	20	64	126	10.9	62	126	10.6	60	127	10.3	
	19	59	122	10.3	57	122	9.9	55	122	9.7	
	18	55	117	9.6	53	117	9.3	51	116	9.1	
0000	0.4		407	44.0	0.4	100	40.0	04	100	40.5	
2200	21	66	127	11.2	64	128	10.8	61	128	10.5	
	20	62	124	10.6	59	124	10.2	57	124	9.9	
	19	57	119	9.9	55	120	9.6	53	119	9.4	
	18	53	115	9.3	51	114	9.0	49	113	8.8	
2100	21	63	125	10.7	60	125	10.4	58	125	10.1	
1 1	20	59	121	10.1	56	121	9.8	54	121	9.6	
	19	54	117	9.5	52	116	9.3	51	115	9.0	
	18	50	112	9.0	48	111	8.7	47	109	8.5	
0000	04		400	40.0		400			400		
2000	21	59	122	10.3	57	122	9.9	55	122	9.7	
	20	56	118	9.7	54	118	9.4	52	117	9.2	
	19	52	114	9.1	50	113	8.9	48	111	8.6	

Figure 5-9. Cruise Performance (Sheet 7 of 10)

CRUISE PERFORMANCE PRESSURE ALTITUDE 10,000 FEET

CONDITIONS:

RPM	MP		C BELIDARD -25°C			ANDAI IPERA -5°C		20°C ABOVE STANDARD TEMP 15°C			
		% BHP	KTAS	GPH	% BHP	KTAS	GPH	% BHP	KTAS	GPH	
2400	20	69	132	11.6	66	133	11.2	64	133	10.9	
	19	64	128	10.9	62	128	10.6	59	128	10.3	
	18	59	123	10.2	57	123	9.9	55	123	9.6	
2300	20	66	130	11.2	64	131	10.9	62	131	10.6	
	19	62	126	10.6	59	126	10.2	57	126	9.9	
	18	57	121	9.9	55	121	9.6	53	120	9.3	
2200	20	64	128	10.8	61	128	10.5	59	128	10.2	
	19	59	123	10.2	57	124	9.9	55	123	9.6	
	18	55	119	9.6	53	118	9.3	51	117	9.0	
2100	20	60	125	10.4	58	125	10.1	56	125	9.8	
2100	19	56	120	9.8	54	120	9.5	52	119	9.2	
	18	52	115	9.2	50	114	8.9	48	113	8.7	
				"		` ` `	"."	'		0	
2000	20	57	121	9.9	55	122	9.6	53	121	9.4	
	19	53	117	9.4	51	116	9.1	50	115	8.9	
	18	49	112	8.8	48	110	8.6	46	108	8.3	



Figure 5-9. Cruise Performance (Sheet 8 of 10)

CRUISE PERFORMANCE PRESSURE ALTITUDE 12,000 FEET

CONDITIONS:

3100 Pounds Recommended Lean Mixture Cowl Flaps Closed



RPM	MP	20°C BELOW STANDARD TEMP -29°C				ANDA IPERA -9°C		20°C ABOVE STANDARD TEMP 11°C		
		% BHP	KTAS	GPH	% BHP	KTAS	GPH	% BHP	KTAS	GPH
2400	18	61	127	10.5	59	128	10.2	57	127	9.9
	17	56	122	9.8	54	121	9.5	52	120	9.2
	16	51	116	9.1	49	114	8.8	48	112	8.6
2300	18	59	125	10.2	57	125	9.9	55	124	9.6
	17	54	120	9.5	52	119	9.2	50	117	9.0
	16	49	113	8.8	48	111	8.6	46	107	8.3
2200	18	57	123	9.8	54	122	9.5	52	121	9.3
	17	52	117	9.2	50	115	8.9	48	114	8.7
2100	18	54	119	9.4	52	118	9.2	50	116	8.9
2100	17	49	113	8.9	48	112	8.6	46	108	8.3
	17	49	113	0.9	40	112	0.0	40	106	0.3
2000	18	51	115	9.1	49	114	8.8	47	111	8.5

Figure 5-9. Cruise Performance (Sheet 9 of 10)

Nov 15/00 5-29

CRUISE PERFORMANCE PRESSURE ALTITUDE 14,000 FEET

CONDITIONS:



	RPM	MP	20°C BELOW STANDARD TEMP -33°C			ST TEM	STANDARD TEMPERATURE -13°C			20°C ABOVE STANDARD TEMP 7°C		
١			% BHP	KTAS	GPH	% BHP	KTAS	GPH	% BHP	KTAS	GPH	
I	2400	16	53	120	9.4	51	118	9.1	49	116	8.8	
١		15	48	112	8.7	46	109	8.4	45	104	8.2	
	2300	16	51	117	9.1	49	115	8.8	48	111	8.6	
	2200	16	49	114	8.8	47	111	8.6	46	107	8.3	
	2100	16	47	110	8.5	45	105	8.2	43	103	8.0	

Figure 5-9. Cruise Performance (Sheet 10 of 10)

RANGE PROFILE 45 MINUTES RESERVE 65 GALLONS USABLE FUEL

CONDITIONS:

3100 Pounds
Maximum Performance Climb with Placard Mixture
Recommended Lean Mixture for Cruise
Standard Temperature
Zero Wind

NOTE:

This chart allows for the fuel used for engine start, taxi, takeoff and climb, cruise at the designated power, and the time during a normal climb up to 10,000 feet and maximum climb above 10,000 feet.




Figure 5-10. Range Profile (Sheet 1 of 2)

RANGE PROFILE 45 MINUTES RESERVE 88 GALLONS USABLE FUEL

CONDITIONS: 3100 Pounds Maximum Performance Climb with Placard Mixture Recommended Lean Mixture for Cruise Standard Temperature Zero Wind

NOTE:

This chart allows for the fuel used for engine start, taxi, takeoff and climb, cruise at the designated power, and the time during a normal climb up to 10,000 feet and maximum climb above 10,000 feet.




Figure 5-10. Range Profile (Sheet 2 of 2)

ENDURANCE PROFILE 45 MINUTES RESERVE 65 GALLONS USABLE FUEL

CONDITIONS: 3100 Pounds Maximum Performance Climb with Placard Mixture Recommended Lean Mixture for Cruise Standard Temperature Zero Wind

NOTE:

This chart allows for the fuel used for engine start, taxi, takeoff and climb, cruise at the designated power, and the time during a normal climb up to 10,000 feet and maximum climb above 10,000 feet.




Figure 5-11. Endurance Profile (Sheet 1 of 2)

Feb 3/97 5-33

ENDURANCE PROFILE 45 MINUTES RESERVE 88 GALLONS USABLE FUEL

CONDITIONS: 3100 Pounds Maximum Performance Climb with Placard Mixture Recommended Lean Mixture for Cruise Standard Temperature Zero Wind

NOTE:

This chart allows for the fuel used for engine start, taxi, takeoff and climb, cruise at the designated power, and the time during a normal climb up to 10,000 feet and maximum climb above 10,000 feet.




Figure 5-11. Endurance Profile (Sheet 2 of 2)

SHORT FIELD LANDING DISTANCE AT 2950 POUNDS

CONDITIONS:

Flaps FULL
Power Off
Maximum Braking
Paved, level, dry runway
Zero Wind
Speed at 50 Ft: 60 KIAS

	0°C		10°C		20°C		30°C		40°C	
Press Alt In Feet	Grnd Roll Ft	Total Ft To Clear 50 Ft Obst								
S. L.	560	1300	580	1335	600	1365	620	1400	640	1435
1000	580	1265	600	1365	620	1400	645	1440	665	1475
2000	600	1370	625	1405	645	1.440	670	1480	690	1515
3000	625	1410	645	1445	670	1485	695	1525	715	1560
4000	650	1450	670	1485	695	1525	720	1565	740	1600
5000	670	1485	695	1525	720	1565	745	1610	770	1650
6000	700	1530	725	1575	750	1615	775	1660	800	1700
7000	725	1575	750	1615	780	1665	805	1710	830	1750
8000	755	1625	780	1655	810	1715	835	1760	865	1805

NOTES:

- 1. Short field technique as specified in Section 4.
- Decrease distances 10% for each 9 knots headwind. For operation with tail winds up to 10 knots, increase distances by 10% for each 2 knots.
- 3. For operation on dry, grass runway, increase distances by 45% of the "ground roll" figure.
- 4. If a landing with flaps up is necessary, increase the approach speed by 10 KIAS and allow for 40% longer distances.

Figure 5-12. Short Field Landing Distance

	*.	*	
			n ^{di}
			98
			*

SECTION 6 WEIGHT & BALANCE/ EQUIPMENT LIST

TABLE OF CONTENTS								
Introduction	6-3							
Airplane Weighing Procedures	6-3							
Weight And Balance	6-5							
Baggage Tie-Down	6-7							
Comprehensive Equipment List	6-17							

			38
8			

٧.

.

٠

INTRODUCTION

This section describes the procedure for establishing the basic empty weight and moment of the airplane. Sample forms are provided for reference. Procedures for calculating the weight and moment for various operations are also provided. A comprehensive list of all Cessna equipment available for this airplane is included at the back of this section.

It should be noted that specific information regarding the weight, arm, moment and installed equipment for this airplane as delivered from the factory can only be found in the plastic envelope carried in the back of this handbook.


A WARNING

IT IS THE RESPONSIBILITY OF THE PILOT TO ENSURE THE AIRPLANE IS LOADED PROPERLY. OPERATION OUTSIDE OF PRESCRIBED WEIGHT AND BALANCE LIMITATIONS COULD RESULT IN AN ACCIDENT AND SERIOUS OR FATAL INJURY.

AIRPLANE WEIGHING PROCEDURES

- 1. Preparation:
 - a. Inflate tires to recommended operating pressures.
 - b. Defuel airplane. Refer to Model 182S, Series 1996 and On, Maintenance Manual.
 - c. Service engine oil as required to obtain a normal full indication. (8 quarts on dipstick.)
 - d. Move sliding seats to the most forward position.
 - e. Raise flaps to the fully retracted position.
 - f. Place all control surfaces in neutral position.
 - g. Remove all non-required items from airplane.
- 2. Leveling:
 - a. Place scales under each wheel (minimum scale capacity, 1000 pounds).
 - b. Deflate the nose tire and/or lower or raise the nose strut to properly center the bubble in the level (Refer to Figure 6-1).

AIRPLANE WEIGHING FORM



LEVELING PROVISIONS

LONGITUDINAL — LEFT SIDE OF TAILCONE AT FS 139.65 & 171.65

MEASURING A AND B

MEASURE A AND B PER PILOT'S OPERAT-ING HANDBOOK INSTRUCTIONS TO AS-SIST IN LOCATING CG WITH AIRPLANE WEIGHED ON LANDING GEAR

LOCATING CG WITH AIRPLANE ON LANDING GEAR

FORMULA for Longitudinal CG

(X) = (A) - $\frac{\text{(Nose Gear Net Weight)(}) \times \text{(B)}}{\text{Nose and Mein Landing GearWeight Totaled (})} = {$

Inches) Aft of Datum

LOCATING PERCENT MAC

FORMULA for Percent MAC
CG Percent MAC = (CG Arm of Airplane) - 25.98
0.5880

POSITION	SCALE READING	SCALE DRIFT	TARE	NET WEIGHT
LEFT SIDE			1	
AIRPL	ANE TOTAL AS W	EIGHED		

AIRPLANE AS WEIGHED TABLE

BASIC EMPTY WEIGHT AND CENTER-OF-GRAVITY TABLE

ITEM	WEIGHT (POUNDS)	CG ARM (INCHES)	MOMENT (INCH-POUND\$/1000)
AIRPLANE (CALCULATED OR AS WEIGHED) (INCLUDES ALL UNDRAINABLE FLUIDS AND FULL OIL)			
DRAINABLE UNUSABLE FUEL AT 6.0 POUNDS PER GALLON	24.0	48.0	1.2
BASIC EMPTY WEIGHT			

Figure 6-1. Airplane Weighing Form

3. Weighing:

 a. Weigh the airplane in a closed hangar to avoid errors caused by air currents.

 With the airplane level and brakes released, record the weight shown on each scale. Deduct the tare, if any, from each reading.

4. Measuring:

- a. Obtain measurement A by measuring horizontally (along the airplane centerline) from a line stretched between the main wheel centers to a plumb bob dropped from the firewall.
- b. Obtain measurement B by measuring horizontally and parallel to the airplane centerline, from center of nose wheel axle, left side, to a plumb bob dropped from the line between the main wheel centers. Repeat on right side and average the measurements.

5. Using weights from item 3 and measurements from item 4, the airplane weight and C.G. can be determined.

6. Basic Empty Weight may be determined by completing Figure 6-1.

WEIGHT AND BALANCE

The following information will enable you to operate your Cessna within the prescribed weight and center of gravity limitations. To determine weight and balance, use the Sample Loading Problem, Loading Graph, and Center of Gravity Moment Envelope as follows:

Take the basic empty weight and moment from appropriate weight and balance records carried in your airplane, and enter them in the column titled YOUR AIRPLANE on the Sample Loading Problem.

NOTE

In addition to the basic empty weight and moment noted on these records, the C.G. arm (fuselage station) is also shown, but need not be used on the Sample Loading Problem. The moment which is shown must be divided by 1000 and this value used as the moment/1000 on the loading problem.

Use the Loading Graph to determine the moment/1000 for each additional item to be carried; then list these on the loading problem.

Nov 15/00 6-5

Figure 6-2. Sample Weight and Balance Record

SAMPLE WEIGHT AND BALANCE RECORD

. (CONTINUOUS HISTORY OF CHANGES IN STRUCTURE OR EQUIPMENT AFFECTING WEIGHT AND BALANCE)

AIRPI	AIRPLANE MODEL				SERIAL NO.			PAG	PAGE NUMBER			
	ITEM NO. DESCRIPTION					VEIGHT	CHANG	E		RUNNING BASIC EMPTY		
DATE	I I CIV	NO.	DESCRIPTION AD		ED	(+)		REMOV	ED (-)		WEIGHT	
	IN	ОПТ	MODIFICATION	(LB	[.]	ARM (IN.)	MOMENT /1000,	WT. (LB.)	ARM (IN.)	MOMENT /1000	WT. (LB.)	MOMENT /1000
			AS DELIVERED		コ							
		_			+						-	
					1							
				_	4					_		_
					+							
					\exists							
				-	\dashv		_				-	_
					\exists							
					\Box							
				├	┥			-			-	
					╛							

0585C1009

Feb 3/97

NOTE

Loading Graph information for the pilot, passengers and baggage is based on seats positioned for average occupants and baggage loaded in the center of the baggage areas as shown on the Loading Arrangements diagram. For loadings which may differ from these, the Sample Loading Problem lists fuselage stations for these items to indicate their forward and aft C.G. range limitations (seat travel and baggage area limitation). Additional moment calculations, based on the actual weight and C.G. arm (fuselage station) of the item being loaded, must be made if the position of the load is different from that shown on the Loading Graph.

Total the weights and moments/1000 and plot these values on the Center of Gravity Moment Envelope to determine whether the point falls within the envelope, and if the loading is acceptable.

BAGGAGE TIE-DOWN

A nylon baggage net having tie-down straps is provided as standard equipment to secure baggage in the area aft of the rear seat (baggage areas A, B and C). Eight eyebolts serve as attaching points for the net. A placard on the baggage door defines the weight limitations in the baggage areas.


When baggage area A is utilized for baggage only, the four forward eyebolts should be used. When only baggage area B is used, the eyebolts just aft of the baggage door and the eyebolts above or below the shelf area may be used. When only baggage area C is utilized, the eyebolts above and below the shelf area should be used. When the cabin floor (baggage areas A and B) is utilized for baggage, the four forward eyebolts and the eyebolts mounted above or below the shelf area should be used. When there is baggage in areas B and C, the eyebolts just aft of the baggage door and the eyebolts above and below the shelf area should be used. When baggage is contained in all three areas, the two forward eyebolts on the cabin floor, the eyebolts just aft of the baggage door or the eyebolts at the bottom of the forward portion of the shelf area and the eyebolts near the upper forward surface of the shelf area should be used.

Nov 15/00 6-7

The rear bench seat can be removed to access the floorboard area of the rear cabin. Baggage may then be tied down using ten tiedown eyebolts to standard attach points located in the interior area of the airplane (shown in Figure 6-4, Sheet 2). The maximum allowable floor loading of the rear cabin area is 200 pounds/square foot; however, when items with small or sharp support areas are carried, the installation of a 1/4" plywood floor is recommended to protect the airplane structure.

The maximum rated load weight capacity for each of the ten tiedowns is 140 pounds. Rope, strap or cable used for tie-down should be rated at a minimum of ten times the load weight capacity of the tie-down fittings used. Weight and balance calculations for items in the area of the rear seat and baggage area can be figured on the Loading Graph using the lines labeled 2nd Row Passengers or cargo.

LOADING ARRANGEMENTS



^{*} Pilot or passenger center of gravity on adjustable seats positioned for average occupant. Numbers in parentheses indicate forward and aft limits of occupant center of gravity range.


NOTES:

- 1. The usable fuel C.G. arm is located at station 46.5
- 2. The aft baggage wall (approximate station 134) can be used as a convenenient interior reference point for determining the location of baggage area fuselage stations.

Figure 6-3. Loading Arrangements

^{**} Arms measured to the center of the areas shown.

CABIN HEIGHT MEASUREMENTS



DOOR OPENING DIMENSIONS

	WIDTH (TOP)	WIDTH (BOTTOM)		HEIGHT (REAR)
CABIN DOORS	32"	36½"	41"	38½"
BAGGAGE DOOR	15 <u>¾</u> "	15¾"	22"	20½"

Figure 6-4. Internal Cabin Dimensions (Sheet 1 of 2)

CABIN WIDTH MEASUREMENTS




Figure 6-4. Internal Cabin Dimensions (Sheet 2 of 2)

			W	EIGHT AN TABUI	ND MOM LATION	ENT
ITEM DESCRIPTION			APLE PLANE	YOUR AIRPLANE		
			Weight (lbs.)	Moment (Lb-ins. /1000)	Weight (lbs.)	Moment (Lb-ins. /1000)
		Basic Empty Weight (Use the data pertaining to your airplane as it is presently equipped. Includes unusable fuel and full oil)	1925	71.9		
	2. Usable Fuel (At 6 Lbs./Gal.)					
		88 Gallons Maximum		24.6		
		Reduced Fuel (65 Gallons)				
	3.	Pilot and Front Passenger (Station 32 to 50)	340	12.6		
	4.	Second Row Passengers	200	14.8		
		Cargo Replacing Second Row Seats (Sta. 65 to 82)				
	5.	*Baggage Area A (Station 82 to 109; 120 Lbs. Max.)	100	9.7		
I	6.	*Baggage Area B (Station 109 to 124; 80 Lbs. Max.)	17	1.7		
	7. *Baggage Area C (Station 124 to 134; 80 Lbs. Max.)					
	8.	RAMP WEIGHT AND MOMENT	3110	135.3		
	9.	start, taxi and runup	-10	-0.5		
	10	.TAKEOFF WEIGHT AND MOMENT (Subtract Step 9 from Step 8)	3100	134.8		

^{11.} Locate this point (3100 at 134.8) on the Center of Gravity Moment Envelope, and since this point falls within the envelope, the loading is acceptable, providing that flight time is allowed for fuel burn-off to a maximum of 2950 pounds before landing.


* The maximum allowable combined weight capacity for baggage in areas A, B and C is 200 pounds. The maximum allowable combined weight capacity in areas B and C is 80 pounds.

Figure 6-5. Sample Loading Problem (Sheet 1 of 2)

	OUR PLANE		OUR PLANE	YOUR AIRPLANI	
Weight (lbs.)	Moment (Lb-ins, /1000)	Weight (lbs.)	Moment (Lb-ins, /1000)	Weight (lbs.)	Moment (Lb-ins, /1000)
/hen seve	eral loading cor , it may be use ic loadings are	nfigurations a	re representati	ve of your the above colu	Jmns so

Figure 6-5. Sample Loading Problem (Sheet 2 of 2)

Feb 3/97 6-13



NOTE: Line representing adjustable seats shows pilot and front seat passenger center of gravity on adjustable seats positioned for an average occupant. Refer to the Loading Arrangements diagram for forward and aft limits of occupant C.G. range.

0785C1008

Figure 6-6. Loading Graph




Figure 6-7. Center of Gravity Moment Envelope




Figure 6-8. Center of Gravity Limits

Feb 3/97

COMPREHENSIVE EQUIPMENT LIST

The following figure (Figure 6-9) is a comprehensive list of all Cessna equipment which is available for the Model 182S airplane. This comprehensive equipment list provides the following information in column form:

In the ITEM NO column, each item is assigned a coded number. The first two digits of the code represent the assignment of the item within the Air Transport Association Specification 100 breakdown (11 for Paint and Placards; 24 for Elecrical Power; 77 for Engine Indicating, etc...). These assignments also correspond to the Maintenance Manual chapter breakdown for the airplane. After the first two digits (and hyphen), items receive a unique sequence number (01, 02, 03, etc...). After the sequence number (and hyphen), a suffix letter is assigned to identify equipment as a required item, a standard item or an optional item. Suffix letters are as follows:

R = required items or equipment for FAA certification

S = standard equipment items

O = optional equipment items replacing required or standard items

A = optional equipment items which are in addition to required or standard items

In the **EQUIPMENT LIST DESCRIPTION** column, each item is assigned a descriptive name to help identify its function.

In the **REF DRAWING** column, a Cessna drawing number is provided which corresponds to the item.

NOTE

If additional equipment is to be installed, it must be done in accordance with the reference drawing, service bulletin or a separate FAA approval.

In the WT LBS and ARM INS columns, information is provided on the weight (in pounds) and arm (in inches) of the equipment item.

NOTES

Unless otherwise indicated, true values (not net change values) for the weight and arm are shown. Positive arms are distances aft of the airplane datum; negative arms are distances forward of the datum.

Asterisks (*) in the weight and arm column indicate complete assembly installations. Some major components of the assembly are listed on the lines immediately following. The sum of these major components does not necessarily equal the complete assembly installation.

Dec 1/97 6-17

ITEM NO	EQUIPMENT LIST DESCRIPTION	REF DRAWING	WT LBS	ARM INS.
	11 - PAINT AND PLACARDS			
11-01-5	CORROSION PROOFING, INTERNAL		20.1	70.0
11-02-\$	PAINT, OVERALL EXTERIOR	0704056	19.6*	92.9*
	-OVERALL WHITE		18.8	91.5
	-COLORED STRIPE DECALS		0.8	135.9
11-03-S	IFR DAY & NIGHT LIMITATIONS PLACARD	0505087-9	0.0	17.3
11-04-O	IFR DAY & NIGHT LIMITATIONS PLACARD, BRAZILIAN	1205085	0.0	17.3
11-05-0	IFR DAY & NIGHT LIMITATIONS PLACARD, GERMAN		0.0	17.3
	22 - AUTO FLIGHT			
22-01-S	SINGLE AXIS AUTOPILOT, KAP 140	3900007-1	8.4*	50.3*
	 KC 140 SINGLE AXIS COMPUTER 	065-00176-2501	2.0	12.4
1	- KS 271C ROLL SERVO	065-00179-0100	2.4	52.0
	 CABLE ASSY, ROLL ACTUATOR 	3924110-1	0.4	66.0
_	- CABLE ASSY, KC 140 AUTOPILOT	3924104-1	0.9	2.0
	- KMC 100 CONFIGURATION MODULE	071-00073-5000	0.1	12.0
	- ANNUNCIATOR	CSEWCA-01	0.4	16.0
22-02-O	DUAL AXIS AUTOPILOT, KAP 140	3900008-1	13.1*	137.1*
	- KC 140 DUAL AXIS COMPUTER WITH ELECTRIC ELEVATOR TRIM	065-00176-5001	2.0	12.0
	- KS-270C PITCH SERVO	0701145-1	4.2	171.3
	- KS-270C PITCH TRIM SERVO	0701146-1	4.1	180.8
	- KS-271C ROLL SERVO	065-00179-0100	2.4	52.0
3	- CABLE ASSY, ROLL ACTUATOR	3924110-1	0.4	66.0
	- CABLE ASSY, KC 140 AUTOPILOT	3924104-1	1.8	87.3
	- KMC 100 CONFIGURATION MODULE	071-00073-5000	0.1	12.0
	- ANNUNCIATOR	CSEWCA-03	0.4	16.0
	23 - COMMUNICATIONS			
23-01-S	STATIC DISCHARGE WICKS, SET OF 10	1201131-2	0.3	152.9
23-02-S	NAV/COM #1 INSTALLATION	3900006-1	11.4*	37.3*
	- KX 155A NAV/COM with GS	066-01032-0101	5.7	12.4
	- KI 209A CDI INDICATOR	066-03056-0011	1.2	13.9
	- CI128A VHF COMM ANTENNA #1	3960113-8	0.5	63.3
	- HARDWARE AND CABLE ASSEMBLY	3921100-1	4.0	76.5
23-03-S	NAV/COM #2 INSTALLATION	3900006-1	8.9*	19.0*
	- KX 155A NAV/COM no GS	066-01032-0201	5.1	12.4
E	- KI 208 CDI INDICATOR	066-03056-0002	1.0	13.9
	- CI128A VHF COMM ANTENNA #2	3960113-9	0.5	63.3
	- ANTENNA COUPLER	3940405-1	0.2	12.0
	- HARDWARE AND CABLE ASSEMBLY	3921101-1	2.0	29.0
23-04-\$	AUDIO/INTERCOM/MARKER BEACON INSTL	3900006-1	6.5*	50.2*
	- KMA 26 AUDIO PANEL	066-01155-0101	1.8	14.4

Figure 6-9. Equipment List Description (Sheet 1 of 6)

ITEM NO	EQUIPMENT LIST DESCRIPTION	REF DRAWING	WT LBS	ARM INS.
	- MARKER BEACON ANTENNA	3960193-1	8.0	131.5
	- HARDWARE AND CABLE ASSEMBLY	3921108-1	3.9	52.8
	24 - ELECTRICAL POWER			
24-01-R	ALTERNATOR, 28 VOLT, 60 AMP	9910591-5	10.0	-33.4
24-02-R	BATTERY, 24 VOLT, 12.75 A.H. MANIFOLD TYPE	C614002-0101	23.2	132.1
24-03-O	BATTERY, 24 VOLT, HEAVY DUTY	G243	27.2	132.1
24-04-R	POWER JUNCTION BOX (PRECISION AIRMOTIVE CORP. MC01-2A) INCLUDES:		6.4*	-2.5*
	- ALTERNATOR CONTROL UNIT	ACC2101	0.2	-2.5
	- MASTER CONTACTOR X61-0007	1270101	0.7	-2.5
	- STARTER CONTACTOR X61-0012	3930400-1	0.7	-2.5
	- AMMETER TRANSDUCER	3930417.2	0.1	-2.0
24-05-S	BASIC AVIONICS KIT INSTALLATION	3900006-1	4.3*	55.5*
	- SUPPORT STRAPS INSTALLATION	1270101-1,-3	0.1	10.0
	- AVIONICS COOLING FAN INSTL	3940406-1	1.6	3.0
	- AVIONICS GROUND INSTALLATIONS	3940358-1	0.1	41.0
	- CIRCUIT BREAKER PANEL INSTL	3930299-1	1.5	16.5
	- MICROPHONE INSTL	3970139-2	0.2	18.5
	- OMNI ANTENNA INSTL	3960142-8	0.5	252.1
	- OMNI ANTENNA CABLE ASSY INSTL	3950162-1	0.3	248.0
	25 - EQUIPMENT/FURNISHINGS			
25-01-R	SEAT, PILOT, ADJUSTABLE, CLOTH COVER	0514212-3	33.8	41.5
25-02-A	SEAT, PILOT, ADJUSTABLE, LEATHR COVER	0514212-25	34.5	41.5
25-03-\$	SEAT, COPILOT, ADJ., CLOTH COVER	0514212-4	33.8	41.5
25-04-A	SEAT, COPILOT, ADJ., LEATHER COVER	0514212-25	34.5	41.5
25-05-S	SEAT, REAR, TWO PIECE BACK, CLOTH COVER	0714065-1	50.0	82.0
25-06-A	SEAT, REAR, TWO PIECE BACK, LEATHER COVER	0714065-2	51.4	82.0
25-07-R	SEAT BELT AND SHOULDER HARNESS, INERTIA REEL, PILOT AND COPILOT	0714070-1	5.2	50.3
25-08-A	SEAT BELT AND SHOULDER HARNESS, MANUAL ADJUST., PILOT AND COPILOT	0714070-2	4.0	50.3
25-09-S	SEAT BELT AND SHOULDER HARNESS, INERTIA REEL, REAR SEAT	0714070-1	5,2	87.8
25-10 - A	SEAT BELT AND SHOULDER HARNESS, MANUAL ADJUST., REAR SEAT	0714070-2	4.0	87.8
25-11-S	SUN VISORS, SET OF 2	0514166-3	1.2	33.0
25-12-S	BAGGAGE RETAINING NET	1215171-1	0.5	108.0
25-13-S	CARGO TIE DOWN RINGS, SET 0F 10	1211203-1	0.4	108.0
25-14-S	PILOT'S OPERATING CHECKLIST (STOWED	0700765-1	0.3	15.0
	IN INSTRUMENT PANEL MAP CASE)			
25-15-R	PILOT'S OPERATING HANDBOOK AND FAA APPROVED AIRPLANE FLIGHT MANUAL (STOWED IN PILOT'S SEAT BACK)	0700765-1	1.2	61.5

Figure 6-9. Equipment List Description (Sheet 2 of 6)

Nov 15/00 6-19

	ITEM NO	EQUIPMENT LIST DESCRIPTION	REF DRAWING	WT LBS	ARM INS.
H	25-16-S	FUEL SAMPLING CUP	\$2107-1	0.1	14.3
	25-17-S	TOW BAR, NOSE GEAR (STOWED)	0501019-1	1.7	108.0
	25-18-R	EMERGENCY LOCATOR TRANSMITTER INSTL	3940409-1	2.2*	134.8*
1			3000-11	1.7	135.0
Ì		- ANTENNA AND CABLE ASSY	3003-45	0.4	133.0
i		- HARDWARE	3940409-1	0.1	138.0
		26 - FIRE PROTECTION			
	26-01-S	FIRE EXTINGUISHER INSTALLATION	0501011-2	5.3*	29.0*
		- FIRE EXTINGUISHER	C421001-0201	4.8	29.0
		- MOUNTING CLAMP & HARDWARE	C421001-0202	0.5	29.0
		27 - FLIGHT CONTROLS			
	27-01-S	DUAL CONTROLS INSTL, RIGHT SEAT	0706010-1	6.3*	12.9*
l		- CONTROL WHEEL, COPILOT	0713377-2	2.0	26.0
		- RUDDER & BRAKE PEDAL INSTL, COPILOT	0760650-3	4.3	6.8
		28 - FUEL			
	28-01-R	FUEL QUANTITY INDICATORS, LEFT & RIGHT	S3317-3	0.7	16.0
l	28-02-R	AUXILIARY FUEL PUMP	5100-00-3	1.9	-2.0
-		31 - INDICATING/RECORDING SYSTEM			
	31-01-S	CLOCK and OAT INDICATOR INSTALLATION	M803B-2	0.3*	16.7*
	1	-TEMPERATURE PROBE	-0/28UIB	0.1	49.0
	31-02-S	FLIGHT HOUR RECORDER	C664503-0103	0.5	17.0
	31-03-R	ANNUNCIATOR PANEL AND LIGHTS	90-44001-1	0.5	15.9
	31-04-R	STALL WARNING INDICATOR	0718007-1	1.0	17.5
		32 - LANDING GEAR			
	32-01-R	WHEEL BRAKE AND TIRE, 6.00 X 6 MAIN	0741625-12	37.8*	58.6*
		- WHEEL ASSY (EACH)	C163001-0301	7.8	58.9
		- BRAKE ASSY (EACH)	C163030-0303	1.8	55.5
		- TIRE (EACH)	C262003-0204	8.0	58.9
		- TUBE (EACH)	C262023-0102	1.7	58.9
	32-02-R	WHEEL AND TIRE ASSY, 5.00 X 5 NOSE	0540000-2	8.8*	-7:1*
		- WHEEL ASSY	1241156-12	2.8	-7.1
		- TIRE	C262003-0202	4.6	-7.1
		- TUBE	C262023-0101	1.1	-7.1
	32-03-A	WHEEL FAIRING AND INSTALLATION	0741638-1	18.3*	44.1*
		- NOSE WHEEL FAIRING	0543079-7	3.9	-6.0
		- MAIN WHEEL FAIRINGS, SET OF 2	0541223-22, -23	10.3	60.2
		- BRAKE FAIRINGS, SET OF 2	0741641-14,-15	1.5	58.0
		- MOUNTING PLATE, SET OF 2	1241141-1,-2	0.9	60.0

Figure 6-9. Equipment List Description (Sheet 3 of 6)

ITEM NO	EQUIPMENT LIST DESCRIPTION	REF DRAWING	WT LBS	ARM INS.
	33 - LIGHTS			
33-01-S	MAP LIGHT IN CONTROL WHEEL	0706010-1	0.2	21.5
33-02-S	COURTESY LIGHTS UNDER WING	0700615-18	0.7	61.7
33-03-S	NAVIGATION LIGHT DETECTORS	1221201-3,-4	0.0	38.7
33-04-S	FLASHING BEACON ON VERTICAL FIN TIP	0701042-5	0.8	253.1
33-05-S	WING TIP STROBE LIGHT INSTALLATION	0501027-6	3.4	38.7
33-06-S	LANDING AND TAXI LIGHT INSTALLATION	1221059-7,-8	2.2	26.8
	34 - NAVIGATION			
34-01-R	INDICATOR, AIRSPEED	S3325-5	0.7	16.2
34-02-S	ALTERNATE STATIC AIR SOURCE	0701028-4	0.2	15.5
34-03-R	ALTIMETER, SENSITIVE WITH 20 FT.	S3328-1	0.9	15.3
04.04.0	MARKINGS, INCHES OF MERCURY	00074.4		450
34-04-0	ALTIMETER, SENSITIVE WITH 20 FT. MARKINGS, MILLIBARS	S3371-1	0.9	15.3
34-05-S	BLIND ALTITUDE ENCODER INSTALLATION	3940408-1	0.8	15.0
34-06 - R	COMPASS INSTL, MAGNETIC	1213679-3	0.5	18.0
34-07-S	GYRO, INSTALLATION (RQS, 37-01-5)	0706009-1	7.6*	11.0*
	- DIRECTIONAL GYRO INDICATOR	S3330-1	2.8	15.2
	- ATTITUDE GYRO INDICATOR	S3326-1	2.1	14.0
	- HOSE AND MISC HARDWARE	0706009-1	2.7	4.5
34-08-S	TURN COORDINATOR INDICATOR	S3291-1	1.2	15.5
34-09-S	VERTICAL SPEED INDICATOR	S3327-1	0.7	15.3
34-10-A	ADF INSTALLATION	3900006-1	6.4*	20.4*
	- KR-87 ADF RECEIVER	066-01072-0014	3.2	12.4
	- KI 227 ADF INDICATOR	066-03063-0000	0.7	13.9
	- ADF ANTENNA	3960192-1	1.5	39.6
	- ADF CABLE ASSEMBLY	3922101-1	1.0	22.0
34-11-S	GPS INSTALLATION	3900006-1	5.5*	18.8*
	- KLN 89B GPS RECEIVER	066-01148-1111	3.3	12.7
	- GPS ANTENNA	3960194-1	0.6	43.4
	- GPS CABLE ASSEMBLY	3928101-1	1.6	22.0
34-12 - S	MODE C TRANSPONDER INSTL	3900006-1	5.3*	18.8*
	- KT 76C TRANSPONDER	066-01156-0101	3.1	12.7
	- TRANSPONDER ANTENNA	3960195-1	0.2	86.5
	- HARDWARE AND CABLE ASSEMBLY	3923102-1	2.0	21.4
34-13- A	HORIZONTAL SITUATION INDICATOR (NET INCREASE) (RQS 22-02-O AUTOPILOT	3900015	14.0*	95.6*
	- GYRO SLAVING METER	071-01242-0006	0.3	16.0
	- FLUX DETECTOR INSTL (IN LH WING)	3940362	0.6	52.6
	- NAV CONVERTER INSTL	3940361	1.3	131.0
	- SLAVED GYRO FOR HSI (IN TAILCONE)	3930363	5.1	136.8
	- GYRO SYSTEM FOR HSI		10.6	1.9

Figure 6-9. Equipment List Description (Sheet 4 of 6)

Nov 15/00 6-21

	ITEM			WT	ARM
	NO	EQUIPMENT LIST DESCRIPTION	REF DRAWING	LBS	INS.
ì		- STD GYRO SYSTEM REMOVED		-13.8	4.5
Ш		- KA 209 NAV INDICATOR REMOVED		-1.2	13.9
П		- WIRING FOR HSI		7.6	58.1
		- HSI INDICATOR	066-03046-0001	3.4	14.1
		37 - VACUUM			
I	37-01-S	DUAL VACUUM SYSTEM, ENGINE DRIVEN	0706009-1	6.2*	-3.4*
		- VACUUM PUMP, AIRBORNE 211CC	E211CC	1.9	-5.0
	1	- VACUUM PUMP, AIRBORNE 212CW	E212CW	1.9	-5.0
J		- COOLING SHROUD, AIRBORNE 2CDH	2CDH-A	0.2	-5.6
		- FILTER INSTALLATION	1201075-2	0.3	12.5
ı		- VACUUM RELIEF VALVE	2H3-45	0.5	2.1
		- MANIFOLD	1H5-25	0.5	-3.0
ı		- VACUUM GAUGE/AMMETER	\$3280-1	0.6	15.6
		53 - FUSELAGE			
	53-01 - S	REFUELING STEPS AND HANDLE INSTL	0701127-1	1.8	15.3
		56 - WINDOWS			
	56-01-S	WINDOW, HINGED RIGHT DOOR	0711050-48	5.8	47.8
	56-02-S	WINDOW, HINGED LEFT DOOR	0711050-47	5.8	47.8
-		61 - PROPELLER			
	61-01-A	PROPELLER ASSEMBLY, 2-BLADE MCCAULEY B2D34C235/90DKB-8	P2357299-02	59.6	-47.4
	61-02-A	SPINNER INSTALLATION, 2-BLADE	D-7267-2	4.4	-49.9
	61-03-R	GOVERNOR, PROPELLER	C161031-0119	2.7	-42.5
į	61 - 04-S	PROPELLER ASSEMBLY, 3-BLADE MCCAULEY B3D36C431/80VSA-1	P4317296-01	76.1	-47.5
	61 - 05-S	SPINNER INSTALLATION, 3-BLADE	D-7261-2	4.5	-49.9
		71 - POWERPLANT			
	71-01-R	FILTER, AIR INTAKE	P198290	0.5	-35.2
ı	71-02-A	WINTER KIT INSTL.	0752733	0.3	-42.0
_		72 - ENGINES			
	72-01-R	ENGINE, LYCOMING IO-540 AB1A5	0750619-1	400.4*	-23.6*
		73 - ENGINE FUEL and CONTROL			
	73-01-R	EGT and CYLINDER HEAD TEMP INDICATOR	S3305-2	0.8	14.5
		77 - ENGINE INDICATING			
	77-01-R	TACHOMETER INSTALLATION, RECORDING	S3329-4	1.0	16.2
	77-02-R	MANIFOLD PRESSURE & FUEL FLOW	S3304-1	1.0	15.0
į	77-03-R	OIL PRESSURE & TEMPERATURE INDICATOR	S3279-1	0.8	14.5

Figure 6-9. Equipment List Description (Sheet 5 of 6)

ITEM NO	EQUIPMENT LIST DESCRIPTION	REF DRAWING	WT LBS	ARM INS.
	78 - EXHAUST			
78-01-R	EXHAUST SYSTEM INSTALLATION	2254003-31,-32	16.8*	-24.2*
	- LEFT EXHAUST SYSTEM	2254003-31	8.4	-24.2
	- RIGHT EXHAUST SYSTEM	2254003-32	8.4	-24.2
	79 - OIL			
79-01 - R	OIL COOLER INSTALLATION, STEWART WARNER	10610R	5.5	-11.4
	98 - MISCELLANEOUS			
98-01-A	AIRCRAFT HOISTING RINGS, SET OF 4	0700612-1	1.5	45.6
98-02-\$	REFUELING STEPS AND HANDLES, SET OF 2	0701127-1	1.8	15.3
98-03-A	RUDDER PEDAL EXTENSIONS, REMOVABLE, SET OF 2 (INSTALLED ARM SHOWN)	0501082-1	2.9	8.0
98-04-A	STABILIZER ABRASION BOOTS, SET OF 2	0500041-3	2.7	206.0
98-05-S	STAINLESS STEEL CONTROL CABLES	0760007-1	0.0	0.0
98-06-A	TAILCONE LIFT HANDLES, SET OF 2	2201009-1	1.0	186.5
98-07-A	TOW HOOK KIT (INSTALLED ARM SHOWN)	0712643-1	0.6*	230.0*
	-TOW HOOK, SCHWEIZER ID-112-15	0500228-2	0.5	232.0
	-NYLON RELEASE CHORD, 18 FEET LONG	0500228-3	0.0	160.0
	AVIONICS PACKAGE OPTIONS			
98-08-R	STANDARD AVIONICS PACKAGE		55.9*	22.1*
	- KX 155A NAV/COM with GLIDE SLOPE	3900006-1	11.4	37.3
1	- KX 155A NAV/COM	3900006-1	8.9	19.0
- 1	- KLN 89 GPS-VFR	3900006-1	5.5	18.8
	- MD 41-230 GPS-NAV SELECTOR			
l)	- KMA 26 AUDIO/INTERCOM/MARKER BEACON INSTALLATION	3930404-1	3.6	41.0
	- KT 76C MODE C TRANSPONDER	3930404-1	4.5	15.2
	- KAP 140 SINGLE AXIS AUTOPILOT	3900007-1	8.4	50.3
	- BASIC AVIONICS KIT INSTL	3900006-1	4.3	55.5
98-09-A	OPTIONAL NAV I AVIONICS PACKAGE (STANDARD AVIONICS PACKAGE PLUS THE FOLLOWING:) (NET CHANGE)		11.1*	135.5*
	- KLN 89B GPS-IFR (EXCHANGE) - GPS-NAV SELECTOR, ANNUNCIATOR	3900006-1 MD41-228	0.0	18.8
	(EXCHANGE) - KR 87 ADF SYSTEM	066-01072-0014	6.4	20.4
	- KAP 140 TWO AXIS AUTOPILOT WITH	3900008-1	4.7	292.2
	ELECTRIC TRIM (EXCHANGE)	55000051	7./	232.2

Figure 6-9. Equipment List Description (Sheet 6 of 6)

16		
7*		
		4.7

SECTION 7 AIRPLANE & SYSTEMS DESCRIPTION

TABLE OF CONTENTS

	Page
Introduction	7-5
Airframe	7-5
Flight Controls	7-6
Trim System	7-6
Instrument Panel	7-6
Pilot Side Panel Layout	7-9
Center Panel Layout	7-9
Copilot Side Panel Layout	7-12
Center Pedestal Layout	7-12
Ground Control	7-12
Wing Flap System	7-13
Landing Gear System	7-14
Baggage Compartment	7-14
Seats	7-14
Integrated Seat Belt/Shoulder Harness	7-15
Entrance Doors And Cabin Windows	7-17
Control Locks	7-18
Engine	7-19
Engine Controls	7-19
Engine Instruments	7-19
New Engine Break-In And Operation	7-21
Engine Lubrication System	7-22
Ignition And Starter System	7-22
Air Induction System	7-23
Exhaust System	7-23
Cooling System	7-23

TABLE OF CONTENTS (Continued)

	Page
Propeller	7-24
Fuel System	7-25
Fuel Distribution	7-25
Fuel Indicating System	7-27
Auxiliary Fuel Pump Operation	7-28
Fuel Venting	7-28
Fuel Selector Valve	7-28
Fuel Drain Valves	7-29
Brake System	7-32
Electrical System	7-32
Annunciator Panel	7-33
Master Switch	7-34
Avionics Master Switch	7-35
Ammeter	7-35
Low Voltage Annunciation	7-36
Circuit Breakers And Fuses	7-36
Ground Service Plug Receptacle	7-37
Lighting Systems	7-38
Exterior Lighting	7-38
Interior Lighting	7-38
Cabin Heating, Ventilating And Defrosting System	7-40
Pitot-Static System And Instruments	7-42
Airspeed Indicator	7-43
Vertical Speed Indicator	7-43
Altimeter	7-44

7-2

TABLE OF CONTENTS (Continued)

	Page
Vacuum System And Instruments	7-44
Attitude Indicator	7-44
Directional Indicator	7-44
Vacuum Gauge	7-46
Low Vacuum Annunciation	7-46
Clock/O.A.T. Indicator	7-47
Stall Warning System	7-47
Standard Avionics	7-48
Avionics Support Equipment	7-49
Avionics Cooling Fan	7-49
Microphone And Headset Installations	7-49
Static Dischargers	7-50
Cabin Features	7-50
Emergency Locator Transmitter	7-50
Cabin Fire Extinguisher	7-51

-

INTRODUCTION

This section provides description and operation of the airplane and its systems. Some equipment described herein is optional and may not be installed in the airplane. Refer to the Supplements, Section 9 for details of other optional systems and equipment.

AIRFRAME

The airplane is an all metal, four-place, high-wing, single-engine airplane equipped with tricycle landing gear and is designed for general utility purposes.

The construction of the fuselage is a conventional formed sheet metal bulkhead, stringer, and skin design referred to as semimonocoque. Major items of structure are the front and rear carry through spars to which the wings are attached, a bulkhead and forgings for main landing gear attachment at the base of the rear door posts, and a bulkhead with attach fittings at the base of the forward door posts for the lower attachment of the wing struts. Four engine mount stringers are also attached to the forward door posts and extend forward to the firewall.

The externally braced wings, containing integral fuel tanks, are constructed of a front and rear spar with formed sheet metal ribs, doublers, and stringers. The entire structure is covered with aluminum skin. The front spars are equipped with wing-to-fuselage and wing-to-strut attach fittings. The aft spars are equipped with wing-to-fuselage attach fittings, and are partial span spars. Conventional hinged ailerons and single slot type flaps are attached to the trailing edge of the wings. The ailerons are constructed of a forward spar containing balance weights, formed sheet metal ribs and "V" type corrugated aluminum skin joined together at the trailing edge. The flaps are constructed basically the same as the ailerons, with the exception of the balance weights and the addition of a formed sheet metal leading edge section.

The empennage (tail assembly) consists of a conventional vertical stabilizer, rudder, horizontal stabilizer, and elevator. The vertical stabilizer consists of a forward and aft spar, formed sheet metal ribs and reinforcements, four skin panels, formed leading edge skins and a dorsal fin.

The rudder is constructed of a forward and aft spar, formed sheet metal ribs and reinforcements, and a wrap-around skin panel. The top of the rudder incorporates a leading edge extension which contains a balance weight.

Nov 15/00 7-5

The horizontal stabilizer is constructed of a forward and aft spar, ribs and stiffeners, center upper and lower skin panels and two, left and two right wrap-around skin panels which also form the leading edges. The horizontal stabilizer also contains the elevator trim tab actuator.

Construction of the elevator consists of formed leading edge skins, a forward spar, ribs, torque tube and bellcrank, left upper and lower "V" type corrugated skins, and right upper and lower "V" type corrugated skins incorporating a trailing edge cut-out for the trim tab. Both elevator tip leading edge extensions incorporate balance weights.

FLIGHT CONTROLS

The airplane's flight control system (Refer to Figure 7-1) consists of conventional aileron, rudder, and elevator control surfaces. The control surfaces are manually operated through mechanical linkage using a control wheel for the ailerons and elevator, and rudder/brake pedals for the rudder. The elevator control system is equipped with downsprings which provide improved stability in flight.

TRIM SYSTEMS

A manually-operated rudder and elevator trim is provided (refer to Figure 7-1). Rudder trimming is accomplished through a bungee connected to the rudder control system and a trim control wheel mounted on the control pedestal. Rudder trimming is accomplished by rotating the horizontally mounted trim control wheel either left or right to the desired trim position. Rotating the trim wheel to the right will trim nose-right; conversely, rotating it to the left will trim nose-left. Elevator trimming is accomplished through the elevator trim tab by utilizing the vertically mounted trim control wheel. Forward rotation of the trim wheel will trim nose-down, conversely, aft rotation will trim nose-up.

INSTRUMENT PANEL

The instrument panel (Refer to Figure 7-2) is of all-metal construction, and is designed in segments to allow related groups of instruments, switches and controls to be removed without removing the entire panel. For specific details concerning the instruments, switches, circuit breakers, and controls on the instrument panel, refer to related topics in this section.




Figure 7-1. Flight Control and Trim Systems (Sheet 1 of 2)




Figure 7-1. Flight Control and Trim Systems (Sheet 2 of 2)

PILOT SIDE PANEL LAYOUT

Flight instruments are contained in a single panel located in front of the pilot. These instruments are designed around the basic "T" configuration. The gyros are located immediately in front of the pilot, and arranged vertically over the control column. The airspeed indicator and altimeter are located to the left and right of the gyros, respectively. The remainder of the flight instruments are clustered around the basic "T".

To the right of the flight instruments is a sub panel which contains engine tachometer and various navigational instruments. To the left of the flight instruments is a sub panel which contains a fuel quantity indicator, an oil temperature/oil pressure indicator, a vacuum gauge/ammeter, an EGT/CHT indicator, a clock/OAT indicator and manifold pressure gauge/fuel flow indicator.


Below the engine and flight instruments are the circuit breakers and switches used throughout the airplane. MASTER, AVIONICS MASTER, the ignition switches and lighting controls are located in this area of the panel.

CENTER PANEL LAYOUT

The center panel contains various avionics equipment arranged in a vertical rack. This arrangement allows each component to be removed without having to access the backside of the panel. Below the panel are the throttle, prop RPM, mixture, alternate static air.

A multi-function annunciator is located above the radio stack and provides caution and warning messages for fuel quantity, oil pressure, low vacuum and low voltage situations.

Nov 15/00 7-9



0585C1015

Figure 7-2. Instrument Panel (Sheet 1 of 2)

SECTION 7 AIRPLANE & SYSTEMS DESCRIPTION

1.	Oil Temperature and Oil Pressure Indicator	23.	Hour Meter
2.	Vacuum Gauge/Ammeter	24.	Glove Box
3.	Fuel Quantity Indicators	25.	Cabin Heat Control
4.	EGT/CHT Indicator	26.	Cabin Air Control
5.	Digital Clock/OAT Indicator	27.	Flap Switch and Indicator
6.	Turn Coordinator	28.	Mixture Control
7.	Airspeed Indicator	29.	Alternate Static Air Control
8.	Directional Gyro	30.	Throttle Control
9.	Attitude Indicator	31.	Radio and Panel Dimming Control
10.	Tachometer	32.	Glareshield and Pedestal Dimming Control
11.	Vertical Speed Indicator	33.	Fuel Selector
12.	Altimeter	34.	Elevator Trim and Indicator
13.	Annunciator Panel	35.	Avionics Master Switch
14.	ADF Bearing Indicator	36.	Circuit Breakers and Switch/Breakers
15.	Course Deviation and Glide Slope Indicators	37.	Master Switch
16.	Audio Control Panel	38.	Ignition Switch
17.	GPS Receiver	39.	Avionics Circuit Breaker Panel
18.	Nav/Com Radio #1	40.	Propeller Control
19.	Nav/Com Radio #2	41.	Rudder Trim
20.	ADF Receiver	42.	Cowl Flap Control
21.	Transponder	43.	Defrost Control
22.	ELT Remote Test Button	44.	Manifold Pressure/Fuel Flow Indicator

Figure 7-2. Instrument Panel (Sheet 2 of 2)

Nov 15/00 7-11

COPILOT SIDE PANEL LAYOUT

The copilot sub panel contains the hour meter, ELT switch, and room for expansion of indicators and other avionics equipment. Below this sub panel are the glove box, cabin heat, defroster and cabin air controls, and wing flap lever.

CENTER PEDESTAL LAYOUT

The center pedestal, located below the center panel, contains the elevator and rudder trim control wheels and position indicators, and provides a bracket for the microphone. The fuel selector valve handle is located at the base of the pedestal. A parking brake handle is mounted below the switch and control panel in front of the pilot.

GROUND CONTROL

Effective ground control while taxiing is accomplished through nose wheel steering by using the rudder pedals; left rudder pedal to steer left and right rudder pedal to steer right. When a rudder pedal is depressed, a spring loaded steering bungee (which is connected to the nose gear and to the rudder bars) will turn the nose wheel through an arc of approximately 11° each side of center. By applying either left or right brake, the degree of turn may be increased up to 29° each side of center.

Moving the airplane by hand is most easily accomplished by attaching a tow bar to the nose gear strut. If a tow bar is not available, or pushing is required, use the wing struts as push points. Do not use the vertical or horizontal surfaces to move the airplane. If the airplane is to be towed by vehicle, never turn the nose wheel more than 29° either side of center or structural damage to the nose gear could result.

The minimum turning radius of the airplane, using differential braking and nose wheel steering during taxi, is approximately 27 feet. To obtain a minimum radius turn during ground handling, the airplane may be rotated around either main landing gear by pressing down on a tailcone bulkhead just forward of the horizontal stabilizer to raise the nose wheel off the ground. Care should be exercised to ensure that pressure is exerted only on the bulkhead area and not on skin between the bulkheads.

WING FLAP SYSTEM

The single slot-type wing flaps (Refer to Figure 7-3), are extended or retracted by positioning the wing flap switch lever on the instrument panel to the desired flap deflection position. The switch lever is moved up or down in a slotted panel that provides mechanical stops at the 10° and 20° positions. To change flap setting, the flap lever is moved to the right to clear mechanical stops at the 10° and 20° positions. A scale and pointer to the left of the flap switch indicates flap travel in degrees. The wing flap system circuit is protected by a 10-ampere circuit breaker, labeled FLAP, on the left side of the control panel.




Figure 7-3. Wing Flap System

LANDING GEAR SYSTEM

The landing gear is of the tricycle type, with a steerable nose wheel and two main wheels. Wheel fairings are optional for both the main and nose wheels. Shock absorption is provided by the tubular spring steel main landing gear struts and the air/oil nose gear shock strut. Each main gear wheel is equipped with a hydraulically-actuated disc type brake on the inboard side of each wheel.

BAGGAGE COMPARTMENT

The baggage compartment consists of the area from the back of the rear passenger seats to the aft cabin bulkhead. Access to the baggage compartment is gained through a lockable baggage door on the left side of the airplane, or from within the airplane cabin. A baggage net with tiedown straps is provided for securing baggage and is attached by tying the straps to tiedown rings provided in the airplane. For baggage area and door dimensions, refer to Section 6.

SEATS

The seating arrangement consists of two vertically adjusting crew seats for the pilot and front seat passenger, and an infinitely adjustable split back bench seat for rear seat passengers.

Seats used for the pilot and front seat passenger are adjustable fore and aft, and up and down. Additionally, the angle of the seat back is infinitely adjustable.

Fore and aft adjustment is made using the handle located below the center of the seat frame. To position the seat, lift the handle, slide the seat into position, release the handle and check that the seat is locked in place. To adjust the height of the seat, rotate the large crank under the right hand corner of the seat until a comfortable height is obtained. To adjust the seat back angle, pull up on the release button, located in center front of seat, just under the seat bottom, position the seat back to the desired angle, and release the button. When the seat is not occupied, the seat back will automatically fold forward whenever the release button is pulled up.

The rear passenger seat consists of a fixed, one-piece seat bottom and an infinitely-adjustable split back. Seat back controls are located beneath each seat bottom and provide adjustment for each seat back. To adjust the seat back, raise the lever, position the seat back to the desired angle, release the lever and check that the back is locked in place.

Headrests are installed on both the front and rear seats. To adjust the headrest, apply enough pressure to it to raise or lower it to the desired level.

INTEGRATED SEAT BELT/SHOULDER HARNESS

All seat positions are equipped with integrated seat belts/shoulder harness assemblies (Refer to Figure 7-4). The design incorporates an overhead inertia reel for the shoulder portion, and a retractor assembly for the lap portion of the belt. This design allows for complete freedom of movement of the upper torso area while providing restraint in the lap belt area. In the event of a sudden deceleration, reels lock up to provide positive restraint for the user.

In the front seats, the inertia reels are located on the centerline of the upper cabin area. In the rear seats, the inertia reels are located outboard of each passenger in the upper cabin.

To use the integrated seat belt/shoulder harness, grasp the link with one hand, and, in a single motion, extend the assembly and insert into the buckle. Positive locking has occurred when a distinctive "snap" sound is heard.

Proper locking of the lap belt can be verified by ensuring that the belts are allowed to retract into the retractors and the lap belt is snug and low on the waist as worn normally during flight. No more than one additional inch of belt should be able to be pulled out of the retractor once the lap belt is in place on the occupant. If more than one additional inch of belt can be pulled out of the retractor, the occupant is too small for the installed restraint system and the seat should not be occupied until the occupant is properly restrained.

Removal is accomplished by lifting the release mechanism on the buckle or by pressing the release button on the buckle and pulling out and up on the harness. Spring tension on the inertia reel will automatically stow the harness.

Nov 15/00 7-15




Figure 7-4. Crew Seats, Seat Belts and Shoulder Harnesses

A manually adustable seat belt/shoulder harness assembly is available for all seats.

To use the manually adjustable seat belt/shoulder harness, fasten and adjust the seat belt/shoulder harness first. Lengthen the seat belt as required by pulling on the release strap on the belt. Snap the connecting link firmly into the buckle, then adjust to length. A properly adjusted harness will permit the occupant to lean forward enough to sit erect, but prevent excessive forward movement and contact with objects during sudden deceleration. Also, the pilot must have the freedom to reach all controls easily.

Disconnecting the manually adjustable seat belt/shoulder harness is accomplished by pushing the button on the buckle to release the connecting link.

ENTRANCE DOORS AND CABIN WINDOWS

Entry to, and exit from the airplane is accomplished through either of two entry doors, one on each side of the cabin at the front seat positions (refer to Section 6 for cabin and cabin door dimensions). The doors incorporate a recessed exterior door handle, a conventional interior door handle, a key operated door lock (left door only), a door stop mechanism, and openable windows in both the left and right doors.

NOTE

The door latch design on this model requires that the outside door handle on the pilot and front passenger doors be extended out whenever the doors are open. When closing the door, do not attempt to push the door handle in until the door is fully shut.

To open the doors from outside the airplane, utilize the recessed door handle near the aft edge of either door by grasping the forward edge of the handle and pulling outboard. To close or open the doors from inside the airplane, use the combination door handle and arm rest. The inside door handle has three positions and a placard at its base which reads OPEN, CLOSE, and LOCK. The handle is spring loaded to the CLOSE (up) position. When the door has been pulled shut and latched, lock it by rotating the door handle forward to the LOCK position (flush with the arm rest). When the handle is rotated to the LOCK position, an over center action will hold it in that position. Both cabin doors should be locked prior to flight, and should not be opened intentionally during flight.

NOTE

Accidental opening of a cabin door in flight due to improper closing does not constitute a need to land the airplane. The best procedure is to set up the airplane in a trimmed condition at approximately 80 KIAS, momentarily shove the door outward slightly, and forcefully close and lock the door.

Exit from the airplane is accomplished by rotating the door handle from the LOCK position, past the CLOSE position, aft to the OPEN position and pushing the door open. To lock the airplane, lock the right cabin door with the inside handle, close the left cabin door, and using the ignition key, lock the door.

The left and right cabin doors are equipped with openable windows which are held in the closed position by a detent equipped latch on the lower edge of the window frame. To open the windows, rotate the latch upward. Each window is equipped with a spring-loaded retaining arm which will help rotate the window outward, and hold it there. If required, either window may be opened at any speed up to 175 KIAS. The rear side windows and rear windows are of the fixed type and cannot be opened.

CONTROL LOCKS

A control lock is provided to lock the aileron and elevator control surfaces to prevent damage to these systems by wind buffeting while the airplane is parked. The lock consists of a shaped steel rod and flag. The flag identifies the control lock and cautions about its removal before starting the engine. To install the control lock, align the hole in the top of the pilot's control wheel shaft with the hole in the top of the shaft collar on the instrument panel and insert the rod into the aligned holes. Installation of the lock will secure the ailerons in a neutral position and the elevators in a slightly trailing edge down position. Proper installation of the lock will place the flag over the ignition switch. In areas where high or gusty winds occur, a control surface lock should be installed over the vertical stabilizer and rudder. The control lock and any other type of locking device should be removed prior to starting the engine.

ENGINE

The airplane is powered by a horizontally opposed, six cylinder, overhead valve, air cooled, fuel injected engine with a wet sump lubrication system. The engine is a Lycoming Model IO-540-AB1A5 and is rated at 230 horsepower at 2400 RPM. Major accessories include a starter and belt driven alternator mounted on the front of the engine, and dual magnetos, dual vacuum pumps, and a full flow oil filter mounted on the rear of the engine accessory case.

ENGINE CONTROLS

Engine manifold pressure is controlled by a throttle located on the switch and control panel. The throttle is open in the forward position and closed in the full aft position. A friction lock, which is a round knurled knob, is located at the base of the throttle and is operated by rotating the lock clockwise to increase friction or counterclockwise to decrease it.

Engine speed is controlled by the propeller control. This system is described under "Propeller" in this section.

The mixture control, mounted near the propeller control, is a red knob with raised points around the circumference and is equipped with a lock button in the end of the knob. The rich position is full forward, and full aft is the idle cutoff position. For small adjustments, the control may be moved forward by rotating the knob clockwise, and aft by rotating the knob counterclockwise. For rapid or large adjustments, the knob may be moved forward or aft by depressing the lock button in the end of the control, and then positioning the control as desired.

ENGINE INSTRUMENTS

Engine operation is monitored by the following instruments: oil pressure indicator, oil temperature indicator, tachometer, cylinder head temperature indicator (CHT), exhaust gas temperature indicator (EGT), and manifold pressure gauge and fuel flow indicator.

The oil pressure/oil temperature indicator unit is located on the lower left side of the instrument panel. Markings for the pressure gauge indicate a minimum idling pressure of 20 PSI (red line), a normal operating range of 50 to 90 PSI (green arc), and a maximum pressure of 115 PSI (red line). Markings for the oil temperature gauge indicated a normal operating range of 100 to 245°F (green arc), and a maximum temperature of 245°F (red line).

Oil pressure signals are generated from a pressure line/transducer combination. An oil pressure line is routed from the upper front of the engine case to the rear engine baffle. At the baffle, the oil pressure line is connected to a transducer. This transducer produces an electrical signal which translates into a pressure reading at the instrument panel gauge.

Oil temperature signals are generated from a resistance-type probe located in the accessory case. As oil temperature changes, the probe resistance changes. This resistance is translated into oil temperature readings on the cockpit indicator.

In addition, a separate low oil pressure indication is provided through the panel annunciator. This annunciator is wired to a pressure switch located on the rear of the engine accessory case. When oil pressure is below 20 PSI, the switch grounds and completes the annunciator circuit, illuminating the red OIL PRESS light. When pressure exceeds 20 PSI, the ground is removed and the OIL PRESS light extinguishes.

NOTE

The low oil pressure switch is also wired into the Hobbs (hour) meter. When pressure exceeds 20 PSI, a ground is supplied to the hour meter, completing the hour meter circuit.

The EGT/CHT indicator, located on the left side of the instrument panel, is activated by electrical signals originating in the engine compartment. Markings for the exhaust gas temperature portion of the indicator are in 25°F increments, with no range markings or red lines. Marking for the cylinder head temperature portion of the indicator are in 50°F increments, with numbers at 200°F, 300°F, 400°F and 500°F. Normal operating temperatures (green arc) for the CHT indicator are 200°F to 500°F, with red line at 500°F.

EGT signals are generated from a thermocouple probe in the exhaust system. This probe allows a small amount of current to flow through it, and as temperature across the probe changes, so does current flow. This change in current flow registers on the indicator as a change in temperature. Although the EGT gauge contains no red lines or operating range marks, it is useful in establishing peak EGT and cruise EGT reference points for leaning the mixture.

CHT signals are generated from a thermistor probe screwed into the cylinder head of the number 1 (right hand forward) cylinder. The resistance of the probe changes in proportion to the temperature, and is registered on the indicator as a change in temperature.

The engine-driven mechanical tachometer is located on the right side of the pilot's instrument panel. The instrument is marked in increments of 100 RPM, and indicates both engine and propeller speed. An hour meter in the lower section of the dial records elapsed engine time in hours and tenths. Instrument markings include the normal operating range (green arc) of 2000 to 2400 RPM, and a maximum (red line) of 2400 RPM.

The manifold pressure gauge is part of the manifold pressure gauge/fuel flow indicator located on the left side of the pilot's instrument panel. The gauge is direct reading and indicates induction air manifold pressure in inches of mercury. It has a normal operating range (green arc) of 15 to 23 In. Hg. The fuel flow. indicator is a fuel pressure indicator calibrated in flow rate. The fuel pressure is taken at the flow divider valve by a pressure transducer. The pressure transducer receives a constant voltage from the indicator and returns a variable voltage depending on the pressure, as pressure increases, voltage increases. The indicator is marked in gallons per hour and has a green arc from 0 to 15 gal./hr. There is no red line or maximum fuel flow (pressure) limitation. There may be some atmospheric conditions that would result in fuel flow rates that exceed the maximum marked value on the indicator (i.e., very low density altitude and full throttle). If the indicator is pegged out because of these conditions, the indicator will not be damaged, and will return to operating range when the throttle is retarded to cruise power settings.

NEW ENGINE BREAK-IN AND OPERATION

The engine underwent a run in at the factory and is ready for the full range of use. It is, however, suggested that cruising be accomplished at 75% power as much as practicable until a total of 50 hours has accumulated or oil consumption has stabilized. This will ensure proper seating of the rings.

ENGINE LUBRICATION SYSTEM

The engine utilizes a full-pressure, wet sump-type lubrication system with aviation grade oil as the lubricant. The capacity of the engine sump (located on the bottom of the engine) is nine quarts (one additional quart is contained in the engine oil filter). Oil is drawn from the sump through a filter screen on the end of a pickup tube to the engine-driven oil pump. Oil from the pump passes through a full-flow oil filter, a pressure relief valve at the rear of the right oil gallery, and a thermostatically controlled remote oil cooler. Oil from the remote cooler is then circulated to the left oil gallery and propeller governor. The engine parts are then lubricated by oil from the galleries. After lubricating the engine, the oil returns to the sump by gravity. The filter adapter in the full flow filter is equipped with a bypass valve which will cause lubricating oil to bypass the filter in the event the filter becomes plugged, or the oil temperature is extremely cold.

An oil dipstick/filler tube is located on the upper left side of the engine case. The dipstick and oil filler tube are accessed through a door located on the left center portion of the upper engine cowling. The engine should not be operated on less than four quarts of oil. To minimize loss of oil through the breather, fill to eight quarts for normal flights of less than three hours. For extended flight, fill to nine quarts (dipstick indication only). For engine oil grade and specifications, refer to Section 8 of this handbook.

IGNITION AND STARTER SYSTEM

Engine ignition is provided by two engine driven magnetos, and two spark plugs in each cylinder. The right magneto fires the lower right and upper left spark plugs, and the left magneto fires the lower left and upper right spark plugs. Normal operation is conducted with both magnetos due to the more complete burning of the fuel/air mixture with dual ignition.

Ignition and starter operation is controlled by a rotary type switch located on the left switch and control panel. The switch is labeled clockwise, OFF, R, L, BOTH, and START. The engine should be operated on both magnetos (BOTH position) except for magneto checks. The R and L positions are for checking purposes and emergency use only. When the switch is rotated to the spring loaded START position, (with the master switch in the ON position), the starter contactor is energized and the starter will crank the engine. When the switch is released, it will automatically return to the BOTH position.

AIR INDUCTION SYSTEM

The engine air induction system receives ram air through an intake on the lower front portion of the engine cowling. The intake is covered by an air filter which removes dust and other foreign matter from the induction air. Airflow passing through the filter enters an air box. The air box has two spring-loaded alternate air doors. If the air induction filter should become blocked, suction created by the engine will open the door and draw unfiltered air from inside the lower cowl area. An open alternate air door will result in an approximate 10% power loss at full throttle. After passing through the air box, induction air enters a fuel/air control unit under the engine, and is then ducted to the engine cylinders through intake manifold tubes.

EXHAUST SYSTEM

Exhaust gas from each cylinder passes through riser assemblies to a muffler and tailpipe. Outside air is pulled in around shrouds which are constructed around the outside of the mufflers to form heating chambers which supply heat to the cabin.

COOLING SYSTEM

Ram air for engine cooling enters through two intake openings in the front of the engine cowling. The cooling air is directed around the cylinders and other areas of the engine by baffling, and is then exhausted through an opening at the bottom aft edge of the cowling. The cowl flaps are mechanically operated from the cabin by means of the cowl flap control on the right side of the control pedestal.

The pedestal is labeled OPEN, COWL FLAPS, CLOSED. Before starting the engine, takeoff and high power operation, the cowl flap control should be placed in the OPEN position for maximum cooling. This is accomplished by moving the control to the right to clear a detent, then moving the control up to the OPEN position. Anytime the control is repositioned, it must first be moved to the right. While in cruise flight, cowl flaps should be closed unless hot day conditions require them to be adjusted to keep the cylinder head temperature at approximately two-thirds of the normal operating range (green arc). During extended let-downs, it may be necessary to completely close the cowl flaps by pushing the cowl flap control down to the CLOSED position.

A winterization kit is available for the airplane. Details of this kit are presented in Section 9, Supplements.

PROPELLER

The airplane has an all-metal, three-bladed, constant-speed, governor-regulated propeller. A two-bladed propeller is also available. A setting introduced into the governor with the propeller control establishes the propeller speed, and thus the engine speed to be maintained. The governor then controls flow of engine oil, boosted to high pressure by the governing pump, to or from a piston in the propeller hub. Oil pressure acting on the piston twists the blades toward high pitch (low RPM). When oil pressure to the piston in the propeller hub is relieved, centrifugal force, assisted by an internal spring, twists the blades toward low pitch (high RPM).

A control knob on the center area of the switch and control panel is used to set the propeller and control engine RPM as desired for various flight conditions. The knob is labeled PROPELLER, PUSH INCR RPM. When the control knob is pushed in, blade pitch will decrease, giving a higher RPM. When the control knob is pulled out, the blade pitch increases, thereby decreasing RPM. The propeller control knob is equipped with a vernier feature which allows slow or fine RPM adjustments by rotating the knob clockwise to increase RPM, and counterclockwise to decrease it. To make rapid or large adjustments, depress the button on the end of the control knob and reposition the control as desired.

FUEL SYSTEM

The airplane fuel system (see Figure 7-6) consists of two vented integral fuel tanks (one tank in each wing), a four-position selector valve, fuel strainer, auxiliary fuel pump, engine-driven fuel pump, a fuel/air control unit, a flow divider, fuel distribution valve and fuel injection nozzles.

WARNING

UNUSABLE FUEL LEVELS FOR THIS AIRPLANE WERE DETERMINED IN ACCORDANCE WITH FEDERAL AVIATION REGULATIONS. FAILURE TO OPERATE THE AIRPLANE IN COMPLIANCE WITH FUEL LIMITATIONS SPECIFIED IN SECTION 2 MAY FURTHER REDUCE THE AMOUNT OF FUEL AVAILABLE IN FLIGHT.

FUEL TANKS	FUEL LEVEL (QUANTITY EACH TANK)	TOTAL FUEL	TOTAL UNUSABLE	TOTAL USABLE ALL FLIGHT CONDITIONS
Two	Full (46.0)	92.0	4.0	88.0
Two	Reduced (34.5)	69.0	4.0	65.0

Figure 7-5. Fuel Quantity Data in U.S. Gallons

FUEL DISTRIBUTION

Fuel flows by gravity from the two wing tanks to a four position selector valve (with integral strainer), labeled BOTH, RIGHT, LEFT and OFF. The selector handle must be pushed down before it can be rotated from RIGHT or LEFT to OFF. From the selector, fuel flows through the fuel strainer, through the auxiliary fuel pump, and to an engine driven fuel pump.




Figure 7-6. Fuel System Schematic

From the engine-driven fuel pump, fuel is delivered to the fuel/air control unit on the bottom of the engine. The fuel/air control unit meters fuel flow in proportion to induction air flow. After passing through the control unit, induction air is delivered to the cylinders (through intake manifold tubes), and metered fuel is delivered to a flow divider located on top of the engine. From the flow divider, individual fuel lines are routed to air bleed type injector nozzles located in the intake chamber of each cylinder.

FUEL INDICATING SYSTEM

Fuel quantity is measured by two float-type fuel quantity transmitters (one in each tank) and indicated by an electrically-operated fuel quantity indicator on the left side of the instrument panel. The gauges are marked for both gallons and pounds of fuel, using 6.0 pounds-per-gallon for conversion. An empty tank is indicated by a red line and the number 0. When an indicator shows an empty tank, approximately 2 gallons remain in a tank as unusable fuel. The indicators should not be relied upon for accurate readings during skids, slips, or unusual attitudes.

Each fuel tank also incorporates warning circuits which can detect low fuel conditions and erroneous transmitter messages. Anytime fuel in the tank drops below approximately 8 gallons (and remains below this level for more than 60 seconds), the amber LOW FUEL message will flash on the annunciator panel for approximately 10 seconds and then remain steady amber. The annunciator cannot be turned off by the pilot. If the left tank is low, the message will read L LOW FUEL. If the right tank is low, the message will read LOW FUEL R. If both tanks are low, the message will read L LOW FUEL R.

In addition to low fuel annunciation, the warning circuitry is designed to report failures with each transmitter caused by shorts, opens or transmitter resistance which increases over time. If the circuitry detects any one of these conditions, the fuel level indicator needle will go to the OFF position (below the 0 mark on the fuel gauge), and the amber annunciator will illuminate. If the left tank transmitter has failed, the message will read L LOW FUEL. If the right tank transmitter has failed, the message will read LOW FUEL R. If both tanks transmitters have failed, the message will read L LOW FUEL R.

Nov 15/00

Fuel pressure is measured by use of a transducer mounted near the fuel manifold. This transducer produces an electrical signal which is translated in the cockpit-mounted indicator as gallons-perhour. Normal operating (green arc) range is from 0 to 15 gallonsper-hour.

AUXILIARY FUEL PUMP OPERATION

The auxiliary fuel pump is used primarily for priming the engine before starting. Priming is accomplished through the regular injection system. If the auxiliary fuel pump switch is accidentally placed in the ON position for prolonged periods (with master switch turned on and mixture rich) with the engine stopped, the intake manifolds will be flooded.

The auxiliary fuel pump is also used for vapor suppression in hot weather. Normally, momentary use will be sufficient for vapor suppression; however, continuous operation is permissible if required. Turning on the auxiliary fuel pump with a normally operating engine pump will result in only a very minor enrichment of the mixture.

It is not necessary to have the auxiliary fuel pump operating during normal takeoff and landing, since gravity and the engine-driven pump will supply adequate fuel flow to the fuel injector unit. In the event of failure of the engine-driven fuel pump, use of the auxiliary fuel pump will provide sufficient fuel to maintain flight at maximum continuous power.

FUEL VENTING

Fuel system venting is essential to system operation. Blockage of the venting system will result in decreasing fuel flow and eventual engine stoppage. Venting is accomplished by an interconnecting line from the right fuel tank to the left fuel tank, and check valve equipped overboard vents in each tank. The overboard vents protrude from the bottom surfaces of the wings behind the wing struts, slightly below the upper attach points of the struts. The fuel filler caps are vacuum vented; the vents will open and allow air to enter the fuel tanks in case the overboard vents become blocked.

FUEL SELECTOR VALVE

The fuel selector valve should be in the BOTH position for takeoff, climb, landing, and maneuvers that involve prolonged slips or skids of more than 30 seconds. Operation from either LEFT or RIGHT tank is reserved for cruising flight.

NOTE

When the fuel selector valve handle is in the BOTH position in cruising flight, unequal fuel flow from each tank may occur if the wings are not maintained exactly level. Resulting wing heaviness can be alleviated gradually by turning the selector valve handle to the tank in the "heavy" wing.

NOTE

It is not practical to measure the time required to consume all of the fuel in one tank, and, after switching to the opposite tank, expect an equal duration from the remaining fuel. The airspace in both fuel tanks is interconnected by a vent line and, therefore, some sloshing of fuel between tanks can be expected when the tanks are nearly full and the wings are not level.

NOTE

Unusable fuel is at a minimum due to the design of the fuel system. However, with 1/4 tank or less, prolonged uncoordinated flight such as slips or skids can uncover the fuel tank outlets causing fuel starvation and engine stoppage. Therefore, with low fuel reserves, do not allow the airplane to remain in uncoordinated flight for periods in excess of one minute.

FUEL DRAIN VALVES

The fuel system is equipped with drain valves to provide a means for the examination of fuel in the system for contamination and grade. The system should be examined before each flight and after each refueling, by using the sampler cup provided to drain fuel from each wing tank sump, the fuel reservoir sump, the fuel selector drain and the fuel strainer sump. If any evidence of fuel contamination is found, it must be eliminated in accordance with the Preflight Inspection checklist and the discussion in Section 8 of this publication. If takeoff weight limitations for the next flight permit, the fuel tanks should be filled after each flight to prevent condensation.

June 13/97 7-29




Figure 7-7. Electrical Schematic (Sheet 1 of 2)




Figure 7-7. Electrical Schematic (Sheet 2 of 2)

BRAKE SYSTEM

■ The airplane has a single-disc, hydraulically-actuated brake on each main landing gear wheel. Each brake is connected, by a hydraulic line, to a master cylinder attached to each of the pilot's rudder pedals. The brakes are operated by applying pressure to the top of either the left (pilot's) or right (copilot's) set of rudder pedals, which are interconnected. When the airplane is parked, both main wheel brakes may be set by utilizing the parking brake which is operated by a handle under the left side of the instrument panel. To apply the parking brake, set the brakes with the rudder pedals, pull the handle aft, and rotate it 90° down.

For maximum brake life, keep the brake system properly maintained, and minimize brake usage during taxi operations and landings.

Some of the symptoms of impending brake failure are: gradual decrease in braking action after brake application, noisy or dragging brakes, soft or spongy pedals, and excessive travel and weak braking action. If any of these symptoms appear, the brake system is in need of immediate attention. If, during taxi or landing roll, braking action decreases, let up on the pedals and then reapply the brakes with heavy pressure. If the brakes become spongy or pedal travel increases, pumping the pedals should build braking pressure. If one brake becomes weak or fails, use the other brake sparingly while using opposite rudder, as required, to offset the good brake.

ELECTRICAL SYSTEM

The airplane is equipped with a 28-volt, direct current electrical system (Refer to Figure 7-7). The system is powered by a belt-driven, 60-amp alternator and a 24-volt battery, located in the tailcone area, aft of the baggage compartment. Power is supplied to most general electrical circuits through a split primary bus bar, with an essential bus wired between the two primaries to provide power for the master switch, annunciator circuits and interior lighting.

Each primary bus bar is also connected to an avionics bus bar via a single avionics master switch. The primary buses are on anytime the master switch is turned on, and are not affected by starter or external power usage. The avionics buses are on when the master switch and avionics master switch are in the ON position.

A CAUTION

PRIOR TO TURNING THE MASTER SWITCH ON OR OFF, STARTING THE ENGINE OR APPLYING AN EXTERNAL POWER SOURCE, THE AVIONICS MASTER SWITCH, LABELED AVIONICS MASTER, SHOULD BE TURNED OFF THE PREVENT ANY HARMFUL TRANSIENT VOLTAGE FROM DAMAGING THE AVIONICS EQUIPMENT.

The airplane uses a power distribution module (J-Box), located on the left forward side of the firewall, to house all relays used throughout the airplane electrical system. In addition, the alternator control unit and the external power connector are housed within the module.

ANNUNCIATOR PANEL

An annunciator panel (with integral toggle switch) is located above the avionics stack and provides caution (amber) and warning (red) messages for selected portions of the airplane systems. The annunciator is designed to flash messages for approximately 10 seconds to gain the attention of the pilot before changing to steady on. The annunciator panel cannot be turned off by the pilot.

Inputs to annunciator come from each fuel transmitter, the oil temperature transducer, low oil pressure switch, the vacuum transducers and the alternator control unit (ACU). Individual LED bulbs illuminate each message and may be replaced through the rear of the annunciator. Illumination intensity can be controlled by placing the toggle switch to either the DIM or DAY position.

The annunciator panel can be tested by turning the Master Switch On and holding the annunciator panel switch in the TST position. All amber and red messages will flash until the switch is released.

NOTE

When the Master Switch is turned ON, some annunciators will flash for approximately 10 seconds before illuminating steadily. When the TST switch is toggled up and held in TST position, all remaining lights will flash until the switch is released.

MASTER SWITCH

The master switch is a split rocker-type switch labeled MASTER, and is ON in the up position and off in the down position. The right half of the switch, labeled BAT, controls all electrical power to the airplane. The left half, labeled ALT, controls the alternator.

A CAUTION

PRIOR TO TURNING THE MASTER SWITCH ON OR OFF, STARTING THE ENGINE OR APPLYING AN EXTERNAL POWER SOURCE, THE AVIONICS MASTER SWITCH, LABELED AVIONICS MASTER, SHOULD BE TURNED OFF TO PREVENT ANY HARMFUL TRANSIENT VOLTAGE FROM DAMAGING THE AVIONICS EQUIPMENT.

Normally, both sides of the master switch should be used simultaneously; however, the BAT side of the switch could be turned on separately to check equipment while on the ground. To check or use avionics equipment or radios while on the ground, the avionics power switch must also be turned on. The ALT side of the switch, when placed in the off position, removes the alternator from the electrical system. With this switch in the off position, the entire electrical load is placed on the battery. Continued operation with the alternator switch in the off position will reduce battery power low enough to open the battery contactor, remove power from the alternator field, and prevent alternator restart.

AVIONICS MASTER SWITCH

Electrical power for Avionics Bus 1 and Avionics Bus 2 is supplied through Primary Bus 1 and Primary Bus 2, respectively. A rocker switch, located between the primary and avionics buses, controls current flow to the avionics buses. Placing the rocker switch in the up (ON) position supplies power to both buses simultaneously. Placing the switch in the down (OFF) position removes power from both buses. The switch is located on the lower left side of the instrument panel.

NOTE

On some aircraft certified outside the United States, the avionics master switch may be split. They are aligned for independent operation of the buses.

With the switch in the off position, no electrical power will be applied to the avionics equipment, regardless of the position of the master switch or the individual equipment switches. The avionics master switch should be placed in the OFF position prior to turning the master switch on or off, starting the engine, or applying an external power source.

Each avionics bus also incorporates a separate circuit breaker installed between the primary bus and the avionics master switch. In the event of an electrical malfunction, this breaker will trip and take the effected avionics bus off-line.

AMMETER

The ammeter/vacuum gauge is located on the lower left side of the instrument panel. It indicates the amount of current, in amperes, from the alternator to the battery or from the battery to the airplane electrical system. When the engine is operating and the master switch is turned on, the ammeter indicates the charging rate applied to the battery. In the event the alternator is not functioning or the electrical load exceeds the output of the alternator, the ammeter indicates the battery discharge rate.

Dec 1/97 7-35

LOW VOLTAGE ANNUNCIATION

The low voltage warning light is incorporated in the annunciator panel and activates anytime voltage falls below 24.5 volts. If low voltage is detected, the red annunciation VOLTS will flash for approximately 10 seconds before illuminating steadily. The pilot cannot turn off the annunciator.

In the event an overvoltage condition occurs, the alternator control unit automatically pops the ALT FLD circuit breaker, removing alternator field current and shutting down the alternator. The battery will then supply system current as shown by a discharge rate on the ammeter. Under these conditions, depending on electrical system load, the low voltage warning annunciator will illuminate when system voltage drops below normal. The alternator control unit may be reset by resetting the circuit breaker. If the warning light extinguishes, normal alternator charging has resumed; however, if the light illuminates again, a malfunction has occurred, and the flight should be terminated as soon as practicable.

NOTE

Illumination of the low voltage light and ammeter discharge indications may occur during low RPM conditions with an electrical load on the system, such as during a low RPM taxi. Under these conditions, the light will go out at higher RPM.

CIRCUIT BREAKERS AND FUSES

All circuit breakers inside the airplane are of the "push to reset" or "switch/breaker" type. The power distribution module uses spade type (automotive style) fuses and one glass type fuse (controlling the clock).

Spare fuses for the power distribution module are located inside the module. If one of the spare fuses is used, a replacement spare should be obtained and reinstalled before the next flight.

GROUND SERVICE PLUG RECEPTACLE

A ground service receptacle plug is integral to the power distribution module and allows the use of an external power source for cold weather starting, and during lengthy maintenance work on electrical and avionics equipment. The receptacle is located on the left side of the airplane near the firewall. Access to the receptacle is gained by opening the access door.

The power distribtuion module (J-Box) incorporates a circuit which will close the battery contactor when external power is applied through the ground service plug receptacle with the master switch turned on. This feature is intended as a servicing aid when battery power is too low to close the contactor, and should not be used to avoid performing proper maintenance procedures on a low battery.

NOTE

If no avionics equipment is to be used or worked on, the avionics master switch should be turned off. If maintenance is required on the avionics equipment, it is advisable to utilize a regulated external power source to prevent damage to the avionics equipment by transient voltage. Do not crank or start the engine with the avionics master switch turned on.

NOTE

Just before connecting an external power source (generator type or battery cart), the avionics master switch and the master switch should be turned off.

If there is any question as to the condition of the battery, the following check should be made after engine has been started and external power source has been removed.

- 1. Master Switch - OFF.
- 2. Taxi and Landing Light Switches - ON.
- 3. Engine RPM - REDUCE to idle.
- 4. Master Switch - ON (with taxi and landing lights turned on)
- 5. Engine RPM - INCREASE to approximately 1500 RPM.
- 6. Ammeter and Low Voltage Annunciator - CHECK.

LIGHTING SYSTEMS

EXTERIOR LIGHTING

Exterior lighting consists of navigation lights on the wing tips and top of the rudder, a dual landing/taxi lights located in the left wing leading edge, a flashing beacon mounted on top of the vertical fin, and a strobe light on each wing tip. In addition, two courtesy lights are recessed into the lower surface of each wing and provide illumination for each cabin door area.

The exterior courtesy lights (and the rear cabin dome light) are turned on by pressing the rear cabin light switch. Pressing the rear cabin light switch again will extinguish the three lights. The remaining exterior lights are operated by breaker/switches located on the lower left instrument panel. To activate these lights, place switch in the UP position. To deactivate light, place in the DOWN position.

NOTE

The strobes and flashing beacon should not be used when flying through clouds or overcast; the flashing light reflected from water droplets or particles in the atmosphere, particularly at night, can produce vertigo and loss of orientation.

INTERIOR LIGHTING

Interior lighting is controlled by a combination of flood lighting, glareshield lighting, pedestal lighting, panel lighting, radio lighting and pilot control wheel lighting.

Flood lighting is accomplished using two lights in the front and a single dome light in the rear. All lights are contained in the overhead console, and are turned on and off with push type switches located near each light. The two front lights are individually rotatable, providing directional lighting for the pilot and front passenger. The rear dome light is a fixed position light and provides for general illumination in the rear cabin area.

Glareshield lighting is accomplished using a fluorescent light recessed into the glareshield. This light is controlled by rotating the GLARESHIELD LT dimmer, located below the nav indicators. Rotating the dimmer clockwise increases light intensity, and rotating the dimmer counterclockwise decreases light intensity.

Pedestal lighting consists of a single, hooded light located above the fuel selector. This light is controlled by rotating the PEDESTAL LT dimmer, located below the nav indicators. Rotating the dimmer clockwise increases light intensity, and rotating the dimmer counterclockwise decreases light intensity.

Panel lighting is accomplished using individual lights mounted in each instrument and gauge. These lights are wired in parallel and are controlled by the PANEL LT dimmer, located below the nav indicators. Rotating the dimmer clockwise increases light intensity, and rotating the dimmer counterclockwise decreases light intensity. Back lighting intensity for the radios and instrument lighting for the RH nav indicators, in the pilot's panel, is controlled by the TST (TEST) - BRT (DAY) - DIM (NIGHT) switch. When the switch is in the BRT (DAY) position, this lighting may be off regardless of the RADIO LT dimmer position. Some earlier aircraft will always have this lighting controlled by the RADIO LT dimmer.

Pilot control wheel lighting is accomplished by use of a rheostat and light assembly, located underneath the pilot control wheel yoke. The light provides downward illumination from the bottom of the yoke to the pilot's lap area. To operate the light, first turn on the NAV light switch, then adjust the map light intensity with the knurled rheostat knob. Rotating the dimmer clockwise increases light intensity, and rotating the dimmer counterclockwise decreases light intensity.

Regardless of the light system in question, the most probable cause of a light failure is a burned out bulb. However, in the event any of the lighting systems fail to illuminate when turned on, check the appropriate circuit breaker. If the circuit breaker has opened, and there is no obvious indication of a short circuit (smoke or odor), turn off the light switch of the affected lights, reset the breaker, and turn the switch on again. If the breaker opens again, do not reset it.

CABIN HEATING, VENTILATING AND DEFROSTING SYSTEM

The temperature and volume of airflow into the cabin can be regulated by manipulation of the push-pull CABIN HT and CABIN AIR controls (Refer to Figure 7-8). Both controls are the double-button locking-type and permit intermediate settings.

For cabin ventilation, pull the CABIN AIR knob out. To raise the air temperature, pull the CABIN HT knob out approximately 1/4 to 1/2 inch for a small amount of cabin heat. Additional heat is available by pulling the knob out farther; maximum heat is available with the CABIN HT knob pulled out and the CABIN AIR knob pushed full in. When no heat is desired in the cabin, the CABIN HT knob is pushed full in.

Front cabin heat and ventilating air is supplied by outlet holes spaced across a cabin manifold just forward of the pilot's and copilot's feet. Rear cabin heat and air is supplied by two ducts from the manifold, one extending down each side of the cabin to an outlet at the front doorpost at floor level. Windshield defrost air is also supplied by two ducts leading from the cabin manifold to defroster outlets near the lower edge of the windshield. Two knobs control sliding valves in either defroster outlet to permit regulation of defroster airflow.

Separate adjustable ventilators supply additional air; one near each upper corner of the windshield supplies air for the pilot and copilot, and two ventilators are available for the rear cabin area to supply air to the rear seat passengers. Additionally, there are ventilators located on the forward cabin sidewall area just below the windshield sill area.




Figure 7-8. Cabin Heating, Ventilating and Defrosting System.

PITOT-STATIC SYSTEM AND INSTRUMENTS

The pitot-static systems supply ram air pressure to the airspeed indicator and static pressure to the airspeed indicator, vertical speed indicator and altimeter. The systems are composed of a heated pitot tube mounted on the lower surface of the left wing, two external static ports on the lower left and right sides of the forward fuselage, an alternate static source valve and the associated plumbing necessary to connect the instruments to the sources.

The heated pitot system consists of a heating element in the pitot tube, a 10-amp switch/breaker labeled PITOT HEAT, and associated wiring. The switch/breaker is located on the lower left side of the instrument panel. When the pitot heat switch is turned on, the element in the pitot tube is heated electrically to maintain proper operation in possible icing conditions.

A static pressure alternate source valve is installed above the throttle, and can be used if the external static source is malfunctioning. This valve supplies static pressure from inside the cabin instead of the external static port.

If erroneous instrument readings are suspected due to water or ice in the pressure line going to the standard external static pressure source, the alternate static source valve should be pulled on.

Pressures within the cabin will vary with open heater/vents and windows. Refer to Section 5 for the configuration applicable to the use of the alternate static source and the correction charts.

AIRSPEED INDICATOR

The airspeed indicator is calibrated in knots and miles per hour. It incorporates an internal, rotatable ring which allows true airspeed to be read off the face of the dial. In addition, the indicator incorporates windows at the seven and twelve o'clock positions. The window at the seven o'clock position displays true airspeed, and the window at the twelve o'clock position displays pressure altitude overlayed with a temperature scale.

Limitation and range markings (in KIAS) include the white arc (36 to 100 knots), green arc (43 to 140 knots), yellow arc (140 to 175 knots), and a red line (175 knots).

To find true airspeed, first determine pressure altitude and outside air temperature. Using this data, rotate the lower left knob until pressure altitude aligns with outside air temperature in the twelve o'clock window. True airspeed (corrected for pressure and temperature) can now be read in the seven o'clock window. For maximum accuracy the true airspeed should be read opposite the calibrated airspeed value.

VERTICAL SPEED INDICATOR

The vertical speed indicator depicts airplane rate of climb or descent in feet per minute. The pointer is actuated by atmospheric pressure changes resulting from changes of altitude as supplied by the static sources.

ALTIMETER

Airplane altitude is depicted by a barometric type altimeter. A knob near the lower left portion of the indicator provides adjustment of the instrument's barometric scale to the current altimeter setting.

VACUUM SYSTEM AND INSTRUMENTS

The vacuum system (Refer to Figure 7-9) provides vacuum necessary to operate the attitude indicator and directional indicator. The system consists of two engine-driven vacuum pumps, two pressure switches for measuring vacuum available through each pump, a vacuum relief valve, a vacuum system air filter, vacuum operated instruments, a vacuum gauge, low vacuum warning on the annunciator, and a manifold with check valves to allow for normal vacuum system operation if one of the vacuum pumps should fail.

ATTITUDE INDICATOR

The attitude indicator is a vacuum air-driven gyro that gives a visual indication of flight attitude. Bank attitude is presented by a pointer at the top of the indicator relative to the bank scale which has index marks at 10°, 20°, 30°, 60°, and 90° either side of the center mark. Pitch and roll attitudes are presented by a miniature airplane superimposed over a symbolic horizon area divided into two sections by a white horizon bar. The upper "blue sky" area and the lower "ground" area have pitch reference lines useful for pitch attitude control. A knob at the bottom of the instrument is provided for in-flight adjustment of the symbolic airplane to the horizon bar for a more accurate flight attitude indication.

DIRECTIONAL INDICATOR

The directional indicator is a vacuum air-driven gyro that displays airplane heading on a compass card in relation to a fixed simulated airplane image and index. The indicator will precess slightly over a period of time. Therefore, the compass card should be set with the magnetic compass just prior to takeoff, and readjusted as required throughout the flight. A knob on the lower left edge of the instrument is used to adjust the compass card to correct for precession. A knob on the lower right edge of the instrument is used to move the heading bug.




Figure 7-9. Vacuum System Schematic

VACUUM GAUGE

The vacuum gauge is part of the vacuum gauge/ammeter, located on the lower left corner of the instrument panel. It is calibrated in inches of mercury and indicates vacuum available for operation of the Attitude and Directional Indicators. The desired vacuum range is 4.5 to 5.5 inches of mercury. Normally, a vacuum reading out of this range may indicate a system malfunction or improper adjustment, and in this case, the Attitude and Directional Indicators should not be considered reliable. However, due to lower atmospheric pressures at higher altitudes, the vacuum gauge may indicate as low as 4.0 in. Hg. at 20,000 feet and still be adequate for normal system operation.

LOW VACUUM ANNUNCIATION

Each engine-driven vacuum pump is plumbed to a common manifold, located forward of the firewall. From the tee, a single line runs into the cabin to operate the various vacuum system instruments. This tee contains check valves to prevent back flow into a pump if it fails. Transducers are located just upstream of the tee and measure vacuum output of each pump.

If output of the left pump falls below 3.0 in. Hg., the amber L VAC message will flash on the annunciator panel for approximately 10 seconds before turning steady on. If output of the right pump falls below 3.0 in. Hg., the amber VAC R message will flash on the annunciator panel for approximately 10 seconds before turning steady on. If output of both pumps falls below 3.0 in. Hg., the amber L VAC R message will flash on the annunciator panel for approximately 10 seconds before turning steady on.

CLOCK / O.A.T. INDICATOR

An integrated clock / O.A.T. is installed in the upper left side of the instrument panel as standard equipment. For a complete description and operating instructions, refer to the Supplements, Section 9.

STALL WARNING SYSTEM

The airplane is equipped with a vane-type stall warning system consisting of an inlet in the leading edge of the left wing, which is electrically connected to a stall warning horn located in the headliner above the left cabin door. A 5-amp push-to-reset circuit breaker labeled STALL WARN, on the left side of the switch and control panel, protects the stall warning system. The vane in the wing senses the change in airflow over the wing, and operates the warning horn at airspeeds between 5 and 10 knots above the stall in all configurations.

The airplane has a heated stall warning system, the vane and sensor unit in the wing leading edge is equipped with a heating element. The heated part of the system is operated by the PITOT HEAT switch, and is protected by the PITOT HEAT circuit breaker.

The stall warning system should be checked during the pre-flight inspection by momentarily turning on the master switch and actuating the vane in the wing. The system is operational if the warning horn sounds as the vane is pushed upward.

Nov 15/00

STANDARD AVIONICS

Standard avionics for the Model 182S airplanes include the following equipment:

KX-155A	Nav/Com Radio
KX-155A	Nav/Com Radio with Glide Slope
KI 208	Indicator Head
KI 209A	Indicator Head with GPS Interface
KT-76C	Transponder
KMA-26	Audio Panel
3000-11	Emergency Locator Transmitter (ELT)
KLN 89B	Global Positioning System (GPS)
KAP 140	Single Axis Autopilot

For complete operating instructions on the standard and optional avionics systems, refer to the Supplements, Section 9.

AVIONICS SUPPORT EQUIPMENT

Avionics operations are supported by the avionics cooling fan, microphone and headset installations and static discharge wicks.

AVIONICS COOLING FAN

An avionics cooling fan is installed on the left side of the interior firewall. The system utilizes a single electric fan and associated ductwork to force-cool the GPS and Nav/Com radios.

Power to the electric fan is supplied through the AVN FAN circuit breaker. The fan operates anytime the master and avionics master switches are ON.

MICROPHONE AND HEADSET INSTALLATIONS

Standard equipment for the airplane includes a hand-held microphone, an overhead speaker, two remote-keyed microphone switches on the control wheels, and provisions for boom mics/headsets at each pilot and passenger station.

The hand-held microphone contains an integral push-to-talk switch. This microphone is plugged into the center pedestal and is accessible to both the pilot and front passenger. Depressing the push-to-talk switch allows audio transmission on the Com radios.

The overhead speaker is located in the center overhead console. Volume and output for this speaker is controlled through the audio panel.

Each control wheel contains a miniature push-to-talk switch. This switch allows the pilot or front passenger to transmit on the Comradios using remote mics.

Each station of the airplane is wired for aviation-style headsets. Mic and headphone jacks are located on each respective arm rest and allow for communications between passengers and pilot. The system is wired so that microphones are all voice-activated. Additional wiring provisions inside the audio panel ensure that only the pilot or front passenger can transmit through the com radios.

NOTE

To ensure audibility and clarity when transmitting with the handheld microphone, always hold it as closely as possible to the lips, then key the microphone and speak directly into it. Avoid covering opening on back side of microphone for optimum noise canceling.

STATIC DISCHARGERS

Static wicks (static dischargers) are installed at various points throughout the airframe to reduce interference from precipitation static. Under some severe static conditions, loss of radio signals is possible even with static dischargers installed. Whenever possible, avoid known severe precipitation areas to prevent loss of dependable radio signals. If avoidance is impractical, minimize airspeed and anticipate temporary loss of radio signals while in these areas.

Static dischargers lose their effectiveness with age, and therefore, should be checked periodically (at least at every annual inspection) by qualified avionics technicians, etc.

CABIN FEATURES

EMERGENCY LOCATOR TRANSMITTER (ELT)

A remote switch/annunciator is installed on the top center location of the copilot's instrument panel for control of the ELT from the flight crew station. The annunciator, which is in the center of the rocker switch, illuminates when the ELT transmitter is transmitting. The ELT emits an omni-directional signal on the international distress frequencies of 121.5 MHz and 243.0 MHz. General aviation and commercial aircraft, the FAA and CAP monitor 121.5 MHz, and 243.0 MHz is monitored by the military. For a basic overview of the ELT, refer to the Supplements, Section 9.

CABIN FIRE EXTINGUISHER

A portable Halon 1211 (Bromochlorodifluoromethane) fire extinguisher is standard for installation on the floorboard near the pilot's seat where it would be accessible in case of fire. The extinguisher has an Underwriters Laboratories classification of 5B:C. If installed, the extinguisher should be checked prior to each flight to ensure that its bottle pressure, as indicated by the gauge on the bottle, is within the green arc (approximately 125 psi) and the operating lever lock pin is securely in place.

To operate the fire extinguisher:

- Loosen retaining clamp(s) and remove extinguisher from bracket.
- 2. Hold extinguisher upright, pull operating ring pin, and press lever while directing the discharge at the base of the fire at the near edge. Progress toward the back of the fire by moving the nozzle rapidly with a side to side sweeping motion.

WARNING

VENTILATE THE CABIN PROMPTLY AFTER SUCCESSFULLY EXTINGUISHING THE FIRE TO REDUCE THE GASES PRODUCED BY THERMAL DECOMPOSITION.

3. Anticipate approximately eight seconds of discharge duration.

Fire extinguishers should be recharged by a qualified fire extinguisher agency after each use. Such agencies are listed under "Fire Extinguisher" in the telephone directory. After recharging, secure the extinguisher to its mounting bracket; do not allow it to lie loose on shelves or seats.

		•	
<u> </u>			
			2

SECTION 8

AIRPLANE HANDLING, SERVICE & MAINTENANCE

TABLE OF CONTENTS	Page
Introduction	8-3_
Identification Plate	8-4
Cessna Owner Advisories	8-4
United States Airplane Owners	8-5
International Airplane Owners	8-5
Publications	8-5
Airplane File	8-6
Airplane Inspection Periods	8-7
FAA Required Inspections	8-7
Cessna Inspection Programs	8-8
Cessna Customer Care Program	8-8
Pilot Conducted Preventive Maintenance	8-9
Alterations Or Repairs	8-9
Ground Handling	8-10
Towing	8-10
Parking	8-10
Tie-Down	8-10_
Jacking	8-11
Leveling	8-11_
Flyable Storage	8-12
Servicing	8-12
Oil	8-13
Oil Specification	8-13
Recommended Viscosity for Temperature Range	8-14

TABLE OF CONTENTS (Continued)

	Page
Capacity of Engine Sump	8-14
Oil and Oil Filter Change	8-14
Fuel	8-15
Approved Fuel Grades (and Colors)	8-15
Fuel Capacity	8-16
Fuel Additives	8-16
Fuel Contamination	8-20
Landing Gear	8-21
Cleaning And Care	8-21
Windshield And Windows	8-21
Painted Surfaces	8-22
Propeller Care	8-23
Engine Care	8-23
Interior Care	8-24

8-2 Nov 15/00

INTRODUCTION

This section contains factory recommended procedures for proper ground handling and routine care and servicing of your airplane. It also identifies certain inspection and maintenance requirements which must be followed if your airplane is to retain that new plane performance and dependability. It is wise to follow a planned schedule of lubrication and preventive maintenance based on climatic and flying conditions encountered in your locality.

Keep in touch with your local Cessna Service Station and take advantage of their knowledge and experience. Your Cessna Service Station knows your airplane and how to maintain it, and will remind you when lubrications and oil changes are necessary, as well as other seasonal and periodic services.

The airplane should be regularly inspected and maintained in accordance with information found in the airplane maintenance manual and in company issued service bulletins and service newsletters. All service bulletins pertaining to the aircraft by serial number should be accomplished and the airplane should receive repetitive and required inspections. Cessna does not condone modifications, whether by Supplemental Type Certificate or otherwise, unless these certificates are held and/or approved by Cessna. Other modifications may void warranties on the airplane since Cessna has no way of knowing the full effect on the overall airplane. Operation of an airplane that has been modified may be a risk to the occupants, and operating procedures and performance data set forth in the operating handbook may no longer be considered accurate for the modified airplane.

IDENTIFICATION PLATE

All correspondence regarding your airplane should include the Serial Number. The Serial Number, Model Number, Production Certificate Number (PC) and Type Certificate Number (TC) can be found on the Identification Plate, located on the aft left tailcone. A secondary Identification Plate is also installed on the lower part of the left forward doorpost. Located adjacent to the secondary Identification Plate is the Finish and Trim Plate which contains a code describing the exterior paint combination of the airplane. The code may be used in conjunction with an applicable Illustrated Parts Catalog if finish and trim information is needed.

CESSNA OWNER ADVISORIES

Cessna Owner Advisories are sent to Cessna Aircraft FAA Registered owners of record at no charge to inform them about mandatory and/or beneficial aircraft service requirements and product changes. Copies of the actual bulletins are available from Cessna Service Stations and Cessna Customer Service.

UNITED STATES AIRPLANE OWNERS

If your airplane is registered in the U. S., appropriate Cessna Owner Advisories will be mailed to you automatically according to the latest aircraft registration name and address which you have provided to the FAA. Therefore, it is important that you provide correct and up-to-date mailing information to the FAA.

If you require a duplicate Owner Advisory to be sent to an address different from the FAA aircraft registration address, please complete and return an Owner Advisory Application (otherwise no action is required on your part).

INTERNATIONAL AIRPLANE OWNERS

To receive Cessna Owner Advisories, please complete and return an Owner Advisory Application.

Receipt of a valid Owner Advisory Application will establish your Cessna Owner Advisory service for one year, after which you will be sent a renewal notice. It is important that you respond promptly to update your address for this critical service.

PUBLICATIONS

Various publications and flight operation aids are furnished in the airplane when delivered from the factory. These items are listed below.

- Customer Care Program Handbook
- Pilot's Operating Handbook and FAA Approved Airplane Flight Manual
- Pilot's Checklist
- Passenger Briefing Card
- Cessna Sales and Service Directory

To obtain additional publications or owner advisory information, you may contact Cessna's Product Support Department at (316) 517-5800. Fax (316) 517-7271 or write to The Cessna Aircraft Company, P.O. Box 7706, Wichita, KS 67277, Dept 751C.

The following additional publications, plus many other supplies that are applicable to your airplane, are available from your local Cessna Dealer.

- Information Manual (contains Pilot's Operating Handbook Information)
- Maintenance Manual, Wiring Diagram Manual and Illustrated Parts Catalog

Your local Cessna Service Station has a Customer Care Supplies and Publications Catalog covering all available items, many of which the Service Station keeps on hand. The Service Station can place an order for any item which is not in stock.

NOTE

A Pilot's Operating Handbook and FAA Approved Airplane Flight Manual which is lost or destroyed may be replaced by contacting your local Cessna Service Station. An affidavit containing the owner's name, airplane serial number and reason for replacement must be included in replacement requests since the Pilot's Operating Handbook and FAA Approved Airplane Flight Manual is identified for specific serial numbered airplanes only.

AIRPLANE FILE

There are miscellaneous data, information and licenses that are a part of the airplane file. The following is a checklist for that file. In addition, a periodic check should be made of the latest Federal Aviation Regulations to ensure that all data requirements are met.

To be displayed in the airplane at all times:

- 1. Aircraft Airworthiness Certificate (FAA Form 8100-2).
- 2. Aircraft Registration Certificate (FAA Form 8050-3).
- 3. Aircraft Radio Station License, (if applicable).

To be carried in the airplane at all times:

1. Current Pilot's Operating Handbook and FAA Approved Airplane Flight Manual.

2. Weight and Balance, and associated papers (latest copy of the Repair and Alteration Form, FAA Form 337, if applicable).

3. Equipment List.

To be made available upon request:

- 1. Airplane Logbook.
- 2. Engine Logbook.

Most of the items listed are required by the United States Federal Aviation Regulations. Since the Regulations of other nations may require other documents and data, owners of airplanes not registered in the United States should check with their own aviation officials to determine their individual requirements.

Cessna recommends that these items, plus the Pilot's Checklists, Customer Care Program Handbook and Customer Care Card, be carried in the airplane at all times.

AIRPLANE INSPECTION PERIODS

FAA REQUIRED INSPECTIONS

As required by U.S. Federal Aviation Regulations, all civil aircraft of U.S. registry must undergo a complete inspection (annual) each twelve calendar months. In addition to the required annual inspection, aircraft operated commercially (for hire) must have a complete inspection every 100 hours of operation.

The FAA may require other inspections by the issuance of airworthiness directives applicable to the airplane, engine, propeller and components. It is the responsibility of the owner/operator to ensure compliance with all applicable airworthiness directives, and when the inspections are repetitive, to take appropriate steps to prevent inadvertent noncompliance.

CESSNA INSPECTION PROGRAMS

In lieu of the 100 hour and annual inspection requirements, an airplane may be inspected in accordance with a Progressive Care Inspection Program or a PhaseCard Inspection Program. Both programs offer systems which allow the work load to be divided into smaller operations that can be accomplished in shorter time periods.

- The Cessna Progressive Care Inspection Program allows an airplane to be inspected and maintained in four operations. The four operations are recycled each 200 hours and are recorded in a specially provided Aircraft Inspection Log as each operation is conducted.
- The PhaseCard Inspection Program offers a parallel system for high-utilization flight operations (approximately 600 flight hours per year). This system utilizes 50 hour intervals (Phase 1 and Phase 2) to inspect high-usage systems and components. At 12 months or 600 flight hours, whichever occurs first, the airplane undergoes a complete (Phase 3) inspection.

Regardless of the inspection method selected, the owner should keep in mind that FAR Part 43 and FAR Part 91 establishes the requirement that properly certified agencies or personnel accomplish all required FAA inspections and most of the manufacturer recommended inspections.

CESSNA CUSTOMER CARE PROGRAM

Specific benefits and provisions of the Cessna Warranty plus other important benefits for you are contained in your Customer Care Program Handbook supplied with your airplane. The Customer Care Program Handbook should be thoroughly reviewed and kept in the airplane at all times.

You will also want to return to your Cessna Service Station either at 50 hours for your first Progressive Care Operation, or at 100 hours for your first 100 hour inspection depending on which program you choose to establish for your airplane. While these important inspections will be performed for you by any Cessna Service Station, in most cases you will prefer to have the Cessna Service Station from whom you purchased the airplane accomplish this work.

PILOT CONDUCTED PREVENTIVE MAINTENANCE

A certified pilot who owns or operates an airplane not used as an air carrier is authorized by FAR Part 43 to perform limited maintenance on his airplane. Refer to FAR Part 43 for a list of the specific maintenance operations which are allowed.

NOTE

Pilots operating airplanes of other than U.S. registry should refer to the regulations of the country of certification for information on preventive maintenance that may be performed by pilots.

A Maintenance Manual must be obtained prior to performing any preventive maintenance to ensure that proper procedures are followed. Your Cessna Service Station should be contacted for further information or for required maintenance which must be accomplished by appropriately licensed personnel.

ALTERATIONS OR REPAIRS

It is essential that the FAA be contacted prior to any alterations on the airplane to ensure that airworthiness of the airplane is not violated. Alterations or repairs to the airplane must be accomplished by licensed personnel, utilizing only FAA Approved components and FAA Approved data, such as Cessna Service Bulletins.

GROUND HANDLING

TOWING

The airplane is most easily and safely maneuvered by hand with the tow bar attached to the nose wheel (the tow bar is stowed on the floor in the baggage area). When towing with a vehicle, do not exceed the nose gear turning angle of 29° either side of center, or damage to the nose landing gear will result.

A CAUTION

REMOVE ANY INSTALLED RUDDER LOCK BEFORE TOWING.

If the airplane is towed or pushed over a rough surface during hangaring, watch that the normal cushioning action of the nose strut does not cause excessive vertical movement of the tail and the resulting contact with low hangar doors or structure. A flat nose tire or deflated strut will also increase tail height.

PARKING

When parking the airplane, head into the wind and set the parking brake. Do not set the parking brake during cold weather when accumulated moisture may freeze the brakes, or when the brakes are overheated. Install the control wheel lock and chock the wheels. In severe weather and high wind conditions, tie the airplane down as outlined in the following paragraph.

TIE-DOWN

Proper tie-down procedure is the best precaution against damage to the parked airplane by gusty or strong winds. To tie-down the airplane securely, proceed as follows:

- 1. Set the parking brake and install the control wheel lock.
- 2. Install a surface control lock over the fin and rudder.
- 3. Tie sufficiently strong ropes or chains (700 pounds tensile strength) to the wing, tail and nose tie-down fittings and secure each rope or chain to a ramp tie-down.
- 4. Install a pitot tube cover.

JACKING

When a requirement exists to jack the entire airplane off the ground, or when wing jack points are used in the jacking operation, refer to the Maintenance Manual for specific procedures and equipment required.

Individual main gear may be jacked by using the jack pad which is incorporated in the main landing gear strut step bracket. When using the individual gear strut jack pad, flexibility of the gear strut will cause the main wheel to slide inboard as the wheel is raised, tilting the jack. The jack must then be lowered for a second jacking operation. Do not jack both main wheels simultaneously using the individual main gear jack pads.

A CAUTION

DO NOT APPLY PRESSURE ON THE ELEVATOR OR HORIZONTAL STABILIZER SURFACES. WHEN PUSHING ON THE TAILCONE, ALWAYS APPLY PRESSURE AT A BULKHEAD TO AVOID BUCKLING THE SKIN.

If nose gear maintenance is required, the nose wheel may be raised off the ground by pressing down on a tailcone bulkhead, just forward of the horizontal stabilizer, and allowing the tail to rest on the tail tie-down ring.

To assist in raising and holding the nose wheel off the ground, ground anchors should be utilized at the tail tie down point.

NOTE

Ensure that the nose will be held off the ground under all conditions by means of suitable stands or supports under weight supporting bulkheads near the nose of the airplane.

LEVELING

Longitudinal leveling of the airplane is accomplished by placing a level on leveling screws located on the left side of the tailcone. Deflate the nose tire and/or lower or raise the nose strut to properly center the bubble in the level. Corresponding points on both upper door sills may be used to level the airplane laterally.

FLYABLE STORAGE

Airplanes placed in non operational storage for a maximum of 30 days or those which receive only intermittent operational use for the first 25 hours are considered in flyable storage status. Every seventh day during these periods, the propeller should be rotated by hand through five revolutions. This action "limbers" the oil and helps prevent any accumulation of corrosion on engine cylinder walls.

WARNING

FOR MAXIMUM SAFETY, CHECK THAT THE IGNITION SWITCH IS OFF, THE THROTTLE IS CLOSED, THE MIXTURE CONTROL IS IN THE IDLE CUT OFF POSITION, AND THE AIRPLANE IS SECURED BEFORE ROTATING THE PROPELLER BY HAND. DO NOT STAND WITHIN THE ARC OF THE PROPELLER BLADES WHILE TURNING THE PROPELLER.

After 30 days, the airplane should be flown for 30 minutes or a ground runup should be made just long enough to produce an oil temperature within the lower green arc range. Excessive ground runup should be avoided.

Engine runup also helps to eliminate excessive accumulations of water in the fuel system and other air spaces in the engine. Keep fuel tanks full to minimize condensation in the tanks. Keep the battery fully charged to prevent the electrolyte from freezing in cold weather. If the airplane is to be stored temporarily, or indefinitely, refer to the Maintenance Manual for proper storage procedures.

SERVICING

In addition to the Preflight Inspection covered in Section 4 of this handbook, complete servicing, inspection and test requirements for your airplane are detailed in the Maintenance Manual. The Maintenance Manual outlines all items which require attention at specific intervals plus those items which require servicing, inspection, and/or testing at special intervals.

Since Cessna Service Stations conduct all service, inspection, and test procedures in accordance with applicable Maintenance Manuals, it is recommended that you contact your Cessna Service Station concerning these requirements and begin scheduling your airplane for service at the recommended intervals.

Cessna Progressive Care ensures that these requirements are accomplished at the required intervals to comply with the 100 hour or annual inspection as previously covered.

Depending on various flight operations, your local Government Aviation Agency may require additional service, inspections, or tests. For these regulatory requirements, owners should check with local aviation officials where the airplane is being operated.

For quick and ready reference, quantities, materials and specifications for frequently used service items are as follows.

OIL

OIL SPECIFICATION

MIL-L-6082 Aviation Grade Straight Mineral Oil: Used when the airplane was delivered from the factory and should be used to replenish the supply during the first 25 hours. This oil should be drained and filter replaced after the first 25 hours of operation. Refill the engine and continue to use until a total of 50 hours has accumulated or oil consumption has stabilized.

MIL-L-22851 Aviation Grade Ashless Dispersant Oil: Oil conforming to Textron Lycoming Service Instruction No. 1014, and all revisions and supplements thereto, must be used after first 50 hours or when oil consumption has stabilized.

RECOMMENDED VISCOSITY FOR TEMPERATURE RANGE

Multiviscosity or straight grade oil may be used throughout the year for engine lubrication. Refer to the following table for temperature verses viscosity ranges.

Temperature	MIL-L-6082 SAE Grade	MIL-L-22851 Ashless Dispersant SAE Grade
Above 27°C (80°F)	60	60
Above 16°C (60°F)	50	40 or 50
-1°C (30°F) to 32°C (90°F)	40	40
-18°C (0°F) to 21°C (70°F)	30	30, 40 or 20W-40
Below -12°C (10°F)	20	30 or 20W-30
-18°C (0°F) to -32°C (90°F)	20W-50	20W-50 or 15W-50
All Temperatures	**	15W-50 or 20W-50

CAPACITY OF ENGINE SUMP

The engine has a total capacity of 9 quarts, with the oil filter accounting for approximately one quart of that total. The engine oil sump has a capacity of 8 quarts. The engine must not be operated on less than 4 quarts (as measured by the dipstick). For extended flights, the engine should be filled to capacity.

OIL AND OIL FILTER CHANGE

After the first 25 hours of operation, drain the engine oil sump and replace the filter. Refill sump with straight mineral oil and use until a total of 50 hours has accumulated or oil consumption has stabilized; then change to ashless dispersant oil. Ashless dispersant oil (and oil filter) should then be changed at time intervals set forth by the engine manufacturer.

NOTE

During the first 25 hour oil and filter change, a general inspection of the overall engine compartment is required. Items which are not normally checked during a preflight inspection should be given special attention. Hoses, metal lines and fittings should be inspected for signs of oil and fuel leaks, and checked for abrasions, chafing, security, proper routing and support, and evidence of deterioration. Inspect the intake and exhaust systems for cracks, evidence of leakage, and security of attachment. Engine controls and linkages should be checked for freedom of movement through their full range, security of attachment and evidence of wear. Inspect wiring for security, chafing, burning, defective insulation, loose or broken terminals, deterioration, and corroded terminals. Check the alternator belt in accordance with Maintenance Manual instructions, and retighten if necessary. A periodic check of these items during subsequent servicing operations is recommended.

FUEL

APPROVED FUEL GRADES (AND COLORS)

100LL Grade Aviation Fuel (Blue). 100 Grade Aviation Fuel (Green).

NOTE

Isopropyl alcohol or diethylene glycol monomethyl ether (DiEGME) may be added to the fuel supply in quantities not to exceed 1% (alcohol) or 0.15% (DiEGME) of total volume. Refer to Fuel Additives in later paragraphs for additional information.

FUEL CAPACITY

92.0 U.S. Gallons Total:

46.0 U.S. Gallons per tank.

NOTE

To ensure maximum fuel capacity when refueling and minimize cross feeding, the fuel selector valve should be placed in either the LEFT or RIGHT position and the airplane parked in a wings level, normal ground attitude. Refer to Figure 1-1 for a definition of normal ground attitude.

Service the fuel system after each flight, and keep fuel tanks full to minimize condensation in the tanks.

FUEL ADDITIVES

Strict adherence to recommended preflight draining instructions as called for in Section 4 will eliminate any free water accumulations from the tank sumps. While small amounts of water may still remain in solution in the gasoline, it will normally be consumed and go unnoticed in the operation of the engine.

One exception to this can be encountered when operating under the combined effect of: (1) use of certain fuels, with (2) high humidity conditions on the ground (3) followed by flight at high altitude and low temperature. Under these unusual conditions, small amounts of water in solution can precipitate from the fuel stream and freeze in sufficient quantities to induce partial icing of the engine fuel system.

While these conditions are quite rare and will not normally pose a problem to owners and operators, they do exist in certain areas of the world and consequently must be dealt with, when encountered.

Therefore, to help alleviate the possibility of fuel icing occurring under these unusual conditions, it is permissible to add isopropyl alcohol or diethylene glycol monomethyl ether (DiEGME) compound to the fuel supply.

The introduction of alcohol or DiEGME compound into the fuel provides two distinct effects: (1) it absorbs the dissolved water from the gasoline and (2) alcohol has a freezing temperature depressant effect.


NOTE

When using fuel additives, it must be remembered that the final goal is to obtain a correct fuel-to-additive ratio in the tank, and not just with fuel coming out of the refueling nozzle. For example, adding 15 gallons of correctly proportioned fuel to a tank which contains 20 gallons of untreated fuel will result in a lower-than-acceptable concentration level to the 35 gallons of fuel which now reside in the tank.

Alcohol, if used, is to be blended with the fuel in a concentration of 1% by volume. Concentrations greater than 1% are not recommended since they can be detrimental to fuel tank materials.

The manner in which the alcohol is added to the fuel is significant because alcohol is most effective when it is completely dissolved in the fuel. To ensure proper mixing, the following is recommended:

- 1. For best results, the alcohol should be added during the fueling operation by pouring the alcohol directly on the fuel stream issuing from the fueling nozzle.
- An alternate method that may be used is to premix the complete alcohol dosage with some fuel in a separate clean container (approximately 2-3 gallon capacity) and then transferring this mixture to the tank prior to the fuel operation.



0585C1001

Figure 8-1. Fuel Mixing Ratio

Diethylene glycol monomethyl ether (DiEGME) compound must be carefully mixed with the fuel in concentrations between 0.10% (minimum) and 0.15% (maximum) of total fuel volume. Refer to Figure 8-1 for a DiEGME-to-fuel mixing chart.

WARNING

ANTI-ICING ADDITIVE IS DANGEROUS TO HEALTH WHEN BREATHED AND/OR ABSORBED INTO THE SKIN.

A CAUTION

MIXING OF DIEGME WITH FUEL IS EXTREMELY IMPORTANT, A CONCENTRATION IN EXCESS OF THAT RECOMMENDED (0.15% BY VOLUME MAXIMUM) MAY RESULT IN DETRIMENTAL EFFECTS TO THE FUEL TANK AND SEALANT, AND DAMAGE TO O-RINGS AND SEALS USED IN THE FUEL SYSTEM AND **ENGINE** COMPONENTS. A CONCENTRATION OF LESS THAN THAT RECOMMENDED (0.10% BY TOTAL WILL VOLUME MINIMUM) RESULT INEFFECTIVE TREATMENT. USE ONLY THAT BLENDING **EQUIPMENT** IS RECOMMENDED BY THE MANUFACTURER TO **OBTAIN PROPER PROPORTIONING.**

Prolonged storage of the airplane will result in a water buildup in the fuel which "leeches out" the additive. An indication of this is when an excessive amount of water accumulates in the fuel tank sumps. The concentration can be checked using a differential refractometer. It is imperative that the technical manual for the differential refractometer be followed explicitly when checking the additive concentration.

Nov 15/00

FUEL CONTAMINATION

Fuel contamination is usually the result of foreign material present in the fuel system, and may consist of water, rust, sand, dirt, microbes or bacterial growth. In addition, additives that are not compatible with fuel or fuel system components can cause the fuel to become contaminated.

Before each flight and after each refueling, use a clear sampler cup and drain at least a cupful of fuel from each fuel tank drain location and from the fuel strainer quick drain valve to determine if contaminants are present, and to ensure the airplane has been fueled with the proper grade of fuel.

If contamination is detected, drain all fuel drain points again, including the fuel selector drain valve, and then gently rock the wings and lower the tail to the ground to move any additional contaminants to the sampling points. Take repeated samples from all fuel drain points until all contamination has been removed. If, after repeated sampling, evidence of contamination still exists, the airplane should not be flown. Tanks should be drained and system purged by qualified maintenance personnel. All evidence of contamination must be removed before further flight. If the airplane has been serviced with the improper fuel grade, defuel completely and refuel with the correct grade. Do not fly the airplane with contaminated or unapproved fuel.

In addition, Owners/Operators who are not acquainted with a particular fixed base operator should be assured that the fuel supply has been checked for contamination and is properly filtered before allowing the airplane to be serviced. Fuel tanks should be kept full between flights, provided weight and balance considerations will permit, to reduce the possibility of water condensing on the walls of partially filled tanks.

To further reduce the possibility of contaminated fuel, routine maintenance of the fuel system should be performed in accordance with the airplane Maintenance Manual. Only the proper fuel, as recommended in this handbook, should be used, and fuel additives should not be used unless approved by Cessna and the Federal Aviation Administration.

LANDING GEAR

Consult the following table for servicing information on the landing gear.

COMPONENT	SERVICING CRITERIA	
Nose Wheel (5.00-5, 6-Ply Rated Tire)	49.0 PSI	
Main Wheel (6.00-6, 6-Ply Rated Tire)	42.0 PSI	
Brakes	MIL-H-5606	
Nose Gear Shock Strut	MIL-H-5606;55.0-60.0 PSI *	

* Keep strut filled with MIL-H-5606 hydraulic fluid per filling instructions placard, and with no load on the strut, inflate with air to 55.0-60.0 PSI. Do not over inflate.

CLEANING AND CARE

WINDSHIELD AND WINDOWS

The plastic windshield and windows should be cleaned with an aircraft windshield cleaner. Apply the cleaner sparingly with soft cloths, and rub with moderate pressure until all dirt, oil scum and bug stains are removed. Allow the cleaner to dry, then wipe it off with soft flannel cloths.

A CAUTION

NEVER USE GASOLINE, BENZENE, ALCOHOL, ACETONE, FIRE EXTINGUISHER, ANTI-ICE FLUID, LACQUER THINNER OR GLASS CLEANER TO CLEAN THE PLASTIC. THESE MATERIALS WILL ATTACK THE PLASTIC AND MAY CAUSE IT TO CRAZE.

If a windshield cleaner is not available, the plastic can be cleaned with soft cloths moistened with Stoddard solvent to remove oil and grease.

13

Follow by carefully washing with a mild detergent and plenty of water. Rinse thoroughly, then dry with a clean moist chamois. Do not rub the plastic with a dry cloth since this builds up an electrostatic charge which attracts dust. Waxing with a good commercial wax will finish the cleaning job. A thin, even coat of wax, polished out by hand with clean soft flannel cloths, will fill in minor scratches and help prevent further scratching.

Do not use a canvas cover on the windshield unless freezing rain or sleet is anticipated since the cover may scratch the plastic surface.

PAINTED SURFACES

The painted exterior surfaces of your new Cessna have a durable, long lasting finish.

Generally, the painted surfaces can be kept bright by washing with water and mild soap, followed by a rinse with water and drying with cloths or a chamois. Harsh or abrasive soaps or detergents which cause corrosion or scratches should never be used. Remove stubborn oil and grease with a cloth moistened with Stoddard solvent. Take special care to make sure that the exterior graphics are not touched by the solvent. For complete care of exterior graphics, refer to Chapter 11 of the 182S, Series 1996 and On, Maintanence Manual.

To seal any minor surface chips or scratches and protect against corrosion, the airplane should be waxed regularly with a good automotive wax applied in accordance with the manufacturer's instructions. If the airplane is operated in a seacoast or other salt water environment, it must be washed and waxed more frequently to assure adequate protection. Special care should be taken to seal around rivet heads and skin laps, which are the areas most susceptible to corrosion. A heavier coating of wax on the leading edges of the wings and tail and on the cowl nose cap and propeller spinner will help reduce the abrasion encountered in these areas. Reapplication of wax will generally be necessary after cleaning with soap solution or after chemical deicing operations.

When the airplane is parked outside in cold climates and it is necessary to remove ice before flight, care should be taken to protect the painted surfaces during ice removal with chemical liquids. Isopropyl alcohol will satisfactorily remove ice accumulations without damaging the paint. However, keep the isopropyl alcohol away from the windshield and cabin windows since it will attack the plastic and may cause it to craze.

PROPELLER CARE

Preflight inspection of propeller blades for nicks, and wiping them occasionally with an oily cloth to clean off grass and bug stains will assure long blade life. Small nicks on the propeller, particularly near the tips and on the leading edges, should be dressed out as soon as possible since these nicks produce stress concentrations, and if ignored, may result in cracks or failure of the propeller blade. Never use an alkaline cleaner on the blades; remove grease and dirt with Stoddard solvent.

ENGINE CARE

The engine may be cleaned, using a suitable solvent, in accordance with instructions in the airplane Maintenance Manual. Most efficient cleaning is done using a spray type cleaner. Before spray cleaning, ensure that protection is afforded for components which might be adversely affected by the solvent. Refer to the Model 182S, Series 1996 and On, Maintenance Manual for proper lubrication of controls and components after engine cleaning. The induction air filter should be replaced each 100 hours or when dirty.

INTERIOR CARE

To remove dust and loose dirt from the upholstery and carpet, clean the interior regularly with a vacuum cleaner.

Blot up any spilled liquid promptly with cleansing tissue or rags. Don't pat the spot; press the blotting material firmly and hold it for several seconds. Continue blotting until no more liquid is taken up. Scrape off sticky materials with a dull knife, then spot clean the area.

Oily spots may be cleaned with household spot removers, used sparingly. Before using any solvent, read the instructions on the container and test it on an obscure place on the fabric to be cleaned. Never saturate the fabric with a volatile solvent; it may damage the padding and backing materials.

Soiled upholstery and carpet may be cleaned with foam type detergent, used according to the manufacturer's instructions. To minimize wetting the fabric, keep the foam as dry as possible and remove it with a vacuum cleaner.

For complete information related to interior cleaning, refer to Chapter 12 of the Model 182S, Series 1996 and On, Maintenance Manual.


SUPPLEMENTS

INTRODUCTION

The supplements in this section contain expanded operational procedures for both standard and optional equipment installed in the airplane. Operators should refer to each supplement to ensure that all limitations and procedures appropriate for their airplane are observed.

A Log Of Approved Supplements is provided beginning on page Log 1 and lists all supplements applicable to this airplane by name, number and revision level. This log should be used as a checklist to ensure all applicable supplements have been placed in the Pilot's Operating Handbook (POH). Supplements may be removed from the POH provided the equipment is not installed on the airplane. If equipment is installed on the airplane, however, the supplement(s) must be retained and updated as revisions to each supplement is issued.

Each individual supplement contains its own Log of Effective Pages. This log lists the page number and effective date of every page in the supplement. The log also lists the dates on which revisions to the supplement occurred. Additionally, the part number of the supplement provides information on the revision level. Refer to the following example:



£ 25			
ij			
î.			

.

LOG OF APPROVED SUPPLEMENTS

NOTE

IT IS THE AIRPLANE OWNER'S RESPONSIBILITY TO ASSURE THAT HE OR SHE HAS THE LATEST REVISION TO EACH SUPPLEMENT OF A PILOT'S OPERATING HANDBOOK AND THE LATEST ISSUED "LOG OF APPROVED SUPPLEMENTS." THIS "LOG OF APPROVED SUPPLEMENTS" WAS THE LATEST REVISION AS OF THE DATE IT WAS SHIPPED BY CESSNA; HOWEVER, SOME CHANGES MAY HAVE OCCURRED AND THE OWNER SHOULD VERIFY THIS IS THE LATEST, MOST UP-TO-DATE VERSION BY CONTACTING CESSNA CUSTOMER SUPPORT AT (316) 517-5800.

SUPP. #	SUPPLEMENT NAME	REV LEVEL	EQUIPMENT INSTALLED
1	Bendix/King KX 155A VHF NAV/COMM with KI 208 or KI 209A Indicator Head	2	:
2	Bendix/King KT 76C Transponder with Blind Encoder	1	·
3	Bendix/King KMA 26 Audio Selector Panel	1	
4	Pointer Model 3000-11 Emergency Locator Transmitter (ELT)	1	
5	Bendix/King KLN 89B Global Positioning System (GPS)	3	-
6	Bendix/King KR 87 Automatic Direction Finder (ADF)	2	,——
7	Bendix/King KAP 140 Autopilot	2	
8	Winterization Kit	1	3
9	Davtron Model 803 Clock/OAT	1	
10	Bendix/King KLN89 Global Positioning System (GPS)	1	

P/N - 182SUSLOG03

LOG OF APPROVED SUPPLEMENTS

SUPP.	SUPPLEMENT NAME	REV LEVEL	EQUIPMENT INSTALLED
11	Bendix/King KAP 140 2-Axis Autopilot (Aircraft Serial No. 18280001 thru 18280164)	3	
12	Canadian Supplement	0	-
13	Bendix/King KCS-55A Slaved Compass System with KI-525A Horizontal Situation Indicator (HSI)	1	
14	Argentine Supplement	0	
15	Bendix/King KAP 140 Autopilot (Serial No. 18280165 and on or aircraft modified by MK182-22-01) with altitude preselect	1	
16	Reserved	0	-
17	Reserved	0	
18	Reserved	0	-
19	KLN 94 Global Positioning System	2	-



Pilot's Operating Handbook and FAA Approved Airplane Flight Manual

CESSNA MODEL 182S AIRPLANES 18280001 AND ON

SUPPLEMENT 1

BENDIX/KING KX 155A
VHF NAV/COMM
with KI 208 or KI 209A INDICATOR HEAD

Member of GAMA
3 February 1997

Revision 2 - 15 November 2000

COPYRIGHT © 1997 CESSNA AIRCRAFT COMPANY WICHITA, KANSAS, USA

182SPHUS-S1-02

S1-1

SUPPLEMENT 1

BENDIX/KING KX 155A VHF NAV/COMM with KI 208 or KI 209A INDICATOR HEAD

The following Log of Effective Pages provides the date of issue for original and revised pages, as well as a listing of all pages in the Supplement. Pages which are affected by the current revision will carry the date of that revision

Revision Level Date of Issue

0 (Original)	Feb. 3, 1997
1	Dec. 1, 1997
2	Nov. 15, 2000

LOG OF EFFECTIVITY PAGES

PAGE	DATE	PAGE	DATE
Title (S1-1)	Nov 15/00	S1-9	Feb 3/97
S1-2	Nov 15/00	S1-10	Feb 3/97
S1-3	Nov 15/00	S1-11	Dec 1/97
S1-4	Feb 3/97	S1-12	Feb 3/97
S1-5	Feb 3/97	S1-13	Nov 15/00
S1-6	Feb 3/97	S1-14	Feb 3/97
S1-7	Feb 3/97	S1-15	Feb 3/97
S1-8	Nov 15/00	S1-16 blank	Feb 3/97

SERVICE BULLETIN CONFIGURATION LIST

The following is a list of Service Bulletins that are applicable to the operation of the airplane, and have been incorporated into this supplement. This list contains only those Service Bulletins that are currently active.

		Airplane		
		Unit	Revision	Incorporated
<u>Number</u>	Title	Effectivity	<u>Incorporation</u>	<u>In Airplane</u>

SUPPLEMENT

BENDIX/KING KX 155A VHF NAV/COMM with KI 208 or KI 209A INDICATOR HEAD

SECTION 1 GENERAL

The Bendix/King KX 155A VHF Nav/Comm, shown in Figure 1, consists of a panel-mounted receiver-transmitter and a KI 208 or KI 209A Indicator.

The set includes a 760-channel VHF communications receiver-transmitter and a 200-channel VHF navigation receiver. A 40-channel glide- slope receiver is also included if the KI 209A indicator is used. The communications receiver-transmitter receives and transmits signals between 118.00 and 136.975 MHz with 25-kHz spacing. Optional 8.33 kHz (2280 channel) Comm is available. The navigation receiver receives VOR and localizer signals between 108.00 and 117.95 MHz in 50-kHz steps. The glide slope receiver is automatically tuned when a localizer frequency is selected. The circuits required to interpret the VOR and localizer signals are also an integral part of the Nav receiver.

Large self-dimming gas discharge readouts display both the communications and navigation operating frequencies. The KX-155A's "flip-flop" preselect feature enables you to store one frequency in the standby display while operating on another and then interchange them instantly with the touch of a button. Both the active (COMM) and the standby (STBY) frequencies may be displayed at all times and are stored in nonvolatile memory without drain on the aircraft battery. KX 155A has 32 programmable comm channels, a stuck microphone alert and transmitter shutdown, Bearing To/From radial mode, course deviation indicator mode and an elapsed timer mode.

Nov 15/00 S1-3

The Comm portion incorporates an automatic squelch. To override the automatic squelch, the Comm volume control knob is pulled out. Push the knob back in to reactivate the automatic squelch. A "T" will be displayed during transmit and "R" during valid signal reception.

The Nav portion uses the pull out feature of the Nav volume control to receive the Nav signal Ident. Pull the volume control knob out to hear the Ident signal plus voice. Push the knob in to attenuate the Ident signal and still hear Nav voice.

All controls for the Nav/Comm, except those for navigation course selection, are mounted on the front panel of the receiver-transmitter. Control lighting is provided by NAV/COMM interior lighting and the instrument panel flood lighting system. Operation and description of the audio selector panel used in conjunction with this radio is shown and described in Supplement 3 in this section.

NOTE

The unit has a stuck microphone alert feature. If the microphone is keyed continuously for greater than 33 seconds, the transmitter stops transmitting and the active Comm frequency flashes to alert the pilot of the stuck mic condition.




Figure 1. Bendix/King KX 155A VHF NAV/COMM with KI 208 or KI 209A Indicator Head (Sheet 1 of 7)

NAV FUNCTION DISPLAYS

109.60 № 030 - + ^
VOR MODE: ACTIVE/BEARING, CDI FORMAT
109.60 g 030 FLAG
VOR MODE: ACTIVE/BEARING, FLAG DISPLAY
109.60 030 ™
VOR MODE: ACTIVE "BEARING TO" FUNCTION DISPLAY
109.60 ^{to})
VOR MODE: ACTIVE/BEARING, FLAG DISPLAY
110.90 LOC -+

LOCALIZER MODE: FREQUENCY/CDI FORMAT

Figure 1. Bendix/King KX 155A VHF NAV/COMM with KI 208 or KI 209A Indicator Head (Sheet 2 of 7)

- 1. OPERATING COMM FREQUENCY DISPLAY -- Displays COMM ACTIVE and COMM STANDBY frequencies with a "T" between them to indicate TRANSMIT and an "R" to indicate RECEIVE modes of operation.
- 2. OPERATING NAV FREQUENCY DISPLAY -- The right portion of the display is allocated to NAV receiver ACTIVE and STANDBY information. The frequency channeling is similar to the COMM when operating in the frequency mode. The NAV ACTIVE and STANDBY frequencies are stored in the memory on power down and return on power up.
- 3. NAV STANDBY/OBS/Bearing/Radial/Timer Display -- The right side of the NAV display is controlled by the MODE SELECTOR BUTTON (see #7 below). With an active VOR frequency, this portion of the display shows the STANDBY frequency, OBS setting for the internal CDI, the bearing to the VOR station, radial from the VOR station, or a count-up/count-down timer. With an active localizer frequency, this portion of the display shows the standby frequency, the letters "LOC", or count-up/count-down timer.
- 4. NAV FREQUENCY SELECTOR KNOB (SMALL) -- Operates in 50 kHz steps. The NAV receiver's lower and upper frequency limits are 108.00 MHz and 117.95 MHz. Exceeding the upper limit of frequency band will automatically return to the lower limit and vice versa. A clockwise rotation will increase (inc) the previous frequency while a counterclockwise rotation will decrease (dec) the previous frequency.
- 5. NAV FREQUENCY SELECTOR KNOB (LARGE) -- Operates in 1 MHz steps. The frequency inc/dec operates the STANDBY frequency display. A clockwise rotation will increase the previous frequency while a counterclockwise rotation will decrease the previous frequency. Exceeding the upper limit of the frequency band will automatically return to the lower limit and vice versa.

Figure 1. Bendix/King KX 155A VHF NAV/COMM with KI 208 or KI 209A Indicator Head (Sheet 3 of 7)

Feb 3/97 S1-7

- 6. NAV/FREQUENCY TRANSFER BUTTON () -- Interchanges the NAV Active and STANDBY frequencies. Depressing the NAV frequency transfer button for 2 seconds or more will cause the display to go into the ACTIVE ENTRY mode. Only the ACTIVE frequency will be displayed and it can be directly changed by using the NAV inc/dec knobs. The display will return to the ACTIVE/STANDBY mode when the NAV frequency transfer button is pushed.
- 7. MODE SELECTOR BUTTON -- Depressing the mode button will cause the NAV display to go from the ACTIVE/STANDBY format to the ACTIVE/CDI (Course Deviation Indicator) format. In the CDI mode, the frequency inc/dec knob (pushed in) channels the ACTIVE frequency. When the ACTIVE window is tuned to a VOR frequency, the standby frequency area is replaced by a three digit OBS (Omni Bearing Selector) display. The desired OBS course can be selected by pulling out the inner NAV frequency knob and turning it. This OBS display is independent of any OBS course selected on an external CDI. An "OBS" in the middle of the NAV display will flash while the inner NAV frequency knob is pulled out. The CDI is displayed on the line below the frequency/OBS. When the ACTIVE window is tuned to a localizer frequency, the standby frequency area is replaced by "LOC". When the received signal is too weak to ensure accuracy the display will "FLAG".

Depressing the mode button again will cause the NAV display to go from the ACTIVE/CDI format to the ACTIVE/BEARING format. In the BEARING mode, the frequency inc/dec knob channels the ACTIVE frequency window. Depressing the frequency transfer button will cause the ACTIVE frequency to be placed in blind storage and the STANDBY frequency (in blind storage) to be displayed in the ACTIVE window display. In bearing mode, the right hand window of the NAV display shows the bearing TO the station. When a too weak or invalid VOR signal is received the display flags (dashes).

Figure 1. Bendix/King KX 155A VHF NAV/COMM with KI 208 or KI 209A Indicator Head (Sheet 4 of 7)

Another push of the mode button will cause the NAV display to go from the ACTIVE/BEARING format to the ACTIVE/RADIAL format. In the RADIAL mode, the frequency inc/dec knobs channel the ACTIVE frequency window and depressing the frequency transfer button will cause the ACTIVE frequency to be placed in blind storage and the STANDBY frequency (in blind storage) to be displayed in the ACTIVE window display. In radial mode of operation, the right hand window of NAV display shows the radial FROM the station. When a too weak or invalid VOR signal is received the display flags (dashes).

Another push of the mode button will cause the unit to go into the TIMER mode. When the unit is turned on, the elapsed timer (ET) begins counting upwards from zero. The timer can be stopped and reset to zero by pushing the NAV frequency transfer button for 2 seconds or more causing the ET on the display to flash. In this state, the timer can be set as a countdown timer or the elapsed timer can be restarted. The countdown timer is set by using the NAV frequency inc/dec knobs to set the desired time and then pushing the NAV frequency transfer button to start the timer. The large knob selects minutes, the small knob in the "in" position selects 10 second intervals, and the small knob in the "out" position selects individual seconds. After the countdown timer reaches zero, the counter will begin to count upwards indefinitely while flashing for the first 15 seconds. When the elapsed timer is reset to zero it may be restarted again by momentarily pushing the NAV frequency transfer button.

8. NAV/VOLUME CONTROL (PULL IDENT) -- Adjusts volume of navigation receiver audio. When the knob is pulled out, the Ident signal plus voice may be heard. The volume of voice/ident can be adjusted by turning this knob.

Figure 1. Bendix/King KX 155A VHF NAV/COMM with KI 208 or KI 209A Indicator Head (Sheet 5 of 7)

Feb 3/97 S1-9

- 9. COMM FREQUENCY SELECTOR KNOB (INNER) -- This smaller knob is designed to change the indicated frequency in steps of 50-kHz when it is pushed in, and in 25-kHz steps when it is pulled out. For 8.33 kHz versions, channels are incremented in 25 kHz steps with the knob pushed in and 8.33 kHz with the knob pulled out.
- 10. COMM FREQUENCY SELECTOR KNOB (OUTER) -- The outer, larger selector knob is used to change the MHz portion of the frequency display. At either band-edge of the 118-136 MHz frequency spectrum, an offscale rotation will wrap the display around to the other frequency band-edge (i.e., 136 MHz advances to 118 MHz).
- 11. CHANNEL BUTTON -- Pressing the CHAN button for 2 or more seconds will cause the unit to enter the channel program (PG) mode. Upon entering the channel program mode, the channel number will flash indicating that it can be programmed. The desired channel can be selected by turning the comm kHz knob. The channel frequency can be entered by pushing the comm transfer button which will cause the standby frequency to flash. The comm frequency knobs are then used to enter the desired frequency. If dashes (located between 136 MHz and 118 MHz) are entered instead of a frequency, the corresponding channel is skipped in channel selection mode. Additional channels may be programmed by pressing the COMM transfer button and using the same procedure. The channel information is saved by pushing the CHAN button which will also cause the unit to return to the previous frequency entry mode.

The channel selection mode (CH) can then be entered by momentarily pushing the CHAN button. The comm frequency knobs can be used to select the desired channel. The unit will automatically default to the previous mode if no channel is selected within 2 seconds after entering the channel selection mode. The unit is placed in the transmit mode by depressing a mic button.

Figure 1. Bendix/King KX 155A VHF NAV/COMM with KI 208 or KI 209A Indicator Head (Sheet 6 of 7)

S1-10 Feb 3/97

12. COMM FREQUENCY TRANSFER BUTTON () -- Interchanges the frequencies in the USE and STANDBY displays. To tune the radio to the desired operating frequency, the desired frequency must be entered into the standby display and then the transfer button must be pushed. This will trade the contents of the active and standby displays. The operating frequency can also be entered by accessing the ACTIVE ENTRY (direct tune) mode which is done by pushing the COMM TRANSFER button for 2 or more seconds. In the direct tune mode, only the active part of the display is visible. The desired frequency can be directly entered into the display. Push the COMM TRANSFER button again to return to the active/standby display.

The transceiver is always tuned to the frequency appearing in the ACTIVE display. It is, therefore, possible to have two different frequencies stored in the ACTIVE and STANDBY displays and to change back and forth between them at the simple push of the transfer button.

- 13. COMM VOLUME CONTROL (OFF/PULL/TEST) -- Rotate the VOL knob clockwise from the OFF position. Pull the VOL knob out and adjust for desired listening level. Push the VOL knob back in to actuate the automatic squelch. The VOL knob may also be pulled out to hear particularly weak signals.
- 14. VOR/Localizer Needle or CDI needle.
- 15. Glideslope Flag
- 16. TO-FROM-NAV FLAG
- 17. Azimuth Card
- 18, OBS Knob
- 19. Glideslope Needle

Figure 1. Bendix/King KX 155A VHF NAV/COMM with KI 208 or KI 209A Indicator Head (Sheet 7 of 7)

Dec 1/97 S1-11

SECTION 2 LIMITATIONS

There is no change to the airplane limitations when this avionic equipment is installed.

SECTION 3 EMERGENCY PROCEDURES

There is no change to the airplane emergency procedures when this avionic equipment is installed. However, if the frequency readouts fail, the radio will remain operational on the last frequency selected. If either frequency transfer button is pressed and held while power is applied to the unit, the unit wakes up with 120.00 MHz in the COMM use frequency and 110.00 MHz in the NAV active frequency, with both COMM and NAV in the active entry mode. This will aid the pilot in blind tuning the radio.

SECTION 4 NORMAL PROCEDURES

COMMUNICATION RECEIVER-TRANSMITTER OPERATION:

- 1. OFF/PULL/TEST Volume Control -- Turn clockwise; pull out and adjust to desired audio level; push control back in to activate the automatic squelch.
- 2. MIC Selector Switch (on audio control panel) -- SET to COMM 1.
- 3. SPEAKER Selector (on audio control panel) -- SET to desired mode.
- 4. COMM Frequency Selector Knobs -- Select desired operating frequency.
- 5. COMM Transfer Button -- PRESS to transfer desired frequency from the STBY display into the COMM display.

6. Mic Button:

a. To transmit -- Press button and speak in microphone.

NOTE

During COMM transmission, a lighted "T" will appear between the "COMM" and "STBY" displays to indicate that the transceiver is operating in the transmit mode.

b. To Receive -- RELEASE mike button.

NAVIGATION RECEIVER OPERATION:

 NAV Frequency Selector Knobs -- SELECT desired operating frequency in "STBY" display.

2. NAV TRANSFER BUTTON -- PRESS to transfer desired frequency from the "STBY" display into the "NAV" display.

- 3. Speaker Selector (on audio control panel) -- SET to desired mode..
- 4. NAV Volume Control -
 - a. ADJUST to desired audio level.
 - b. PULL out to identify station.

VOR OPERATION:

Channel the NAV Receiver to the desired VOR and monitor the audio to positively identify the station. To select an OBS course, turn the OBS knob to set the desired course under the lubber line. When a signal is received, the NAV flag will pull out of view and show a "TO" or "FROM" flag as appropriate for the selected course.

LOC OPERATION

Localizer circuitry is energized when the NAV Receiver is channeled to an ILS frequency. Monitor the LOC audio and positively identify the station. The NAV flag will be out of view when the signal is of sufficient strength to be usable.

4

GLIDESLOPE OPERATION

The glideslope receiver is automatically channeled when a localizer frequency is selected. A separate warning flag is provided to indicate usable signal conditions.

PILOT CONFIGURATION

This mode can be accessed by pressing and holding the NAV Mode Button for more than 2 seconds and then pressing the Nav Frequency Transfer Button for an additional 2 seconds, while continuing to hold the NAV Mode Button. When the Pilot Config Mode is entered the unit will show the "SWRV" mnemonic which is the unit software revision level. Adjustment pages can be accessed by MODE button presses.

The pilot may adjust two parameters in the pilot configuration, the display minimum brightness and sidetone volume level. Minimum Brightness (BRIM) will have a range of 0-255. The dimmest is 0 and the brightest is 255. Sidetone volume level is adjusted when SIDE is displayed. Values from 0-255 may be selected with 0 being least volume, 255 being the greatest.

Adjustment	Mnemonic	Min Level	Max Level
Software Revision Number	SWRV		
Minimum Display Brightness	BRIM	0	255
Sidetone Level	SIDE	0	255

Subsequent presses of the MODE button sequences through SWRV, BRIM, SIDE, and then back to SWRV.

Pressing the NAV Transfer Button momentarily exits Pilot configuration mode. The NAV returns to its pre-Pilot Config state with the new brightness and sidetone levels stored in nonvolatile memory.

SECTION 5 PERFORMANCE

There is no change to the airplane performance when this avionic equipment is installed. However, the installation of an externally mounted antenna, or several related antennas, will result in a minor reduction in cruise performance.

		,
	20	



Pilot's Operating Handbook and FAA Approved Airplane Flight Manual

CESSNA MODEL 182S

AIRPLANES 18280001 AND ON

SUPPLEMENT 2

BENDIX/KING KT 76C
TRANSPONDER WITH BLIND ENCODER

Member of GAMA
3 February 1997

COPYRIGHT © 1997 CESSNA AIRCRAFT COMPANY WICHITA, KANSAS, USA

182SPHUS-S2-01

Revision 1 - 15 November 2000

S2-1

SUPPLEMENT 2

BENDIX/KING KT 76C TRANSPONDER with BLIND ENCODER

The following Log of Effective Pages provides the date of issue for original and revised pages, as well as a listing of all pages in the Supplement. Pages which are affected by the current revision will carry the date of that revision

Revision Level Date of Issue

0 (Original)

Feb. 3, 1997

-

Nov. 15, 2000

LOG OF EFFECTIVITY PAGES

PAGE	DATE	PAGE	DATE
Title (S2-1)	Nov 15/00	S2-6	Nov 15/00
S2-2	Nov 15/00	S2-7	Nov 15/00
S2-3	Nov 15/00	S2-8	Feb 3/97
S2-4	Feb 3/97	S2-9	Feb 3/97
S2-5	Feb 3/97	S2-10 blank	Feb 3/97

SERVICE BULLETIN CONFIGURATION LIST

The following is a list of Service Bulletins that are applicable to the operation of the airplane, and have been incorporated into this supplement. This list contains only those Service Bulletins that are currently active.

		Airplane		
		Unit	Revision	Incorporated
Number	<u>Title</u>	Effectivity	<u>Incorporation</u>	<u>In Airplane</u>

SUPPLEMENT

BENDIX/KING KT 76C TRANPONDER with BLIND ENCODER

SECTION 1

GENERAL

The Bendix/King Transponder (Type KT 76C), shown in Figure 1, is the airborne component of an Air Traffic Control Radar Beacon System (ATCRBS). The transponder enables the ATC ground controller to "see" and identify more readily the aircraft on the radarscope. The blind encoder (SSD120-20) enables the transponder to automatically report aircraft altitude to ATC.

The Bendix/King Transponder system consists of a panel-mounted unit and an externally-mounted antenna. The transponder receives interrogating pulse signals on 1030 MHz and transmits coded pulse-train reply signals on 1090 MHz. It is capable of replying to Mode A (aircraft identification) and also to Mode C (altitude reporting) interrogations on a selective reply basis on any of 4096 information code selections. A sidewall-mounted SSD120-20 Blind Encoder is included in the avionic configuration, the transponder can provide altitude reporting in 100-foot increments between -1000 and +20,000 feet.


The KT 76C features microprocessor and LSI (Large Scale Integrated) control. Mode and code selection are performed using the rotary knob and numeric buttons and all functions including the flight level altitude are presented on a gas discharge display. All display segments are automatically dimmed by a photocell type sensor.

Nov 15/00 S2-3

A VFR programming sequence, described in Section 4, allows the pilot to preprogram any single code such as "1200" into the KT 76C. Pressing the VFR button instantly returns the KT 76C to the preprogrammed code without having to manually enter "1200".

All Bendix/King Transponder operating controls are located on the front panel of the unit. Functions of the operating controls are described in Figure 1.

S2-4 Feb 3/97



- IDENT BUTTON (IDT) When depressed, selects special identifier pulse to be transmitted with transponder reply to effect immediate identification of the airplane on the ground controller's display. ("R" will illuminate steadily for approximately 18 seconds. Button illumination is controlled by the avionic light dimming rheostat.
- 2. ALTITUDE DISPLAY Displays the pressure altitude on the left side of the display. The display is in hundreds of feet. "FL" is annunciated to indicate Flight Level altitude. Flight Level is a term to indicate that the altitude is not true altitude, but barometric altitude which is not corrected for local pressure. For Example, "FL-040" corresponds to an altitude of 4000 feet, meaning sea level pressure of 29.92 inches of mercury.

The Flight Level altitude is only displayed when the altitude reporting is enabled, i.e. in Altitude mode. If an invalid code from the altimeter is detected dashes will appear in the altitude window. Altitude reporting is disabled if the altitude window is blank or has dashes.

Figure 1. Bendix/King KT 76C Transponder with Blind Encoder (Sheet 1 of 2)

- 3. MODE ANNUNCIATORS Displays the operating mode of the transponder.
- 4. REPLY INDICATOR (R) "R" is illuminated momentarily when the transponder is replying to a valid interrogation and during the 18 ±2 seconds following the initiation of an Ident.
 - 5. MODE SELECTOR KNOB Controls application of power and selects transponder operating mode as follows:
 - OFF Turns set off.
 - SBY Turns set on for standby power and code selection. "SBY" is annunciated.
 - TST Self-test function. The transmitter is disabled. All display segments will illuminate.
 - ON Turns set on and enables transponder to transmit Mode A (aircraft identification) reply pulses. ON is annunciated.
 - ALT Turns set on and enables transponder to transmit either Mode A (aircraft identification) reply pulses and Mode C (altitude reporting) pulses selected automatically by the interrogating signal. ALT is annunciated.
 - 6. VFR CODE BUTTON (VFR) Pressing the VFR Button will cause a pre-programmed Mode A reply code to supersede whatever Mode A reply code was previously in use. Button illumination is controlled by the RADIO LT dimming rheostat
 - 7. CLEAR BUTTON (CLR) -- Pressing the CLR button will delete the last Mode A code digit entered.
 - 8. NUMERIC KEYS 0-7 Selects assigned Mode A reply code. The new code will be transmitted after a 5-second delay.

Figure 1. Bendix/King KT 76C Transponder with Blind Encoder (Sheet 2 of 2)

S2-6 Nov 15/00

SECTION 2 LIMITATIONS

There is no change to the airplane limitations when this avionic equipment is installed.

SECTION 3 EMERGENCY PROCEDURES

TO TRANSMIT AN EMERGENCY SIGNAL:

- 1. Mode Selector Knob -- ALT.
- 2. Numeric Keys 0-7 -- SELECT 7700 operating code.

TO TRANSMIT A SIGNAL REPRESENTING LOSS OF ALL COMMUNICATIONS (WHEN IN A CONTROLLED ENVIRONMENT):

- 1. Mode Selector Knob -- ALT.
- 2. Numeric Keys 0-7 -- SELECT 7600 operating code.

SECTION 4 NORMAL PROCEDURES

BEFORE TAKEOFF:

1. Mode Selector Knob -- SBY.

TO TRANSMIT MODE A (AIRCRAFT IDENTIFICATION) CODES IN FLIGHT:

1. Numeric Keys 0-7 -- SELECT assigned code..

2. Mode Selector Knob -- ON.

NOTES

- During normal operation with Mode Selector Knob in ON position, reply indicator flashes, indicating transponder replies to interrogations.
- Mode A reply codes are transmitted in ALT also; however, Mode C codes are suppressed when the Mode Selector Knob is positioned to ON.
- 3. IDT Button -- DEPRESS momentarily when instructed by ground controller to "squawk IDENT" ("R" will illuminate steadily indicating IDENT operation).

TO TRANSMIT MODE C (ALTITUDE REPORTING) CODES IN FLIGHT:

- 1. Transponder Code Selector Knob -- SELECT assigned code.
- 2. Mode Selector Knob -- ALT.

NOTES

- When directed by ground controller to "stop altitude squawk", turn Mode Selector Knob to ON for Mode A operation only.
- Altitude transmitted by the transponder for altitude squawk and displayed on the KT 76C panel is pressure altitude (referenced to 29.92") and conversion to indicated altitude is done in the ATC computers.

TO SELF-TEST TRANSPONDER OPERATION:

- 1. Mode Selector Knob -- TST Check all displays.
- 2. Mode Selector Knob -- SELECT desired function.

TO PROGRAM VFR CODE:

- 1. Mode Selector Knob -- SBY.
- 2. Numeric Keys 0-7 -- SELECT desired VFR code.
- 3. IDT Button -- PRESS AND HOLD.
 - a. VFR Code Button -- PRESS (while still holding IDT button) to place new VFR code in nonvolatile memory for subsequent call up.

SECTION 5 PERFORMANCE

There is no change to the airplane performance when this avionic equipment is installed. However, the installation of an externally-mounted antenna, or related external antennas, will result in a minor reduction in cruise performance.

	2007	
24.7		12
		3.5
		W
		X.
1		



Pilot's Operating Handbook and FAA Approved Airplane Flight Manual

CESSNA MODEL 182S

AIRPLANES 18280001 AND ON

SUPPLEMENT 3

BENDIX/KING KMA 26 AUDIO SELECTOR PANEL

Member of GAMA
3 February 1997

Revision 1 - 15 November 2000

COPYRIGHT © 1997 CESSNA AIRCRAFT COMPANY WICHITA, KANSAS, USA

182SPHUS-S3-01

SUPPLEMENT 3

BENDIX/KING KMA 26 AUDIO SELECTOR PANEL

The following Log of Effective Pages provides the date of issue for original and revised pages, as well as a listing of all pages in the Supplement. Pages which are affected by the current revision will carry the date of that revision

Revision Level Date of Issue

0 (Original) Feb 3, 1997 Nov. 15, 2000

LOG OF EFFECTIVITY PAGES

PAGE	DATE	PAGE	DATE
Title (S3-1)	Nov 15/00	S3-5	Feb 3/97
S3-2	Nov 15/00	S3-6	Feb 3/97
S3-3	Feb 3/97	S3-7	Nov 15/00
S3-4	Feb 3/97	S3-8	Feb 3/97

SERVICE BULLETIN CONFIGURATION LIST

The following is a list of Service Bulletins that are applicable to the operation of the airplane, and have been incorporated into this supplement. This list contains only those Service Bulletins that are currently active.

		Airplane		
		Unit	Revision	Incorporated
Number	Title	Effectivity	Incorporation	In Airplane

SUPPLEMENT

BENDIX/KING KMA 26 AUDIO SELECTOR PANEL

SECTION 1 GENERAL


The Bendix/King KMA 26 Audio Selector Panel is a combination audio amplifier, an audio distribution panel intercom, and a marker beacon receiver. The audio amplifier is for amplification of the audio signals for the speaker system. All receiver audio distribution functions are controlled by two rows of pushbuttons. A rotary selector switch on the right side of the console connects the microphone to either EMG, Com 1, Com 2, Com 3 or PA (Unused position). All operating controls are shown and described in Figure 1.

A crystal-controlled superheterodyne marker beacon receiver with 3-light presentation is incorporated within the unit. Dimming circuitry for the marker lamps automatically adjusts brightness appropriate to the cockpit ambient light level. Hi and Lo sensitivity and lamp test functions are also provided.

Light dimming for the audio control panel is manually controlled by the RADIO light rheostat knob.

MARKER FACILITIES

MARKER	IDENTIFYING TONE	LIGHT* White	
Inner, Airway & Fan	Continuous 6 dots/sec (3000 Hz)		
Middle	Alternate dots and dashes (1300 Hz)	Amber	
Outer	2 dashes/sec (400 Hz)	Blue	
	*When the identifying tone is keyed, the respective indicating light will blink accordingly.		



 MARKER BEACON ANNUNCIATOR LIGHTS -- The three-light marker beacon receiver built into the KMA 26 gives a visual and aural signal when the ship's antenna passes over a 75 MHz beacon. The blue, amber, and white lights on the faceplate, as well as the audio tones, identify the beacon type.

INNER, AIRWAY and FAN -- Light illuminates white to indicate passage of ILS inner, airway or fan marker beacons.

OUTER -- Light illuminates blue to indicate passage of outer marker beacon.

MIDDLE -- Light illuminates amber to indicate passage of middle marker beacon.

- 2. PHOTOCELL FOR AUTOMATIC DIMMING OF MARKER BEACON LIGHTS AND SELECT BUTTON -- The photocell in the faceplate automatically dims the marker lights as well as the green annunciators in the Speaker Audio Select Buttons for night operation.
- 3. MARKER BEACON SENSITIVITY LAMP AND TEST SWITCH --The "MKR" Audio Select button must be pushed so that the green annunciator is illuminated for the marker beacon to receive to provide an audio signal at beacon passage. When this switch is on "HI SENS" (upper) position, the high sensitivity is selected which permits you to hear the outer marker tone about a mile out. At this point you may select the the "LO SENS" (middle) position to temporarily silence the tone. It will start to sound again when you are closer to the marker, giving you a more precise indication of its location.

Figure 1. Bendix/King KMA 26 Audio Selector Panel (Sheet 1 of 3)

S3-4

- 4. AUDIO SELECT BUTTONS -- Push button audio selection is available for three Communications receivers ("COM 1", "COM 2", and "COM 3"), two Navigation receivers ("NAV 1" and "NAV 2"), the internal Marker Beacon receiver ("MKR"), one DME, one ADF, and one additional auxiliary receiver ("AUX"). The "AUX" position could be used, for example, for a second DME or ADF. When a receiver's audio is selected, the green annunciator illuminates at the bottom of the button. Push the button again to deselect the receiver's audio.
- 5. MICROPHONE SELECTOR SWITCH (MIC) -- Used to select the desired transmitter for the cockpit microphones. The "C1", "C2", and "C3" positions are for transmitting on the Com 1, Com 2, and Com 3 communications transceivers, respectively. The "EMG" (emergency) position is used to bypass the KMA 26's audio amplifier and directly connects Com 1 to the pilot's microphone and headphones. This provides a fail-safe method of communication should the unit fail. The "PA" position may be selected when the aircraft is configured with a passenger address capability. The "Auto Com" feature always provides automatic headphone audio selection to match the Com transmitter in use. To add speaker audio, simply push the Speaker Select Switch (inner right knob) to the "in" position. Pulling the switch to the "out" position removes speaker audio.
- SPEAKER SELECT (PUSH SPKR) SWITCH -- With the Speaker Select Switch pushed in, both headphone and cabin speaker audio will be heard. Headphone audio is active full-time. Headphone audio cannot be deselected.
- 7. MONITOR SELECT (MONI) BUTTON -- When activated, if Com 1 is selected on the Microphone Selector Switch then Com 2 audio is automatically routed to the speaker. Or if Com 2 is selected on the Microphone Selector Switch, then Com 1 is routed to the speaker. Pressing the "MONI" button again will disable the feature. Initially when "MONI" is selected the green annunciators in the button flash for approximately 5 seconds, then remains steady while the Com annunciation returns to its previous state.
- 8. CREW INTERCOM VOLUME (VOL CREW) KNOB and INTERCOM VOX SENSITIVITY SET (INTERCOM PUSH VOX) SWITCH -- Inside knob adjusts Pilot and Copilot intercom volume. Intercom operation is voice activated (VOX), where intercom becomes active automatically when a crew member or passenger begins to speak. Set the intercom VOX squelch by momentarily pressing and releasing the left inner knob when no one is speaking.

Figure 1. Bendix/King KMA 26 Audio Selector Panel (Sheet 2 of 3)

- 9. PASSENGER INTERCOM VOLUME (VOL PASS) KNOB -- Adjusts passenger intercom volume.
- 10. INTERCOM MODE SELECT SWITCH -- Has three modes "ALL", "CREW", AND "PILOT" which are selected with the toggle switch on the lower left side on the faceplate. In the "ALL" position the pilot, copilot, and passengers are all on the same intercom "loop" and everyone hears the radios. In the "CREW" position the pilot and copilot are on one intercom loop and can hear the radios while the passengers have their own dedicated intercom and do not hear the radios. In the "PILOT" mode the pilot hears the radios but is isolated from the intercom while the copilot and passengers are on the same intercom loop and do not hear the radios.

When either the "ALL" or "CREW" intercom modes are selected, the pilot's and copilot's intercom volume is controlled by rotating the Crew Intercom Volume Knob (left inner knob) while the passenger's volume is controlled by rotating the Passenger Intercom Volume Knob (left outer knob). When the "PILOT" intercom mode is selected, the copilot's and passenger's volume is controlled with the Passenger Intercom Volume Knob. Remember, the volume knobs on the KMA 26 control intercom volume only, not the receiver's volume.

 MARKER MUTE BUTTON -- Mutes currently active marker beacon audio.

Figure 1. Bendix/King KMA 26 Audio Selector Panel (Sheet 3 of 3)

SECTION 2 LIMITATIONS

There is no change to the airplane limitations when this avionic equipment is installed.

SECTION 3 EMERGENCY PROCEDURES

In the event of a failure of the audio amplifier in the KMA 26, as evidenced by the inability to transmit in COM 1, 2 or 3.

1. MIC Selector Switch -- EMG.

NOTE

This action bypasses the KMA 26 audio amplifier and connects the pilot's mic/head set directly to COM 1.

SECTION 4 NORMAL PROCEDURES

AUDIO CONTROL SYSTEM OPERATION:

- 1. MIC Selector Switch -- Turn to desired transmitter.
- 2. SPEAKER and Audio Select Button(s) -- SELECT desired receiver(s).

NOTES

Rotation of the MIC selector switch selects the Com audio automatically.

Nov 15/00 S3-7

MARKER BEACON RECEIVER OPERATION:

- 1. TEST Position -- HOLD toggle down momentarily to verify all lights are operational.
- 2. SENS Selections -- Select HI sensitivity for airway flying or LO for ILS/LOC approaches.

SECTION 5 PERFORMANCE

There is no change to the airplane performance when this avionic equipment is installed. However, the installation of an externally mounted antenna or related external antennas, will result in a minor reduction in cruise performance.



Pilot's Operating Handbook and FAA Approved Airplane Flight Manual

CESSNA MODEL 182S AIRPLANES 18280001 AND ON

POINTER MODEL 3000-11 OR MODEL 4000-11 EMERGENCY LOCATOR TRANSMITTER

SUPPLEMENT 4

Member of GAMA
3 February 1997

COPYRIGHT © 1997 CESSNA AIRCRAFT COMPANY WICHITA, KANSAS, USA

182SPHUS-S4-01

Revision 1 - 15 November 2000

S4-1

SUPPLEMENT 4

POINTER MODEL 3000-11 OR MODEL 4000-11 EMERGENCY LOCATOR TRANSMITTER (ELT)

The following Log of Effective Pages provides the date of issue for original and revised pages, as well as a listing of all pages in the Supplement. Pages which are affected by the current revision will carry the date of that revision

Revision Level Date of Issue

0 (Original) Feb 3, 1997 1 Nov. 15, 2000

LOG OF EFFECTIVITY PAGES

PAGE	DATE	PAGE	DATE
Title (S4-1) S4-2	Nov 15/00 Nov 15/00	S4-6 S4-7	Nov 15/00 Nov 15/00
S4-3	Nov 15/00	S4-8	Nov 15/00
S4-4	Nov 15/00	S4-9	Nov 15/00
S4-5	Nov 15/00	S4-10	Nov 15/00

SERVICE BULLETIN CONFIGURATION LIST

The following is a list of Service Bulletins that are applicable to the operation of the airplane, and have been incorporated into this supplement. This list contains only those Service Bulletins that are currently active.

		Airplane		
		Unit	Revision	Incorporated
Number	<u>Title</u>	Effectivity	Incorporation	<u>In Airplane</u>

SUPPLEMENT

POINTER MODEL 3000-11 OR 4000-11 EMERGENCY LOCATOR TRANSMITTER (ELT)

SECTION 1

GENERAL

This supplement provides information which must be observed when operating the Pointer Model 3000-11 or 4000-11 Emergency Locator Transmitter.


Both the Pointer Model 3000-11 ELT (which incorporates the english placard) and Model 4000-11 ELT (which incorporates the bilingual placard) consist of a self-contained, dual-frequency, solid-state transmitter powered by a battery pack consisting of five alkaline "C" cell batteries and is automatically activated by a deceleration sensing inertia "G" switch, which is designed to activate when the unit senses longitudinal inertia forces as required in TSO-C91A. Also, a remote switch/annunciator is installed on the top right hand side of the copilot's instrument panel for control of the ELT from the flight crew station. The annunciator, which is in the center of the rocker switch, illuminates when the ELT transmitter is transmitting. The ELT emits an omni-directional signal on the international distress frequencies of 121.5 MHz and 243.0 MHz. General aviation and commercial aircraft, the FAA and CAP monitor 121.5 MHz, and 243.0 MHz is monitored by the military.

The ELT is contained in a high impact, fire retardant, glass filled Lexon case with carrying handle and is mounted behind the aft cabin partition wall on the right side of the tailcone. To gain access to the unit, unfasten the turn fasteners on the aft cabin partition. The ELT is operated by a control panel at the forward facing end of the unit or by the remote switch/annunciator located on the top right hand portion of the copilot's instrument panel (see Figure 1).

Power for the transmitter is provided by an alkaline battery pack inside the transmitter case.

In accordance with FAA regulations, the ELT's battery pack must be replaced after 2 years shelf or service life or for any of the following reasons:

- a. After the transmitter has been used in an emergency situation (including any inadvertent activation of unknown duration).
- b. After the transmitter has been operated for more than one cumulative hour (e.g. time accumulated in several tests and inadvertent activation of known duration).
- c. On or before battery replacement date. Battery replacement date is marked on the battery pack and the label on the transmitter.






Figure 1. Pointer Model 3000-11 Emergency Locator Transmitter.



- 1. REMOTE CABLE JACK -- Connects to ELT remote switch/annunciator located on the copilot's instrument panel.
- 2. ANTENNA RECEPTACLE -- Connects to antenna mounted on top of tailcone.
- TRANSMITTER ANNUNCIATOR LIGHT -- Illuminates red to indicate the transmitter is transmitting a distress signal.
- 4. MASTER FUNCTION SELECTOR SWITCH (3-position toggle switch):
 - AUTO -- Arms transmitter for automatic activation if "G" switch senses a predetermined deceleration level.
 - ON -- Activates transmitter instantly. Used for test purposes and if "G" switch is inoperative. The ON position bypasses the automatic activation switch. (The red annunciator in the center of the remote switch/annunciator should illuminate).

- OFF/RESET -- Deactivates transmitter during handling, following rescue and to reset the automatic activation function. (The red annunciator in the center of the remote switch/annunciator should extinguish).
- 5. REMOTE SWITCH/ANNUNCIATOR (3-position rocker switch):
 ON -- Remotely activates the transmitter for test or
 emergency situations. Red annunciator in
 center of rocker switch illuminates to indicate
 that the transmitter is transmitting a distress
 signal.
 - AUTO -- Arms transmitter for automatic activation if "G" switch senses a predetermined deceleration level.
 - RESET -- Deactivates and rearms transmitter after automatic activation by the "G" switch. Red annunciator in center of rocker switch should extinguish.




Figure 2. Pointer Model 4000-11 Emergency Locator Transmitter (ELT).

- 1. REMOTE CABLE JACK -- Connects to ELT remote switch/annunciator located on the copilot's instrument panel.
- ANTENNA RECEPTACLE -- Connects to antenna mounted on top of tailcone.
- TRANSMITTER ANNUNCIATOR LIGHT -- Illuminates red to indicate the transmitter is transmitting a distress signal.

4. MASTER FUNCTION SELECTOR SWITCH (3-position toggle switch):

ON --

Activates transmitter instantly. Used for test purposes and if "G" switch is inoperative. The ON position bypasses the automatic activation switch. (The red annunciator in the center of the remote switch/annunciator should illuminate).

AUTO --

Arms transmitter for automatic activation if "G" switch senses a predetermined deceleration level.

OFF/RESET -- Deactivates transmitter during handling, following rescue and to reset the automatic activation function. (The red annunciator in the center of the remote switch/annunciator should extinguish).

5. REMOTE SWITCH/ANNUNCIATOR (3-position rocker switch):
ON -- Remotely activates the transmitter for test or
emergency situations. Red annunciator in
center of rocker switch illuminates to indicate
that the transmitter is transmitting a distress

signal.

AUTO -- Arms transmitter for automatic activation if "G" switch senses a predetermined deceleration level.

RESET -- Deactivates and rearms transmitter after automatic activation by the "G" switch. Red annunciator in center of rocker switch should extinguish.

SECTION 2 LIMITATIONS

Refer to Section 2 of the Pilot's Operating Handbook (POH).

SECTION 3 EMERGENCY PROCEDURES

Before performing a forced landing, especially in remote and mountainous areas, activate the ELT transmitter by positioning the remote switch/annunciator to the ON position. The annunciator in center of the rocker switch should be illuminated.

Immediately after a forced landing where emergency assistance is required, the ELT should be utilized as follows:

NOTE

The ELT remote switch/annunciator system could be inoperative if damaged during a forced landing. If inoperative, the inertia "G" switch will activate automatically. However, to turn the ELT OFF and ON again requires manual switching of the master function selector switch which is located on the ELT unit.

1. ENSURE ELT ACTIVATION:

a. Position remote switch/annunciator to the ON position even if annunciator light is already on.

b. If airplane radio is operable and can be safely used (no threat of fire or explosion), turn ON and select 121.5 MHz. If the ELT can be heard transmitting, it is working properly.

Ensure that antenna is clear of obstructions.

NOTE

When the ELT is activated, a decreasing tone will be heard before the typical warbling tone begins.

- 2. PRIOR TO SIGHTING RESCUE AIRCRAFT -- Conserve airplane battery. Do not activate radio transceiver.
- 3. AFTER SIGHTING RESCUE AIRCRAFT -- Position remote switch/annunciator to the RESET position and release to the AUTO position to prevent radio interference. Attempt contact with rescue aircraft with the radio transceiver set to a frequency of 121.5 MHz. If no contact is established, return the remote switch/annunciator to the ON position immediately.

4. FOLLOWING RESCUE -- Position remote switch/annunciator to the AUTO position, terminating emergency transmissions.

SECTION 4 NORMAL PROCEDURES

As long as the remote switch/annunciator is in the AUTO position and the ELT master function selector switch remains in the AUTO position, the ELT automatically activates when the unit senses longitudinal inertia forces as required in TSO-C91A.

Following a lightning strike, or an exceptionally hard landing, the ELT may activate although no emergency exists. If the remote switch/annunciator illuminates, the ELT has inadvertently activated itself. Another way to check is to select 121.5 MHz on the radio transceiver and listen for an emergency tone transmission. If the remote switch/annunciator is illuminated or an emergency tone is heard, position the remote switch/annunciator in the RESET position and release to the AUTO position.

The ELT must be serviced in accordance with FAR Part 91.207.

INSPECTION/TEST

 The emergency locator transmitter should be tested every 100 hours.

NOTE

Test should only be conducted within the first 5 minutes of each hour.

- Disconnect antenna cable from ELT.
- 3. Turn airplane battery switch and avionics power switches ON.
- 4. Turn airplane transceiver ON and set frequency to 121.5 MHz.
- 5. Place remote switch/annunciator in the ON position. The annunciator should illuminate. Permit **only three** emergency tone transmissions, then immediately reposition the remote switch/annunciator to the RESET position and release to the AUTO position.

- Place the ELT master function selector switch in the ON position. Verify that the transmitter annunciator light on the ELT and the remote switch/annunciator on the instrument panel are illuminated.
- 7. Place the ELT master function selector switch in the OFF/RESET position.
- 8. Reposition ELT master function selector switch to AUTO.
- 9. Reconnect antenna cable to ELT.

WARNING

A TEST WITH THE ANTENNA CONNECTED SHOULD BE APPROVED AND CONFIRMED BY THE NEAREST CONTROL TOWER.

NOTE

Without its antenna connected, the ELT will produce sufficient signal to reach the airplane transceiver, yet it will not disturb other communications or damage output circuitry.

After accumulated test or operation time equals 1 hour, battery pack replacement is required.

IN-FLIGHT MONITORING AND REPORTING

Pilot's are encouraged to monitor 121.5 MHz and/or 243.0 MHz while in flight to assist in identifying possible emergency ELT transmissions. On receiving a signal, report the following information to the nearest air traffic control facility:

- 1. Your position at the time the signal was first heard.
- 2. Your position at the time the signal was last heard.
- 3. Your position at maximum signal strength.
- 4. Your flight altitude and frequency on which the emergency signal was heard -- 121.5 MHz or 243.0 MHz. If possible, positions should be given relative to a navigation aid. If the aircraft has homing equipment, provide the bearing to the emergency signal with each reported position.

SECTION 5 PERFORMANCE

There is no change in airplane performance when the ELT is installed.



Pilot's Operating Handbook and FAA Approved Airplane Flight Manual

CESSNA MODEL 182S AIRPLANES 182S80001 AND ON

Member of GAMA
3 February 1997

COPYRIGHT © 1997 CESSNA AIRCRAFT COMPANY WICHITA, KANSAS, USA

182SPHUS-S5-03

Revision 3 - 20 May 1999

S5-1

BENDIX/KING KLN 89B GLOBAL POSITIONING SYSTEM (IFR)

The following Log of Effective Pages provides the date of issue for original and revised pages, as well as a listing of all pages in the Supplement. Pages which are affected by the current revision will carry the date of that revision

Revision Level	Date of Issue		
0 (Original)	Feb. 3, 1997 Dec. 1, 1997		
2	July 15, 1998		
3	May 20, 1999		

LOG OF EFFECTIVITY PAGES

DATE	PAGE	DATE
May 20/99	S5-11	May 20/99
May 20/99	S5-12	May 20/99
July 15/98	S5-13	May 20/99
July 15/98	S5-14	May 20/99
July 15/98	S5-15	May 20/99
May 20/99	S5-16	May 20/99
July 15/98	S5-17	May 20/99
July 15/98	S5-18	May 20/99
July 15/98	S5-19	May 20/99
July 15/98	S5-20 blank	May 20/99
	May 20/99 May 20/99 July 15/98 July 15/98 July 15/98 May 20/99 July 15/98 July 15/98 July 15/98	May 20/99 S5-11 May 20/99 S5-12 July 15/98 S5-13 July 15/98 S5-14 July 15/98 S5-15 May 20/99 S5-16 July 15/98 S5-17 July 15/98 S5-18 July 15/98 S5-19

BENDIX/KING KLN 89B GLOBAL POSITIONING SYSTEM (IFR)

SERVICE BULLETIN CONFIGURATION LIST

The following is a list of Service Bulletins that are applicable to the operation of the airplane, and have been incorporated into this supplement. This list contains only those Service Bulletins that are currently active.

Number	<u>Title</u>	Airplane Unit Effectivity	Revision Incorporation	Incorporated In Airplane
SB98-34- 01	KLN 89B NAVIGATION SYSTEM IFR NON- PRECISION APPROACH LIMITATION	182S80001 THRU 182S80257	7/15/98	

BENDIX/KING KLN 89B GPS NAVIGATION SYSTEM (IFR)

SECTION 1

GENERAL

WARNING

THE KLN 89B IS NOT AUTHORIZED FOR INSTRUMENT APPROACHES UNLESS THE OPERATIONAL REVISION STATUS IS UPGRADED TO "ORS 02" OR LATER, AS READ ON THE POWER-ON PAGE, AND THE HOST SOFTWARE IS UPGRADED TO "HOST 00880-0004" OR LATER, AS READ ON THE KLN 89B OTH 6 PAGE.

The KLN 89B GPS (Global Positioning System) is a three-dimensional precision navigation system based on 24 earth orbiting satellites. Receiver Autonomous Integrity Monitoring (RAIM) is a function that every IFR-certified GPS receiver must continuously perform to assure position accuracy. RAIM is available when 5 or more of these satellites are in view, or 4 satellites are in view and a barometrically corrected altitude input from the airplane's altimeter is made. Annunciation is provided if there are not enough satellites in view to assure position integrity.

Operational guidance for the KLN 89B GPS Navigation System is provided with the Bendix/King KLN 89B Pilot's Guide (supplied with the airplane). This Pilot's Guide should be thoroughly studied and VFR operations conducted so that you are totally familiar with the GPS system of navigation before actually using this equipment in IFR conditions.

The database card is an electronic memory containing information on airports, navaids, intersections, SID's, STAR's, instrument approaches, special use airspace, and other items of interest to the pilot.

Every 28 days, Bendix/King receives new database information from Jeppesen Sanderson for the North American database region. This information is processed and downloaded onto the database cards. Bendix/King makes these database card updates available to KLN 89B GPS users.

A CAUTION

THE DATABASE MUST BE UPDATED ONLY WHILE THE AIRCRAFT IS ON THE GROUND. THE KLN 89B DOES NOT PERFORM ANY NAVIGATION FUNCTION WHILE THE DATABASE IS BEING UPDATED.

NOTE

A current database is required by regulation in order to use the KLN 89B GPS system for nonprecision approaches.

Provided the KLN 89B navigation system is receiving adequate usable signals, it has been demonstrated capable of and has been shown to meet the accuracy specifications of: VFR/IFR en route oceanic and remote, en route domestic, terminal, and instrument approach (GPS, Loran-C, VOR, VOR-DME, TACAN, NDB, NDB-DME, RNAV) operation within the U.S. National Airspace System, North Atlantic Minimum Navigation Performance Specifications (MNPS) Airspace and latitudes bounded by 74° North and 60° South using the WGS-84 (or NAD 83) coordinate reference datum in accordance with the criteria of AC 20-138, AC 91-49, and AC 120-33. Navigation data is based upon use of only the global positioning system (GPS) operated by the United States.


Aircraft using GPS for oceanic IFR operations may use the KLN 89B to replace one of the other approved means of long range navigation. A single KLN 89B GPS installation may also be used on short oceanic routes which require only one means of long-range navigation.

NOTE

FAA approval of the KLN 89B does not necessarily constitute approval for use in foreign airspace.

NOTE

When the KLN 89B contains receiver software RCVR 01621-0001 (or higher dash number), as verified on the OTH 6 page, the unit is qualified for BRNAV (Basic Area Navigation) operation in the European region in accordance with the criteria of AC 90-96. (Reference ICAO Doc 7030 Regional Supplementary Procedures, JAA Technical Guidance Leaflet AMJ20X2 and Eurocontrol RNAV Standard Doc 003-93 Area Navigation Equipment Operational Requirements and Functional Requirements (RNAV).)



- 1. GPS MESSAGE (MSG) ANNUNCIATOR LIGHT -- MSG will begin flashing whenever the message prompt (a large "M" on the left side of the screen) on the KLN 89B GPS unit begins flashing to alert the pilot that a message is waiting. Press the Message (MSG) key on the GPS to display the message. If a message condition exists which requires a specific action by the pilot, the message annunciator will remain on but will not flash.
- 2. GPS WAYPOINT (WPT) ANNUNCIATOR LIGHT -- GPS WAYPOINT annunciator will begin to flash approximately 36 seconds prior to reaching a Direct-To waypoint. Also, when turn anticipation is enabled in the KLN 89B GPS unit, the annunciator will begin to flash 20 seconds prior to the beginning of turn anticipation, then illuminate steady at the very beginning of turn anticipation.

Figure 1. GPS Annunciator/Switch (Sheet 1 of 3)

1

WARNING

TURN ANTICIPATION IS AUTOMATICALLY DISABLED FOR FAF WAYPOINTS AND THOSE USED EXCLUSIVELY IN SID/STARS WHERE OVERFLIGHT IS REQUIRED. FOR WAYPOINTS SHARED BETWEEN SID/STARS AND PUBLISHED EN ROUTE SEGMENTS (REQUIRING OVERFLIGHT IN THE SID/STARS), PROPER SELECTION ON THE PRESENTED WAYPOINT PAGE IS NECESSARY TO PROVIDE ADEQUATE ROUTE PROTECTION ON THE SID/STARS.

- 3. GPS APPROACH (GPS, APR) SWITCH -- Pressing the GPS APPROACH switch manually selects or disarms the approach ARM mode and also cancels the approach ACTV mode after being automatically engaged by the KLN 89B GPS system. The white background color of the GPS APPROACH annunciator makes it visible in daylight.
- 4. ARM ANNUNCIATOR LIGHT -- ARM annunciator will illuminate when the KLN 89B GPS system automatically selects the approach ARM mode or when the approach ARM mode is manually selected. The approach ARM mode will be automatically selected when the airplane is within 30 NM of an airport, and an approach is loaded in the flight plan for that airport. The approach ARM mode can manually be selected at a greater distance than 30 NM from the airport by pressing the GPS APPROACH switch; however, this will not change the CDI scale until the airplane reaches the 30 NM point. The approach ARM mode can also be disarmed by pressing the GPS APPROACH switch.
- 5. ACTIVE (ACTV) ANNUNCIATOR LIGHT -- ACTV annunciator will illuminate when the KLN 89B GPS system automatically engages the approach ACTV mode (the ACTV mode can only be engaged by the KLN 89B GPS system which is automatic.) To cancel the approach ACTV mode, press the GPS APPROACH switch; this will change the mode to the approach ARM mode and illuminate the ARM annunciator.

Figure 1. GPS Annunciator/Switch (Sheet 2 of 3)

6. NAV/GPS SWITCH -- Toggles from Nav 1 to GPS and vice versa to control the type of navigation data to be displayed on the CDI (Course Deviation Indicator). The No. 1 CDI Omni Bearing Selector (OBS) provides analog course input to the KLN 89B OBS mode when the NAV/GPS in switch/annunciator is in GPS. When the NAV/GPS switch annunciation is in NAV, GPS course selection in OBS mode is digital through the use of the controls and display at the KLN 89B.

NOTE

Manual CDI course centering in **OBS** mode using the control knob can be difficult, especially at long distances. Centering the Course Deviation Indicator (CDI) needle can best be accomplished by pressing the Direct-To button and then manually setting the No. 1 CDI course to the course value prescribed in the KLN 89B displayed message.

NOTE

The Directional Gyro heading (HDG) bug must also be set to provide proper course datum to the autopilot if coupled to the KLN 89B in **LEG** or **OBS**. (When the optional HSI is installed, the HSI course pointer provides course datum to the autopilot.)

- NAVIGATION SOURCE (NAV) ANNUNCIATOR -- The NAV annunciator will illuminate steady to inform the pilot that NAV 1 information is being displayed on the NAV 1 CDI.
- 8. NAVIGATION SOURCE (**GPS**) ANNUNCIATOR -- The **GPS** annunciator will illuminate steady to inform the pilot that GPS information is being displayed on the NAV 1 CDI.

Figure 1. GPS Annunciator/Switch (Sheet 3 of 3)

SECTION 2 LIMITATIONS

- The KLN 89B GPS Pilot's Guide, P/N 006-08786-0000, dated May, 1995 (or later applicable revision) must be available to the flight crew whenever IFR GPS navigation is used. The Operational Revision Status (ORS) of the Pilot's Guide must match the ORS level annunciated on the Self Test page.
- 2. IFR Navigation is restricted as follows:
 - a. The system must utilize ORS level 01 or later FAA approved revision.
 - b. The data on the self test page must be verified prior to use.
 - c. IFR en route and terminal navigation is prohibited unless the pilot verifies the currency of the database or verifies each selected waypoint for accuracy by reference to current approved data.
 - d. The system must utilize ORS Level 02 or later FAA approved revision to conduct nonprecision instrument approaches. In addition, the software level status found on page OTH 6 must be "HOST 00880-0004" or later. Instrument approaches must be accomplished in accordance with approved instrument approach procedures that are retrieved from the KLN 89B database. The KLN 89B database must incorporate the current update cycle.
 - 1) The KLN 89B Quick Reference, P/N 006-08787-0000, dated 5/95 (or later applicable to revision) must be available to the flight crew during instrument approach operations.
 - Instrument approaches must be conducted in the approach mode and RAIM must be available at the Final Approach Fix.

- 3) APR ACTV mode must be annunciated at the Final Approach Fix.
- 4) Accomplishment of ILS, LOC, LOC-BC, LDA, SDF, and MLS approaches are not authorized.
- 5) When an alternate airport is required by the applicable operating rules, it must be served by an approach based on other than GPS or Loran-C navigation.
- 6) The KLN 89B can only be used for approach guidance if the reference coordinate datum system for the instrument approach is WGS-84 or NAD-83. (All approaches in the KLN 89B database use the WGS-84 or the NAD-83 geodetic datum).
- e. For BRNAV operations in the European region:
 - 1) With 23 (24 if the altitude input to the KLN 89B is not available) or more satellites projected to be operational for the flight, the aircraft can depart without further action.
 - 2) With 22 (23 if the altitude input to the KLN 89B is not available) or fewer satellites projected to be operational for the flight, the availability of the GPS integrity (RAIM) should be confirmed for the intended flight (route and time). This should be obtained from a prediction program run outside of the aircraft. The prediction program must comply with the criteria of Appendix 1 of AC90-96. In the event of a predicted continuous loss of RAIM of more than 5 minutes for any part of the intended flight, the flight should be delayed, cancelled, or rerouted on a track where RAIM requirements can be met.

AlliedSignal's Preflight, Version 2.0 or later computer based prediction program may be used for the RAIM prediction. Alternate methods should be submitted for approval in accordance with Advisory Circular AC90-96.

f. The aircraft must have other approved navigation equipment appropriate to the route of flight installed and operational.

PLACARDS

Use of the KLN 89B without the Operational Revision Status upgrade to "ORS 02" or later is limited to VFR and IFR enroute only. The following information must be presented in the form of placards when the airplane is equipped with a KLN 89B unit that has not been upgraded.

1. On the instrument panel near the KLN 89B unit:

GPS NOT APPROVED FOR IFR APPROACH

This placard is not required with an Operational Revision Status upgrade to "ORS 02" or later as read on the Power-On page and host software upgrade to "HOST 00880-0004" or later as read on the OTH 6 page.

SECTION 3 EMERGENCY PROCEDURES

There are no changes to the basic airplane emergency procedures when the KLN 89B GPS is installed.

- 1. If the KLN 89B GPS information is not available or invalid, utilize remaining operational navigation equipment as required.
- 2. If a "RAIM NOT AVAILABLE" message is displayed while conducting an instrument approach, terminate the approach. Execute a missed approach if required.

- 3. If a "RAIM NOT AVAILABLE" message is displayed in the en route or terminal phase of flight, continue to navigate using the KLN 89B or revert to an alternate means of navigation appropriate to the route and phase of flight. When continuing to use the KLN 89B for navigation, position must be verified every 15 minutes using another IFR approved navigation system.
- 4. Refer to the KLN 89B Pilot's Guide, Appendices B and C, for appropriate pilot actions to be accomplished in response to annunciated messages.

SECTION 4 NORMAL PROCEDURES

OPERATION

Normal operating procedures are outlined in the KLN 89B GPS Pilot's Guide, P/N 006-08786-0000, dated May, 1995, (or later applicable revision). A KLN 89B Quick Reference, P/N 006-08787-0000, dated May, 1995 (or later applicable revision) containing an approach sequence, operating tips and approach related messages is intended as well for cockpit use by the pilot familiar with KLN 89B operations when conducting instrument approaches.

WARNING

TO PREVENT THE POSSIBILITY OF TURN ANTICIPATION CAUSING POTENTIALLY MISLEADING NAVIGATION WHEN THE AIRCRAFT IS NOT ON COURSE, VERIFY THE CDI COURSE AND CDI NEEDLE PRESENTATION IS PROPER PRIOR TO TAKEOFF AND DO NOT SWITCH FROM OBS TO LEG WITH GREATER THAN 1 NM CROSS TRACK ERROR (XTK).

IF MISLEADING DATA IS SUSPECTED, A DIRECT-TO OPERATION TO YOUR DESIRED WAYPOINT WILL CLEAR ANY PREVIOUS OBS COURSE, AND CANCEL TURN ANTICIPATION.

After the above Direct-To operation, further reorientation to the nearest leg of the active flight plan may be accomplished by pressing the Direct-To button followed by pressing the Clear button and finally the Enter Button.

Refer to the Pilot's Guide section 4.2.2 for an explanation of turn anticipation, and Appendix A - Navigation Terms for the definition of cross track error (XTK).

AUTOPILOT COUPLED OPERATION

The KLN 89B may be coupled to the KAP 140 autopilot by first selecting **GPS** on the NAV/GPS switch. Manual selection of the desired track on the pilot's DG heading bug is required to provide course datum to the KAP 140 autopilot. (Frequent course datum changes may be necessary, such as in the case of flying a DME arc.) The autopilot approach mode (APR) should be used when conducting a coupled GPS approach.

NOTE

<u>Select HDG mode for DME arc intercepts</u>. NAV or APR coupled DME arc intercepts can result in excessive overshoots (aggravated by high ground speeds and/or intercepts from <u>inside</u> the arc).

APPROACH MODE SEQUENCING AND RAIM PREDICTION

WARNING

FAMILIARITY WITH THE EN ROUTE OPERATION OF THE KLN 89B DOES NOT CONSTITUTE PROFICIENCY IN APPROACH OPERATIONS. DO NOT ATTEMPT APPROACH OPERATIONS IN IMC (INSTRUMENT METEOROLOGICAL CONDITIONS) PRIOR TO ATTAINING PROFICIENCY IN THE USE OF THE KLN 89B.

The special use airspace alert will automatically be disabled prior to flying an instrument approach to reduce the potential for message congestion.

1. Prior to arrival, select a STAR if appropriate from the APT 7 page. Select an approach and an initial approach fix (IAF) from the APT 8 page.

NOTE

Using the outer knob, select the ACT (Active Flight Plan Waypoints) pages. Pull the inner knob out and scroll to the destination airport, then push the inner knob in and select the ACT 7 or ACT 8 page.

To delete or replace a SID, STAR or approach, select FPL 0 page. Place the cursor over the name of the procedure, press ENT to change it, or CLR then ENT to delete it.

2. En route, check for RAIM availability at the destination airport ETA on the **OTH 3** page.

NOTE

RAIM must be available at the FAF in order to fly an instrument approach. Be prepared to terminate the approach upon loss of RAIM.

- 3. At or within 30 nm from the airport:
 - a. Verify automatic annunciation of APRARM.
 - b. Note automatic CDI needle scaling change from ±5.0 nm to ±1.0 nm over the next 30 seconds.
 - c. Update the KLN 89B altimeter baro setting as required.
 - d. Internally the KLN 89B will transition from en route to terminal integrity monitoring.

- Select NAV 4 page to fly the approach procedure.
 - a. If receiving radar vectors, or need to fly a procedure turn or holding pattern, fly in OBS until inbound to the FAF.

OBS navigation is TO-FROM (like a VOR) without waypoint sequencing.

WARNING

TO PREVENT THE POSSIBILITY OF TURN ANTICIPATION CAUSING POTENTIALLY MISLEADING NAVIGATION WHEN THE AIRCRAFT IS NOT ON COURSE, DO NOT SWITCH FROM OBS TO LEG WITH GREATER THAN 1 NM CROSS TRACK ERROR (XTK).

b. **NoPT** routes including DME arc's are flown in **LEG**. <u>LEG</u> is mandatory from the FAF to the MAP.

NOTE

Select HDG mode for DME arc intercepts. NAV or APR coupled DME arc intercepts can result in excessive overshoots (aggravated by high ground speeds and/or intercepts from inside the arc).

WARNING

FLYING FINAL OUTBOUND FROM AN OFF-AIRPORT VORTAC ON AN OVERLAY APPROACH; BEWARE OF THE DME DISTANCE INCREASING ON FINAL APPROACH, AND THE GPS DISTANCE-TO-WAYPOINT DECREASING, AND NOT MATCHING THE NUMBERS ON THE APPROACH PLATE.

SECTION 9 - SUPPLEMENTS SUPPLEMENT 5 - FAA APPROVED

- 5. At or before 2 nm from the FAF inbound:
 - a. Select the FAF as the active waypoint, if not accomplished already.
 - b. Select LEG operation.
- 6. Approaching the FAF inbound (within 2 nm):
 - a. Verify APR ACTV.
 - b. Note automatic CDI needle scaling change from ±1.0 nm to ±0.3 nm over the 2 nm inbound to the FAF.
 - c. Internally the KLN 89B will transition from terminal to approach integrity monitoring.
- 7. Crossing the FAF and APR ACTV is not annunciated:
 - a. Do not descend.
 - b. Execute the missed approach.
- 8. Missed Approach:
 - a. Climb.
 - b. Navigate to the MAP (in APRARM if APR ACTV is not available).

NOTE

There is no automatic LEG sequencing at the MAP.

c. After climbing in accordance with the published missed approach procedure, press the Direct To button, verify or change the desired holding fix and press **ENT**.

GENERAL NOTES

- The database must be up to date for instrument approach operation.
- Only one approach can be in the flight plan at a time.
- Checking RAIM prediction for your approach while en route using the OTH 3 page is recommended. A self check occurs automatically within 2 nm of the FAF. APR ACTV is inhibited without RAIM.
- Data cannot be altered, added to or deleted from the approach procedures contained in the database. (DME arc intercepts may be relocated along the arc through the NAV 4 or the FPL 0 pages).
- Some approach waypoints do not appear on the approach plates (including in some instances the FAF).
- Waypoint suffixes in the flight plan:
 - i-- IAF
 - f-- FAF
 - m -- MAP
 - h -- missed approach holding fix.

•The DME arc IAF (arc intercept waypoint) will be on your present position radial off the arc VOR when you load the IAF into the flight plan, or the beginning of the arc if currently on a radial beyond the arc limit. To adjust the arc intercept to be compatible with a current radar vector, bring up the arc IAF waypoint in the NAV 4 page scanning field or under the cursor on the FPL 0 page, press CLR, then ENT. Fly the arc in LEG. Adjust the heading bug (if autopilot coupled) and CDI course with reference to the desired track value on the NAV 4 page (it will flash to remind you). Left/right CDI needle information is relative to the arc. Displayed distance is not along the arc but direct to the active waypoint. (The DME arc radial is also displayed in the lower right corner of the NAV 4 page.)

SECTION 9 - SUPPLEMENTS SUPPLEMENT 5 - FAA APPROVED

- The DME arc IAF identifier may be unfamiliar. Example: D098G where 098 stands for the 098° radial off the referenced VOR, and G is the seventh letter in the alphabet indicating a 7 DME arc.
- APRARM to APR ACTV is automatic provided that:
 - a. You are in APRARM (normally automatic).
 - b. You are in LEG mode.
 - c. The FAF is the active waypoint.
 - d. Within 2 nm of the FAF.
 - e. Outside of the FAF.
 - f. Inbound to the FAF.
 - g. RAIM is available.
- Direct-To operation between the FAF and MAP cancels APR
 ACTV. Fly the missed approach in APRARM.
- Flagged navigation inside the FAF may usually be restored (not guaranteed) by pressing the GPS APR button changing from **ACTV** to **ARM**. Fly the missed approach.
- The instrument approach using the KLN 89B may be essentially automatically started 30 nm out (with a manual baro setting update) or it may require judicious selection of the OBS and LEG modes.
- APRARM may be canceled at any time by pressing the GPS APR button. (A subsequent press will reselect it.)

SECTION 5 PERFORMANCE

There is no change to the airplane performance when this avionics equipment is installed. However, installation of an externally-mounted antenna or related external antennas, will result in a minor reduction in cruise performance.

	 -12	 18		
				94
14				
				58



Pilot's Operating Handbook and FAA Approved Airplane Flight Manual

CESSNA MODEL 182S AIRPLANES 18280001 AND ON SUPPLEMENT 6

BENDIX/KING KR87
AUTOMATIC DIRECTION FINDER

Member of GAMA
3 February 1997

COPYRIGHT © 1997 CESSNA AIRCRAFT COMPANY WICHITA, KANSAS, USA

182SPHUS-S6-02

Revision 2 - 15 November 2000

S6-1

BENDIX/KING KR 87 AUTOMATIC DIRECTION FINDER (ADF)

The following Log of Effective Pages provides the date of issue for original and revised pages, as well as a listing of all pages in the Supplement. Pages which are affected by the current revision will carry the date of that revision

Revision Level Date of Issue 0 (Original) Feb. 3, 1997 1 Dec. 1, 1997 2 Nov. 15, 2000

LOG OF EFFECTIVITY PAGE

PAGE	DATE	PAGE	DATE
Title (S6-1) S6-2	Nov 15/00 Nov 15/00	S6-7 S6-8	Feb 3/97 Feb 3/97
S6-3 S6-4	Nov 15/00 Feb 3/97	S6-9 S6-10	Feb 3/97 Feb 3/97
S6-5	Feb 3/97	S6-11	Dec 1/97
S6-6	Feb 3/97	S6-12	Feb 3/97

SERVICE BULLETIN CONFIGURATION LIST

The following is a list of Service Bulletins that are applicable to the operation of the airplane, and have been incorporated into this supplement. This list contains only those Service Bulletins that are currently active.

		Airplane Unit	Revision	incorporated
Number	<u>Title</u>	Effectivity	Incorporation	In Airplane

BENDIX/KING KR 87 AUTOMATIC DIRECTION FINDER (ADF)

SECTION 1 GENERAL


The Bendix/King Digital ADF is a panel-mounted, digitally tuned automatic direction finder. It is designed to provide continuous 1-kHz digital tuning in the frequency range of 200-kHz to 1799-kHz and eliminates the need for mechanical band switching. The system is comprised of a receiver, a built-in electronics timer, a bearing indicator, and a KA-44B combined loop and sense antenna. Operating controls and displays for the Bendix/King Digital ADF are shown and described in Figure 1. The audio system used in conjunction with this radio for speaker-phone selection is shown and described in Supplement 3 of this handbook.

The Bendix/King Digital ADF can be used for position plotting and homing procedures, and for aural reception of amplitude-modulated (AM) signals.

The "flip-flop" frequency display allows switching between preselected "STANDBY" and "ACTIVE" frequencies by pressing the frequency transfer button. Both pre-selected frequencies are stored in a non-volatile memory circuit (no battery power required) and displayed in large, easy-to-read, self-dimming gas discharge numerics. The active frequency is continuously displayed in the left window, while the right window will display either the standby frequency or the selected readout from the built-in electronic timer.

The built-in electronic timer has two separate and independent timing functions. An automatic flight timer that starts whenever the unit is turned on. This timer functions up to 59 hours and 59 minutes. An elapsed timer which will count up or down for up to 59 minutes and 59 seconds. When a preset time interval has been programmed and the countdown reaches :00, the display will flash for 15 seconds. Since both the flight timer and elapsed timer operate independently, it is possible to monitor either one without disrupting the other. The pushbutton controls and the bearing indicators are internally lighted. Intensity is controlled by the RADIO light dimming rheostat.

Nov 15/00 S6-3






Figure 1. KR 87 Automatic Direction Finder (ADF) (Sheet 1 of 4)

S6-4

- 1. ANT/ADF MODE ANNUNCIATOR -- Antenna (ANT) is selected by the "out" position of the ADF button. This mode improves the audio reception and is usually used for station identification. The bearing pointer is deactivated and will park in the 90° relative position. Automatic Direction Finder (ADF) mode is selected by the depressed position of the ADF button. This mode activates the bearing pointer. The bearing pointer will point in the direction of the station relative to the aircraft heading.
- IN-USE FREQUENCY DISPLAY -- The frequency to which the ADF is tuned is displayed here. The active ADF frequency can be changed directly when either of the timer functions is selected.
- 3. BFO (Beat Frequency Oscillator) ANNUNCIATOR -- The BFO mode, activated and annunciated when the "BFO" button is depressed, permits the carrier wave and associated morse code identifier broadcast on the carrier wave to be heard.

CW signals (Morse Code) are unmodulated and no audio will be heard without use of BFO. This type of signal is not used in the United States air navigation. It is used in some foreign countries and marine beacons.

4. STANDBY FREQUENCY/FLIGHT TIME OR ELAPSED TIME ANNUNCIATION -- When FRQ is displayed the STANDBY frequency is displayed in the right hand display. The STANDBY frequency is selected using the frequency select knobs. The selected STANDBY frequency is put into the ACTIVE frequency windows by pressing the frequency transfer button. Either the standby frequency, the flight timer, or the elapsed time is displayed in this position. The flight timer and elapsed timer are displayed replacing the standby frequency which goes into "blind" memory to be called back at any time by depressing the FRQ button. Flight time or elapsed time are displayed and annunciated alternatively by depressing the FLT/ET button.

Figure 1. KR 87 Automatic Direction Finder (ADF) (Sheet 2 of 4)

Feb 3/97 S6-5

- 5. FLIGHT TIMER AND ELAPSED TIMER MODE ANNUNCIATION -- Either the elapsed time (ET) or flight time (FLT) mode is annunciated here.
 - 6. FREQUENCY SELECT KNOBS -- Selects the standby frequency when FRQ is displayed and directly selects the active frequency whenever either of the time functions is selected. The frequency selector knobs may be rotated either clockwise or counterclockwise. The small knob is pulled out to tune the 1's. The small knob is pushed in to tune the 10's. The outer knob tunes the 100's with rollover into the 1000's up to 1799. These knobs are also used to set the desired time when the elapsed timer is used in the countdown mode.
 - 7. ON/OFF/VOLUME CONTROL SWITCH (ON/OFF/VOL) -- Controls primary power and audio output level. Clockwise rotation from OFF position applies primary power to the receiver; further clockwise rotation increases audio level. Audio muting causes the audio output to be muted unless the receiver is locked on a valid station.
 - 8. SET/RESET ELAPSED TIMER BUTTON (SET/RST) -- The set/reset button when pressed resets the elapsed timer whether it is being displayed or not.
 - FLIGHT TIMER/ELAPSED TIMER MODE SELECTOR BUTTON (FLT/ET) -- The Flight Timer/Elapsed Time mode selector button when pressed alternatively selects either Flight Timer mode or Elapsed Timer mode.
- 10. FREQUENCY TRANSFER BUTTON (FRQ) -- The FRQ transfer button when pressed exchanges the active and standby frequencies. The new frequency becomes active and the former active frequency goes into standby.
- 11. BFO (Beat Frequency Oscillator) BUTTON -- The BFO button selects the BFO mode when in the depressed position. (See note under item 3).
- 12. ADF BUTTON -- The ADF button selects either the ANT mode or the ADF mode. The ANT mode is selected with the ADF button in the out position. The ADF mode is selected with the ADF button in the depressed position.

Figure 1. KR 87 Automatic Direction Finder (ADF) (Sheet 3 of 4

- 13. LUBBER LINE -- Indicates relative or magnetic heading of the aircraft. The heading must be manually input by the pilot with the heading (HDG) knob.
- 14. COMPASS CARD -- Manually rotatable card that indicates relative or magnetic heading of aircraft, as selected by HDG knob.
- 15. BEARING POINTER -- Indicates relative or magnetic bearing to station as selected by HDG knob. If the relative heading of North (N) is manually selected under the lubber line by the pilot, then the bearing pointer indicates the relative bearing to the station. If the aircraft's magnetic heading is selected under the lubber line by the pilot, then the bearing pointer indicates the magnetic bearing to the station.
- HEADING KNOB (HDG) --Rotates card to set in relative or magnetic heading of aircraft.

Figure 1. KR 87 Automatic Direction Finder (ADF) (Sheet 4 of 4)

Feb 3/97 S6-7

SECTION 2 LIMITATIONS

There is no change to airplane limitations when the KR 87 ADF is installed.

SECTION 3 EMERGENCY PROCEDURES

There are no changes to the basic airplane emergency procedures when the KR 87 ADF is installed.

SECTION 4 NORMAL PROCEDURES

TO OPERATE AS AN AUTOMATIC DIRECTION FINDER:

- 1. OFF/VOL Control -- ON.
- 2. Frequency Selector Knobs -- SELECT desired frequency in the standby frequency display.
- 3. FRQ Button -- PRESS to move the desired frequency from the standby to the active position.
- 4. ADF Selector Switch (on audio control panel) -- SELECT as desired.
- 5. OFF/VOL Control -- SET to desired volume level and identify that desired station is being received.
- 6. ADF Button -- SELECT ADF mode and note relative bearing on indicator.

ADF TEST (PRE-FLIGHT or IN-FLIGHT):

- 1. ADF Button -- SELECT ANT mode and note pointer moves to 90° position.
- 2. ADF Button -- SELECT ADF mode and note the pointer moves without hesitation to the station bearing. Excessive pointer sluggishness, wavering or reversals indicate a signal that is too weak or a system malfunction.

TO OPERATE BFO:

- 1. OFF/VOL Control -- ON.
- 2. BFO Button -- PRESS on.
- 3. ADF Selector Buttons (on audio control panel) -- SET to desired mode.
- 4. VOL Control -- ADJUST to desired listening level.

NOTE

A 1000-Hz tone and Morse Code identifier is heard in the audio output when a CW signal is received.

TO OPERATE FLIGHT TIMER:

- 1. OFF/VOL Control -- ON.
- 2. FLT/ET Mode Button -- PRESS (once or twice) until FLT is annunciated. Timer will already be counting since it is activated by turning the unit on.
- 3. OFF/VOL. Control -- OFF and then ON if it is desired to reset the flight timer.

TO OPERATE AS A COMMUNICATIONS RECEIVER ONLY:

- 1. OFF/VOL Control -- ON.
- 2. ADF Button -- SELECT ANT mode.
- 3. Frequency Selector Knobs -- SELECT desired frequency in the standby frequency display.
- 4. FRQ Button -- PRESS to move the desired frequency from the standby to the active position.
- 5. ADF Selector Buttons (on audio control panel) -- SET to desired mode.
- 6. VOL Control -- ADJUST to desired listening level.

Feb 3/97 S6-9

TO OPERATE ELAPSED TIME TIMER-COUNT UP MODE:

- 1. OFF/VOL Control -- ON.
- 2. FLT/ET Mode Button -- PRESS (once or twice) until ET is annunciated.
- 3. SET/RST Button -- PRESS momentarily to reset elapsed timer to zero.

NOTE

The Standby Frequency which is in memory while Flight Time or Elapsed Time modes are being displayed may be called back by pressing the FRQ button, then transferred to active use by pressing the FRQ button again.

TO OPERATE ELAPSED TIME TIMER-COUNT DOWN MODE:

- 1. OFF/VOL Control -- ON.
- 2. FLT/ET Mode Button -- PRESS (once or twice) until ET is annunciated.
- SET/RST Button -- PRESS until the ET annunciation begins to flash.
- 4. FREQUENCY SELECTOR KNOBS -- SET desired time in the elapsed time display. The small knob is pulled out to tune the 1's. The small knob is pushed in to tune the 10's. The outer knob tunes minutes up to 59 minutes.

NOTE

Selector knobs remain in the time set mode for 15 seconds after the last entry or until the SET/RST, FLT/ET or FRQ button is pressed.

5. SET/RST Button -- PRESS to start countdown. When the timer reaches 0, it will start to count up as display flashes for 15 seconds.

NOTE

While FLT or ET are displayed, the active frequency on the left side of the window may be changed, by using the frequency selector knobs, without any effect on the stored standby frequency or the other modes.

ADF OPERATION NOTES:

ERRONEOUS ADF BEARING DUE TO RADIO FREQUENCY PHENOMENA:

In the U.S., the FCC, which assigns AM radio frequencies, occasionally will assign the same frequency to more than one station in an area. Certain conditions, such as Night Effect, may cause signals from such stations to overlap. This should be taken into consideration when using AM broadcast station for navigation.

Sunspots and atmospheric phenomena may occasionally distort reception so that signals from two stations on the same frequency will overlap. For this reason, it is always wise to make positive identification of the station being tuned, by switching the function selector to ANT and listening for station call letters.

ELECTRICAL STORMS:

In the vicinity of electrical storms, an ADF indicator pointer tends to swing from the station tuned toward the center of the storm.

NIGHT EFFECT:

This is a disturbance particularly strong just after sunset and just after dawn. An ADF indicator pointer may swing erratically at these times. If possible, tune to the most powerful station at the lowest frequency. If this is not possible, take the average of pointer oscillations to determine relative station bearing.

MOUNTAIN EFFECT:

Radio waves reflecting from the surface of mountains may cause the pointer to fluctuate or show an erroneous bearing. This should be taken into account when taking bearings over mountainous terrain.

COASTAL REFRACTION:

Radio waves may be refracted when passing from land to sea or when moving parallel to the coastline. This also should be taken into account.

Dec 1/97 S6-11

SECTION 5 PERFORMANCE

There is no change to the airplane performance when this avionic equipment is installed. However, the installation of an externally mounted antenna or related external antennas, will result in a minor reduction in cruise performance.



Pilot's Operating Handbook and FAA Approved Airplane Flight Manual

CESSNA MODEL 182S AIRPLANES 18280001 AND ON SUPPLEMENT 8

WINTERIZATION KIT



COPYRIGHT © 1997 CESSNA AIRCRAFT COMPANY WICHITA, KANSAS, USA

182SPHUS-S8-01

Revision 1 - 15 November 2000

S8-1

WINTERIZATION KIT

The following Log of Effective Pages provides the date of issue for original and revised pages, as well as a listing of all pages in the Supplement. Pages which are affected by the current revision will carry the date of that revision

Revision Level Date of Issue

0 (Original) Feb 3, 1997 1 Nov. 15, 2000

LOG OF EFFECTIVITY PAGES

PAGE	DATE	PAGE	DATE
Title (S8-1) S8-2 S8-3 S8-4	Nov 15/00 Nov 15/00 Feb 3/97 Feb 3/97	8	

SERVICE BULLETIN CONFIGURATION LIST

The following is a list of Service Bulletins that are applicable to the operation of the airplane, and have been incorporated into this supplement. This list contains only those Service Bulletins that are currently active.

		Airplane		
		Unit	Revision	Incorporated
Number	<u>Title</u>	Effectivity	Incorporation	<u>In Airplane</u>

WINTERIZATION KIT

SECTION 1 GENERAL

The winterization kit consists of two cover plates (with placards) which attach to the air intakes in the cowling nose cap, a placard silk screened on the instrument panel, and insulation for the crankcase breather line. This equipment should be installed for operations in tempertues consistently below 20°F (-7°C). Once installed, the crankcase breather insulation is approved for permanent use in both hot and cold weather.

SECTION 2 LIMITATIONS

The following information must be presented in the form of placards when the airplane is equipped with a winterization kit.

1. On each nose cap cover plate:

THIS PLATE NOT TO BE USED WHEN TEMPERATURE EXCEEDS +20°F.

2. On the instrument panel near the EGT gauge:

WINTERIZATION KIT MUST BE REMOVED WHEN OUTSIDE AIR TEMPERATURE IS ABOVE 20°F.

Feb 3/97

S8-3

SECTION 3 EMERGENCY PROCEDURES

There is no change to the airplane emergency procedures when the winterization kit is installed.

SECTION 4 NORMAL PROCEDURES

There is no change to the airplane normal procedures when the winterization kit is installed.

SECTION 5 PERFORMANCE

There is no change to the airplane performance when the winterization kit is installed.



Pilot's Operating Handbook and FAA Approved Airplane Flight Manual

CESSNA MODEL 182S AIRPLANES 18280001 AND ON SUPPLEMENT 9

DAVTRON MODEL 803 CLOCK / O.A.T.

Member of GAMA
3 February 1997

COPYRIGHT © 1997 CESSNA AIRCRAFT COMPANY WICHITA, KANSAS, USA

182SPHUS-S9-01

Revision 1 - 15 November 2000

S9-1

SUPPLEMENT 9

DAVTRON MODEL 803 CLOCK/O.A.T.

The following Log of Effective Pages provides the date of issue for original and revised pages, as well as a listing of all pages in the Supplement. Pages which are affected by the current revision will carry the date of that revision

Revision Level Date of Issue

0 (Original) Feb 3, 1997 Nov. 15, 2000

LOG OF EFFECTIVITY PAGES

PAGE	DATE	PAGE	DATE
Title (S9-1)	Nov 15/00	S9-4	Feb 3/97
S9-2	Nov 15/00	S9-5	Nov 15/00
S9-3	Feb 3/97	S9-6	Feb 3/97

SERVICE BULLETIN CONFIGURATION LIST

The following is a list of Service Bulletins that are applicable to the operation of the airplane, and have been incorporated into this supplement. This list contains only those Service Bulletins that are currently active.

		Airplane		
		Unit	Revision	Incorporated
Number	Title	Effectivity	Incorporation	In Airplane

SUPPLEMENT

DIGITAL CLOCK/O.A.T.

SECTION 1 GENERAL

The Davtron Model 803 digital clock combines the features of a clock, outside air temperature gauge (O.A.T.) and voltmeter in a single unit. The unit is designed for ease of operation with a three button control system. The upper button is used to control sequencing between temperature and voltage. The lower two buttons control reading and timing functions related to the digital clock. Temperature and voltage functions are displayed in the upper portion of the unit's LCD window, and clock/timing functions are displayed in the lower portion of the unit's LCD window.

The digital display features an internal light (back light) to ensure good visibility under low cabin lighting conditions and at night. The intensity of the back light is controlled by the PANEL LT rheostat. In addition, the display incorporates a test function which allows checking that all elements of the display are operating.

SECTION 2 LIMITATIONS

There is no change to the airplane limitations when the digital clock/O.A.T. is installed.

SECTION 3 EMERGENCY PROCEDURES

There is no change to the airplane emergency procedures when the digital clock/O.A.T. is installed.

Feb 3/97 S9-3




Figure 1. Davtron Model 803 Digital Clock

SECTION 4 NORMAL PROCEDURES

TEST MODE

The unit may be tested by holding the SELECT button down for three seconds. Proper operation is indicated by the display 88:88 and activation of all four annunciators.

O.A.T. / VOLTMETER OPERATION

The upper portion of the LCD window is dedicated to O.A.T. and voltmeter operations. The voltmeter reading is preselected upon startup and is indicated by an "E" following the display reading. Pushing the upper button will sequence the window from voltage to fahrenheit ("F") to centigrade ("C"), and back again to voltage.

CLOCK OPERATIONS

The lower portion of the LCD window is dedicated to clock and timing operations. Pushing the SELECT button will sequence the window from universal time (UT) to local time (LT) to flight time (FT) to elapsed time (ET), and back again to universal time. Pushing the CONTROL button allows for timing functions within the four SELECT menus. Setting procedures are as follows:

SETTING UNIVERSAL TIME

Use the SELECT button to select universal time (UT). Simultaneously press both the SELECT and the CONTROL buttons to enter the set mode. The tens of hours digit will start flashing. The CONTROL button has full control of the flashing digit, and each button push increments the digit. Once the tens of hours is set the SELECT button selects the next digit to be set. After the last digit has been selected and set with the CONTROL button, a final push of the SELECT button exits the set mode. The lighted annunciator will resume its normal flashing, indicating the clock is running in universal time mode.

SETTING LOCAL TIME

Use the SELECT button to select local time (LT). Simultaneously press both the SELECT and the CONTROL buttons to enter the set mode. The tens of hours digit will start flashing. The set operation is the same as for UT, except that minutes are already synchronized with the UT clock and cannot be set in local time.

FLIGHT TIME RESET

Use the SELECT button to select flight time (FT). Hold the CONTROL button down for 3 seconds, or until 99:59 appears on the display. Flight time will be zeroed upon release of the CONTROL button.

SETTING FLIGHT TIME FLASHING ALARM

Use the SELECT button to select flight time (FT). Simultaneously press both the SELECT and the CONTROL buttons to enter the set mode. The tens of hours digit will start flashing. The set operation is the same as for UT. When actual flight time equals the alarm time, the display will flash. Pressing either the SELECT or CONTROL button will turn the flashing off and zero the alarm time. Flight time is unchanged and continues counting.

Nov 15/00 S9-5

SETTING ELAPSED TIME COUNT UP

Use the SELECT button to select elapsed time (ET). Press the CONTROL button and elapsed time will start counting. Elapsed time counts up to 59 minutes, 59 seconds, and then switches to hours and minutes. It continues counting up to 99 hours and 59 minutes. Pressing the CONTROL button again resets elapsed time to zero.

SETTING ELAPSED TIME COUNT DOWN

Use the SELECT button to select Elapsed Time (ET). Simultaneously press both the SELECT and the CONTROL buttons to enter the set mode. The tens of hours digit will start flashing. The set operation is the same as for UT, and a count down time can be set from a maximum of 59 minutes and 59 seconds. Once the last digit is set, pressing the SELECT button exits the set mode and the clock is ready to start the countdown. Pressing the CONTROL button now will start the countdown. When countdown reaches zero, the display will flash. Pressing either the SELECT or CONTROL button will reset the alarm. After reaching zero, the elapsed time counter will count up.

BUTTON SELECT DISABLE

When there is no airplane power applied to the unit, the CONTROL and SELECT buttons are disabled.

SECTION 5 PERFORMANCE

There is no change to the airplane performance when this equipment is installed. However, installation of this OAT probe will result in a minor reduction in cruise performance.



Pilot's Operating Handbook and FAA Approved Airplane Flight Manual

CESSNA MODEL 182S AIRPLANES 18280001 AND ON

SUPPLEMENT 10

BENDIX/KING KLN 89 (VFR) GLOBAL POSITIONING SYSTEM

Member of GAMA

3 February 1997

CESSNA AIRCRAFT COMPANY WICHITA, KANSAS, USA Revision 1 - 15 November 2000

182SPHUS-S10-01

COPYRIGHT © 1997

S10-1

SUPPLEMENT 10

BENDIX/KING KLN 89 (VFR) GLOBAL POSITIONING SYSTEM

The following Log of Effective Pages provides the date of issue for original and revised pages, as well as a listing of all pages in the Supplement. Pages which are affected by the current revision will carry the date of that revision

Revision Level Date of Issue

0 (Original)

Feb 3, 1997

Nov. 15, 2000

LOG OF EFFECTIVITY PAGES

PAGE	DATE	PAGE	DATE
Title (S10-1) S10-2 S10-3 S10-4	Nov 15/00 Nov 15/00 Nov 15/00 Feb 3/97		

SERVICE BULLETIN CONFIGURATION LIST

The following is a list of Service Bulletins that are applicable to the operation of the airplane, and have been incorporated into this supplement. This list contains only those Service Bulletins that are currently active.

		Airpiane		
		Unit	Revision	Incorporated
Number	Title	Effectivity	Incorporation	In Airplane

SUPPLEMENT

BENDIX/KING KLN 89 (VFR) GLOBAL POSITIONING SYSTEM

SECTION 1 GENERAL

The Bendix/King KLN 89 is a navigation system based on the Global Positioning Satellite network. It contains a database cartridge which may be updated by subscription. Complete descriptive material on the KLN 89 may be found in the Bendix/King KLN 89 Pilot's Guide supplied with the unit. This pilot guide must be available during operation of the KLN 89 unit.

SECTION 2 LIMITATIONS

Use of the KLN 89 is limited to VFR operations only. The following information must be presented in the form of placards when the airplane is equipped with a KLN 89 unit:

1. On the instrument panel near the KLN 89 unit:

GPS NOT APPROVED FOR IFR NAVIGATION

SECTION 3 EMERGENCY PROCEDURES

There is no change to the airplane emergency procedures when the KLN 89 GPS is installed.

Nov 15/00 S10-3

SECTION 4 NORMAL PROCEDURES

There is no change to basic airplane normal operating procedures with the KLN 89 GPS installed.

SECTION 5 PERFORMANCE

There is no change to the airplane performance when the KLN 89 GPS is installed. However, installation of an externally-mounted antenna or related external antennas will result in a minor reduction in cruise performance.



Pilot's Operating Handbook and FAA Approved Airplane Flight Manual

CESSNA MODEL 182S

AIRPLANE SERIALS 18280001 THRU 18280164

SUPPLEMENT 11

BENDIX/KING KAP 140 2 AXIS AUTOPILOT

Member of GAMA
3 February 1997

COPYRIGHT © 1997 CESSNA AIRCRAFT COMPANY WICHITA, KANSAS, USA

182SPHUS-S11-03

Revision 3 - 15 November 2000

S11-1

1

SUPPLEMENT 11

BENDIX/KING KAP 140 2 AXIS AUTOPILOT

Nov. 15, 2000

The following Log of Effective Pages provides the date of issue for original and revised pages, as well as a listing of all pages in the Supplement. Pages which are affected by the current revision will carry the date of that revision

Revision Level	Date of Issue
0 (Original)	Feb. 3, 1997
1	July 18, 1997
2	Dec. 1, 1997

LOG OF EFFECTIVITY PAGES

PAGE	DATE	PAGE	DATE
Title (S11-1) S11-2 S11-3 S11-4 (blank) S11-5 S11-6 S11-7 S11-8 S11-9 S11-10 S11-11	Nov 15/00 Nov 15/00 Feb 3/97 Feb 3/97 Dec 1/97 Dec 1/97 Dec 1/97 Feb 3/97 Feb 3/97	S11-15 S11-16 S11-17 S11-18 S11-19 S11-20 S11-21 S11-22 S11-23 S11-24 S11-25	July 18/97 July 18/97 July 18/97 July 18/97 Feb 3/97 Nov 15/00 Nov 15/00 Feb 3/97 Feb 3/97 Feb 3/97
S11-12	Feb 3/97	S11-25 S11-26	Feb 3/97
S11-13	Dec 1/97	S11-27	Feb 3/97
S11-14	July 18/97	S11-28	Feb 3/97

S11-2 Nov 15/00

SUPPLEMENT 11

BENDIX/KING KAP140 2- AXIS AUTOPILOT SERVICE BULLETIN CONFIGURATION LIST

The following is a list of Service Bulletins that are applicable to the operation of the airplane, and have been incorporated into this supplement. This list contains only those Service Bulletins that are currently active.

Number Title

Airplane Unit Revision Effectivity

Incorporation In Airplane

Incorporated

⊞ec a e	56 50 50	
		12
1		

SUPPLEMENT

BENDIX/KING KAP 140 2 AXIS AUTOPILOT

SECTION 1 GENERAL

The KAP 140 2 Axis Autopilot provides the pilot with the following features: Vertical Speed mode (VS); Altitude hold (ALT); Wing Level (ROL); Heading select (HDG); Approach (APR); ILS coupling to Localizer (LOC) and Glideslope (GS); and backcourse (REV) modes of operation.

The KAP 140 2 Axis Autopilot has an electric trim system which provides autotrim during autopilot operation and manual electric trim (MET) for the pilot when the autopilot is not engaged. The electric trim system is designed to fail safe for any single inflight trim malfunction. Trim faults are visually and aurally annunciated.

A lockout device prevents autopilot or MET engagement until the system has successfully passed preflight self test. Automatic preflight self-test begins with initial power application to the autopilot.

The following conditions will cause the Autopilot to automatically disengage:

- A. Power failure.
- B. Internal Flight Control System failure.

- C. Pitch accelerations in excess of +1.4g or less than 0.6g will cause the autopilot to disengage.
- D. Flagged turn and bank gyro.
- E. Computer autopilot monitor that detects either the R (ROLL) or P (PITCH) axis annunciator.

Activation of AP DISC/TRIM INT control wheel switch will also disconnect the autopilot.

The AVIONICS MASTER switch supplies power to the avionics bus bar of the radio circuit breakers and the autopilot circuit breaker. The AVIONICS MASTER switch also serves as an emergency AP/MET shutoff.

The airplane MASTER switch function is unchanged and can be used in an emergency to shut off electrical power to all flight control systems while the problem is isolated.

The following circuit breakers are used to protect the KAP 140 2-Axis Autopilot:

	LABEL	<u>FUNCTIONS</u>
I	AUTO PILOT	Supplies power to the KC 140 Computer and the autopilot pitch, roll and pitch trim servos.
	WARN	Supplies separate power for autopilot alerting on the ship's annunciator panel.





Figure 1. Bendix/King 2-Axis KAP 140 Autopilot Schematic (Sheet 1 of 5)



- 1. PITCH AXIS (P) ANNUNCIATOR -- When illuminated, indicates failure of pitch axis and will either disengage the autopilot or not allow engagement of the pitch axis.
- 2. AUTOPILOT ENGAGE/DISENGAGE (AP) BUTTON -- When pushed, engages autopilot if all logic conditions are met. The autopilot will engage in the basic roll (ROL) mode which functions as a wing leveler and the pitch axis mode of vertical speed (VS) mode. The commanded vertical speed will be displayed in the upper right corner of autopilot display area. The captured VS will be vertical speed present at the moment of AP button press. The button may be used to disengage the autopilot.
- 3. ROLL AXIS (R) ANNUNCIATOR -- When illuminated, indicates failure of the roll axis and disengage the autopilot.
- 4. HEADING (HDG) MODE SELECTOR BUTTON -- When pushed, will select the Heading mode, which commands the airplane to turn to and maintain the heading selected by the heading bug on the Directional Gyro. A new heading may be selected at any time and will result in the airplane turning to the new heading. Button can also be used to toggle between HDG and ROL modes. This button may be used to engage the autopilot

Figure 1. Bendix/King 2-Axis KAP 140 Autopilot, Operating Controls and Indicators (Sheet 2 of 5)

É

- 5. NAVIGATION (NAV) MODE SELECTOR BUTTON -- When pushed, will select the Navigation mode. The mode provides automatic beam capture and tracking of VOR, LOC, or GPS signals as selected for presentation on the #1 CDI. NAV mode is recommended for enroute navigation tracking.
- 6. APPROACH (APR) MODE SELECTOR BUTTON -- When pushed, will select the Approach mode. This mode provides automatic beam capture and tracking of VOR, GPS, LOC and Glideslope (GS) on ILS, as selected for presentation on #1 CDI. APR mode tracking sensitivity is recommended for instrument approaches.
- 7. BACK COURSE APPROACH (REV) MODE BUTTON -- This button is active only when the couled navigation receiver is tuned to a LOC/ILS frequency. When pushed will select the Back Course approach mode. This mode functions identically to the approach mode except that the autopilot response to LOC signals is reversed. Glideslope is locked out with REV mode.
- 8. ALTITUDE HOLD (ALT) MODE SELECT BUTTON -- When pushed, will select the altitude hold mode. This mode provides capture and tracking of the selected altitude. The selected altitude is the airplane altitude at the moment the ALT button is pressed. If the ALT button is pressed with an established VS rate present, there will be approximately a 10% (of VS rate) overshoot, with the airplane returned positively to the selected altitude. This button may be used to engage the autopilot.
- 9. VERTICAL SPEED (UP/DN) MODE BUTTONS -- The action of these buttons are dependent upon the vertical mode present when pressed. If VS mode is active (AP plus any lateral mode) and the UP button is pressed, the autopilot will modify the displayed VS command (FPM) in the up direction. Single momentary cycles on either the UP or DN button will increment the VS command by 100 FPM per cycle. When either button is continuously held in, it will modify the vertical speed command by 300 fpm per second.

Figure 1. Bendix/King 2-Axis KAP 140 Autopilot, Operating Controls and Indicators (Sheet 3 of 5)

Feb 3/97 S11-9

If ALT mode is active, pressing the UP/DN buttons will modify the captured altitude by 20 feet per cycle, or if held continuously will command the airplane up or down at the rate of 500 FPM, synchronizing the ALT reference to the actual airplane altitude upon button release.

- 10. AUTOPILOT CIRCUIT BREAKER -- A 5-amp circuit breaker supplying 28 VDC to the KAP 140 system.
- 11. WARN C/B -- Power to the autopilot disconnect horn and the annunciator panel.
- 12. AUTOPILOT DISCONNECT (A/P DISC TRIM INT) SWITCH --When depressed will disengage the autopilot and interrupt electric trim power. An autopilot disconnect will be annunciated by a continuous 2 second tone accompanied by a flashing "AP" displayed on the autopilot computer.
- 13. MANUAL ELECTRIC TRIM SWITCHES (MET) -- When both switches are pressed in the same direction, will activate pitch trim in the selected direction. If only one switch is moved, the trim system will not operate. If only the right half of the MET switch assembly is held for 3 seconds, the trim monitoring system will detect a switch failure resulting in a Pannunciation on the autopilot display and the disabling of the electric trim system. Autopilot power will have to be cycled to clear the fault. Use of manual electric trim during autopilot operation will disengage the autopilot.
- 14. OMNI BEARING SELECT KNOB (OBS) -- Selects the desired course to be tracked by the autopilot. (Note: The HDG bug must also be positioned to the proper course to capture and track the selected radial or desired track).

Figure 1. Bendix/King 2-Axis KAP 140 Autopilot, Operating Controls and Indicators (Sheet 4 of 5)

S11-10 Feb 3/97

- 15. HEADING SELECT KNOB (HDG) -- Positions the heading bug on the compass card. Note that the position of the heading bug also provides course datum to the autopilot when tracking in NAV, APR, or REV (BC) modes. This is in addition to its more intuitive use in the HDG mode.
- 16. PITCH TRIM (PT) Annunciator -- Indicates the direction of required pitch trim. With electric trim installed, the annunciation simply provides status as to the autopilot's request for autotrim. A solid indication represents the lowest demand level for trim; whereas a flashing annunciator implies a greater demand. A solid P without an arrowhead is an indication of a pitch trim fault. Refer to the EMERGENCY PROCEDURES for proper response to a pitch trim fault.
- 17. PITCH TRIM Annunciation -- Illuminates whenever the automated preflight self test detects a pitch trim fault or a continuous monitoring system detects a pitch trim fault in flight. Refer to the EMERGENCY PROCEDURES for proper response to a pitch trim fault.

Figure 1. Bendix/King 2-Axis KAP 140 Autopilot, Operating Controls and Indicators (Sheet 5 of 5)

Feb 3/97 S11-11

SECTION 2 LIMITATIONS

The following autopilot limitations must be adhered to:

- The entire preflight test procedure outlined under Section 4, paragraph A of this supplement, including steps 1 through 7, must be successfully completed prior to each flight. Use of the autopilot or manual electric trim system is prohibited prior to completion of these tests.
- 2. During autopilot operation, a pilot with seat belt fastened must be seated at the left pilot position.
- 3. The autopilot must be OFF during takeoff and landing.
- 4. The system is approved for Category I operation only (Approach mode selected).
- 5. Autopilot maximum airspeed limitation -- 160 KIAS. Autopilot minimum airspeed limitation -- 80 KIAS.
- 6. Flaps must be up with the autopilot engaged.
- 7. The autopilot must be disengaged below 200 feet AGL during approach operations and below 800 feet AGL for all other phases of flight.
- 8. Overriding the autopilot to change pitch or roll attitude is prohibited. (Disengage with AP/DISC/TRIM INT or AP select button.)
- 9. The AUTOPILOT circuit breaker must be pulled following any inflight illumination of the red "PITCH TRIM" warning light, but only after first completing the Emergency Procedures (Section 3, paragraph 1.). The manual electric trim and autopilot autotrim systems will be disabled with the AP/TRIM circuit breaker pulled.

PLACARDS

The following information must be displayed in the form of composite or individual placards.

1. Near the throttle:

CAUTION:

POWER CHANGES IN EXCESS
OF 3 In HG MAN PRESS/SEC
IN TURBULENCE WITH
AUTOPILOT ENGAGED CAN
CAUSE AUTOPILOT UPSET.

NOTE

Autopilot upset can result in a rapid pitch up or pitch down of the airplane. If this condition occurs while making power change in turbulence, firmly grasp the control wheel and maintain airplane control. Press and hold A/P DISC switch throughout recovery. Once the airplane is stabilized, the autopilot may be re-engaged as described in Section 4, Normal Procedures.

2. Above the flap control handle/indicator:

FLAPS MUST BE UP WITH THE AUTOPILOT ENGAGED

SECTION 3 EMERGENCY PROCEDURES

The four step procedure listed under paragraph A should be among the basic airplane emergency procedures that are committed to memory. It is important that the pilot be proficient in accomplishing all four steps without reference to this manual.

- 1. In case of Autopilot, Autopilot Trim, or Manual Electric Trim malfunction (accomplish Items A and B simultaneously):
 - A. Airplane Control Wheel -- GRASP FIRMLY and regain aircraft control.
 - B. A/P DISC/TRIM INT Switch -- PRESS and HOLD throughout recovery.
 - C. AIRCRAFT -- RETRIM Manually as Needed.
 - D. AUTOPILOT Circuit Breaker -- PULL.

NOTE

The Avionics Master Switch may be used as an alternate means of removing all power from the autopilot and electric trim systems. If necessary perform steps 1A through 1C above, then turn the Avionics Master Switch OFF before locating and pulling the Autopilot Circuit Breaker. Turn the Avionics Master Switch on as soon as possible to restore power to all other avionics equipment. Primary attitude, airspeed, directional compass, and altitude instruments will remain operational at all times.

WARNING

DO NOT ATTEMPT TO RE-ENGAGE THE AUTOPILOT FOLLOWING AN AUTOPILOT, AUTOTRIM, OR MANUAL ELECTRIC TRIM MALFUNCTION UNTIL THE CAUSE FOR THE MALFUNCTION HAS BEEN CORRECTED.

Maximum Altitude losses due to autopilot malfunction:

CONFIGURATION	ALT. LOSS
Cruise, Climb, Descent Maneuvering APPR	250 ft. 100 ft. 50 ft.
	00 It.

AMPLIFIED EMERGENCY PROCEDURES

The following paragraphs are presented to supply additional information for the purpose of providing the pilot with a more complete understanding of the recommended course of action for an emergency situation.

- 1. An autopilot or autotrim malfunction occurs when there is an uncommanded deviation in the airplane flight path or when there is abnormal control wheel or trim wheel motion. In some cases, and especially for autopilot trim, there may be little to no airplane motion, yet the red PITCH TRIM annunciator may illuminate and an alert tone may sound.
 - The primary concern in reacting to an autopilot or autopilot trim malfunction, or to an automatic disconnect of the autopilot, is in maintaining control of the airplane. Immediately grasp the control wheel and press and hold down the A/P DISC/TRIM INT switch throughout the recovery. Manipulate the controls as required to safely maintain operation of the airplane within all of its operating limitations. Elevator trim should be used manually as needed to relieve control forces. Locate and pull the AUTOPILOT circuit breaker on the right hand circuit breaker panel to completely disable the autopilot system.
- 2. A manual electric trim malfunction may be recognized by the illumination of a red PITCH TRIM annunciator accompanied by an alert tone, or by unusual trim wheel motions with the autopilot mode OFF without pilot actuation of the manual electric trim switches. As with an autopilot malfunction, the first concern following a manual electric trim malfunction is regaining control of the airplane. Grasp the control wheel firmly and press and hold down the A/P DISC/TRIM INT switch. Locate and pull the AUTOPILOT circuit breaker on the right hand breaker panel.
- 3. Note that the emergency procedure for any malfunction is essentially the same: immediately grasp the control wheel and regain airplane control while pressing and holding the A/P DISC/TRIM INT switch down, and retrim the airplane as needed. After these steps have been accomplished secure the autopilot electric trim system by pulling the autopilot circuit breaker. As with any other airplane emergency procedure, it is important that the 4 steps of the Autopilot/Electric Trim Emergency Procedures located on Page 13 of this supplement are committed to memory.

- 4. The AVIONICS MASTER switch may be used as required to remove all power from the Autopilot and Electric Trim systems while the circuit breaker is located and pulled. Return the AVIONICS MASTER switch to the ON position as soon as possible. With the AVIONICS MASTER switch off, all flight instruments will remain operational; however, communications, navigation, and identification equipment will be inoperable.
- 5. It is important that all portions of the autopilot and electric trim system are preflight tested prior to each flight in accordance with the procedures published herein in order to assure their integrity and continued safe operation during flight.

WARNING

DO NOT RESET AUTOPILOT CIRCUIT BREAKER FOLLOWING AN AUTOPILOT/AUTOTRIM OR MANUAL ELECTRIC TRIM MALFUNCTION UNTIL THE CAUSE FOR THE MALFUNCTION HAS BEEN CORRECTED.

A flashing T annunciator with an up or down arrow head on the face of the autopilot computer.

- A flashing T auto trim annunciation on the face of the autopilot indicates a failure of the auto trim function to relieve pitch servo loading in a timely manner. This condition should be temporary.
- 1. FLASHING T ANNUNCIATION -- OBSERVE aircraft pitch behavior. If pitch behavior is satisfactory, wait 5-10 seconds for the annunciation to stop.
- 2. If annunciation continues, Airplane Control Wheel -- GRASP FIRMLY, disengage the autopilot and check for an out of pitch trim condition manually retrim as required.
- 3. AUTOPILOT OPERATION -- CONTINUE if satisfied that the out of trim indication was temporary. DISCONTINUE if evidence indicates a failure of the auto trim function.

A red **P** or **R** on the face of the autopilot computer.

1. A red P is an indication that the pitch axis of the autopilot has been disabled and cannot be engaged. DO NOT ENGAGE INTO A ROLL AXIS ONLY SYSTEM.

NOTE

If the red **P** lamp was the result of some abnormal accelerations on the airplane, the annunciation should be extinguished within approximately one minute and normal use of the autopilot will be reestablished.

 A red R is an indication that the roll axis of the autopilot has been disabled and cannot be engaged. The autopilot cannot be reengaged.

Flashing mode annunciation in the display of the autopilot computer.

- 1. Flashing **HDG** -- Indicates a failed heading. **PRESS HDG** button to terminate flashing. ROL will be displayed.
- 2. Flashing NAV, APR or REV -- Usually an indication of a flagged navigation source. PRESS the NAV, APR or REV button to terminate flashing. ROL will be displayed. (Select a valid navigation source.)

NOTE

A flashing NAV, APR or REV annunciation can also be caused by a failed heading valid input.

 Flashing GS -- Indication of a flagged glideslope. (GS will rearm automatically if a valid GS signal is received.)

NOTE

To continue tracking the localizer, observe the appropriate minimums for a nonprecision approach. (Press ALT twice in rapid succession to terminate the flashing. Control the pitch axis in the default VS mode.)

NOTE

At the onset of mode annunciator flashing, the autopilot has already reverted to a default mode of operation, i.e., ROL and or VS mode. An immediate attempt to reengage to lost mode may be made if the offending navigation, glideslope or compass flag has cleared.

EXCEPTION

The HDG annunciation will flash for 5 seconds upon selection of NAV, APR, or REV modes to remind the pilot to set the HDG bug for use as course datum.

Effects of instrument losses upon autopilot operation:

- 1. Loss of the artificial horizon -- no effect on the autopilot.
- 2. Loss of the turn coordinator -- autopilot inoperative.
- 3. Loss of the DG (Directional Gyro)-- The directional gyro does not provide any system valid flag. If the DG fails to function properly the autopilot heading and navigation mode will not function correctly. Under these conditions, the only useable lateral mode is ROL.

SECTION 4 NORMAL PROCEDURES

- A. PREFLIGHT (PERFORM PRIOR TO EACH FLIGHT):
 - 1. AVIONICS MASTER -- ON.
 - 2. POWER APPLICATION AND SELF TEST -- A self test is performed upon power application to the computer. This test is a sequence of internal checks that validate proper system operation prior to allowing normal system operation. The sequence is indicated by "PFT" with an increasing number for the sequence steps. Successful completion of self test is identified by all display segments being illuminated (Display Test), external "Pitch Trim" (A/C System Annunciator Panel) being illuminated, and the disconnect tone sounding.

NOTE

Upon applying power to the autopilot, the red P warning on the face of the autopilot may illuminate indicating that the pitch axis cannot be engaged. This condition should be temporary, lasting approximately 30 seconds. The P will extinguish and normal operation will be available.

S11-18 Feb 3/97

WARNING

IF PITCH TRIM LIGHT STAYS ON, THEN THE AUTOTRIM DID NOT PASS PREFLIGHT TEST. THE AUTOPILOT CIRCUIT BREAKER MUST BE PULLED. MANUAL ELECTRIC TRIM AND AUTOPILOT ARE INOPERATIVE.

3. MANUAL ELECTRIC TRIM -- TEST as follows: Press both halves of the split Manual Electric Trim (MET) switches to the nose down position, verify that the trim wheel and the trim tab position indicator are moving in the down direction. Repeat test for the nose up direction.

Press MET for nose up trim, press and hold the AP DISC/TRIM INT switch, verify that both the trim wheel and indicator are not moving, release the AP DISC / TRIM INT switch while still holding MET trim up, the trim wheel and indicator should continue to move in the nose up direction.

- 4. AUTOPILOT -- ENGAGE by pressing AP button.
- 5. **FLIGHT CONTROLS** -- **MOVE** fore, aft, left and right to verify the autopilot can be overpowered.
- 6. A/P DISC/TRIM INT Switch -- PRESS. Verify that the autopilot disconnects.
- 7. TRIM -- SET to take off position manually.

WARNING

THE PILOT IN COMMAND MUST CONTINUOUSLY MONITOR THE AUTOPILOT WHEN IT IS ENGAGED, AND BE PREPARED TO DISCONNECT THE AUTOPILOT AND TAKE IMMEDIATE CORRECTIVE ACTION -- INCLUDING MANUAL CONTROL OF THE AIRPLANE AND/OR PERFORMANCE OF EMERGENCY PROCEDURES -- IF AUTOPILOT OPERATION IS NOT AS EXPECTED OR IF AIRPLANE CONTROL IS NOT MAINTAINED.

WARNING

DURING ALL AUTOPILOT COUPLED OPERATIONS, THE PILOT IN COMMAND MUST USE PROPER AUTOPILOT COMMANDS AND USE THE PROPER ENGINE POWER TO ENSURE THAT THE AIRPLANE IS MAINTAINED BETWEEN 80 AND 160 KIAS, AND DOES NOT EXCEED OTHER BASIC AIRPLANE OPERATING LIMITATIONS.

NOTE

Autopilot tracking performance will be degraded in turbulence.

NOTE

Avoid abrupt power changes at low indicated airspeeds with the autopilot engaged.

- 1. BEFORE TAKEOFF:
 - a. A/P DISC/TRIM INT Switch -- PRESS.

2. AFTER TAKEOFF:

 a. Elevator Trim -- VERIFY or SET to place the airplane in a trimmed condition prior to Autopilot engagement.

NOTE

Engaging the autopilot into a mistrim condition may cause unwanted attitude changes and a "TRIM FAIL" annunciation.

b. AP Button -- PRESS. Note ROL and VS annunciator on. If no other modes are selected the autopilot will operate in the ROL and vertical speed modes.

WARNING

WHEN OPERATING AT OR NEAR THE BEST RATE OF CLIMB AIRSPEED, AT CLIMB POWER SETTINGS, AND USING VERTICAL SPEED MODE, IT IS EASY TO DECELERATE TO AN AIRSPEED WHERE CONTINUED DECREASES IN AIRSPEED WILL RESULT IN A REDUCED RATE OF CLIMB. CONTINUED OPERATION IN VERTICAL SPEED MODE COULD RESULT IN A STALL.

WHEN OPERATING AT OR NEAR THE MAXIMUM AUTOPILOT SPEED, IT WILL BE NECESSARY TO REDUCE POWER IN ORDER TO MAINTAIN THE DESIRED RATE OF DESCENT AND NOT EXCEED THE MAXIMUM AUTOPILOT SPEED.

Nov 15/00 S11-21

WARNING

DO NOT HELP THE AUTOPILOT OR HAND-FLY AIRPLANE WITH THE **AUTOPILOT** ENGAGED AS THE AUTOPILOT WILL RUN THE PITCH TRIM TO OPPOSE CONTROL WHEEL A MISTRIM OF THE AIRPLANE, MOVEMENT. WITH ACCOMPANYING LARGE ELEVATOR CONTROL FORCES, MAY RESULT IF THE PILOT MANIPULATES THE CONTROL MANUALLY WHILE THE AUTOPILOT ENGAGED.

3. CLIMB OR DESCENT:

- a. Using Vertical Trim:
 - VERTICAL SPEED Control -- PRESS either the UP or DN button to select aircraft vertical speed within the limits of ±2000 ft./min.
 - 2) **VERTICAL SPEED** Control -- **RELEASE** when desired vertical speed is displayed. The autopilot will maintain the displayed vertical speed.

4. ALTITUDE (**ALT**) HOLD:

a. **ALT** Hold Selector Button -- **PRESS**. Note **ALT** hold annunciator **ON**. Autopilot will maintain the selected altitude.

NOTE

It is recommended by the FAA (AC00-24B) to use basic "PITCH ATTITUDE HOLD" mode during operation in severe turbulence. However, since this autopilot does <u>not</u> use the attitude gyro as a pitch reference, it is recommended that the autopilot be disconnected and that the airplane be flown by hand in severe turbulence.

b. Change altitudes:

- 1) Using Vertical Speed (Recommended for altitude changes less than 100 ft.)
 - a) **VERTICAL SPEED** Control -- **PRESS** and **HOLD** either the **UP** or **DN** button. Vertical Speed will seek a rate of change of about 500 fpm.
 - b) **VERTICAL SPEED** Control -- **RELEASE** when desired altitude is reached. The autopilot will maintain the desired altitude.

NOTE

As an alternative, press either the UP or DN button with a succession of quick momentary presses programming either an increase or decrease in the altitude preference at the rate of 20 feet each time the button is depressed.

5. HEADING HOLD:

- a. Heading Selector Knob -- SET BUG to desired heading.
- b. **HDG** Mode Selector Button -- **PRESS**. Note **HDG** mode annunciator **ON**. Autopilot will automatically turn the aircraft to the selected heading.

NOTE

Aircraft heading may change in ROL mode due to turbulence.

c. Heading Selector Knob -- **MOVE BUG** to the desired heading. Autopilot will automatically turn the aircraft to the new selected heading.

6. NAV COUPLING:

- a. **OBS** Knob -- **SELECT** desired course.
- b. NAV Mode Selector Button -- PRESS. Note NAVARM annunciated.
- c. Heading Selector Knob -- ROTATE BUG to agree with OBS course.

NOTE

When NAV is selected, the autopilot will flash HDG for 5 seconds to remind the pilot to reset the HDG bug to the OBS course. IF HDG mode was in use at the time of NAV button selection, a 45° intercept angle will then be automatically established based on the position of the bug.

NOTE

All angle intercepts compatible with radar vectors may be accomplished by selecting ROL mode <u>PRIOR</u> to pressing the NAV button. The HDG bug must still be positioned to agree with the OBS course to provide course datum to the autopilot when using a DG (Directional Gyro).

- 1) If the D-Bar is greater than 2 to 3 dots: the autopilot will annunciate **NAVARM**; when the computed capture point is reached the **ARM** annunciator will go out and the selected course will be automatically captured and tracked.
- 2) If the D-Bar is less than 2 to 3 dots: the HDG mode will disengage upon selecting NAV mode; the NAV annunciator will illuminate and the capture/track sequence will automatically begin.

- 7. APPROACH (APR) COUPLING: (To enable glideslope coupling on an ILS and more precise tracking on instrument approaches).
 - a. **OBS** Knob -- **SELECT** desired approach course. (For a localizer, set it to serve as a memory aid.)
 - b. **APR** Mode Selector Button -- **PRESS**. Note APR ARM annunciated.
 - c. Heading Selector Knob -- **ROTATE BUG** to agree with desired approach.

NOTE

When APR is selected, the autopilot will flash HDG for 5 seconds to remind the pilot to reset the HDG bug to the approach course. If HDG mode was in use at the time of APR button selection, a 45° intercept angle will then be automatically established based on the position of the bug.

NOTE

All angle intercepts compatible with radar vectors may be accomplished by selecting ROL mode <u>PRIOR</u> to pressing the APR button. The HDG bug must still be positioned to agree with the desired approach course to provide course datum to the autopilot when using a DG.

- If the D-Bar is greater than 2 to 3 dots: the autopilot will annunciate APRARM; when the computed capture point is reached the ARM annunciator will go out and the selected course will be automatically captured and tracked.
- 2) If the D-Bar is less than 2 to 3 dots: the HDG mode will disengage upon selecting APR mode; the APR annunciator will illuminate and the capture/track sequence will automatically begin.

Feb 3/97 S11-25

- 8. BACK COURSE (REV) APPROACH COUPLING (i.e., reverse localizer):
 - a. **OBS** Knob -- **SELECT** the localizer course to the <u>front</u> course inbound (as a memory aid).
 - b. **REV** Mode Selector Button -- **PRESS**.
 - c. Heading Selector Knob -- **ROTATE BUG** to the heading corresponding to the localizer <u>front course inbound</u>.

NOTE

When REV is selected, the autopilot will flash HDG for 5 seconds to remind the pilot to reset the HDG bug to the localizer <u>FRONT COURSE INBOUND</u> heading. If heading mode was in use at the time of REV button selection, a 45° intercept angle will then be automatically established based on the position of the bug.

NOTE

All angle intercepts compatible with radar vectors may be accomplished by selecting ROL mode <u>PRIOR</u> to pressing the REV button. The HDG bug must still be positioned to the localizer <u>FRONT COURSE INBOUND</u> heading to provide course datum to the autopilot when using a DG.

- If the D-Bar is greater than 2 to 3 dots: the autopilot will annunciate REVARM; when the computed capture point is reached the ARM annunciator will go out and the selected back course will be automatically captured and tracked.
- 2) If the D-Bar is less than 2 to 3 dots: the HDG mode will disengage upon selecting **REV** mode; the **REV** annunciator will illuminate and the capture/track sequence will automatically begin.

9. GLIDESLOPE COUPLING

a. APR Mode -- ENGAGED, Note GS ARM annunciated.

NOTE

Glideslope coupling is inhibited when operating in NAV or REV modes. With NAV 1 selected to a valid ILS, glideslope ARM and coupling occurs automatically in the APR mode when tracking a localizer.

b. At Glideslope centering -- note ARM annunciator goes out.

NOTE

Autopilot can capture glideslope from above or below the beam.

10. MISSED APPROACH

- a. A/P DISC/TRIM INTER Switch PRESS to disengage AP.
- b. MISSED APPROACH EXECUTE.
- c. AP Button -- After aircraft is in trim, PRESS for autopilot operation if desired.

NOTE

If tracking the ILS course outbound as part of the missed approach procedure is desired, use the NAV mode to prevent inadvertent GS coupling.

11. BEFORE LANDING

a. A/P DISC/TRIM INT Switch -- PRESS to disengage AP.

SECTION 5 PERFORMANCE

There is no change to the airplane performance when the KAP140 2-Axis Autopilot is installed.



Pilot's Operating Handbook and FAA Approved Airplane Flight Manual

CESSNA MODEL 182S
AIRPLANES 18280001 AND ON
SUPPLEMENT 12
CANADIAN

SUPPLEMENT

Member of GAMA
11 July 1997

COPYRIGHT © 1997 CESSNA AIRCRAFT COMPANY WICHITA, KANSAS, USA

182SPHUS-S12-01

Revision 1 - 15 November 2000

S12-1

CANADIAN SUPPLEMENT

The following Log of Effective Pages provides the date of issue for original and revised pages, as well as a listing of all pages in the Supplement. Pages which are affected by the current revision will carry the date of that revision

Revision Level Date of Issue

0 (Original) July 11, 1997 Nov. 15, 2000

LOG OF EFFECTIVITY PAGES

PAGE	DATE	PAGE	DATE
Title (S12-1)	Nov 15/00	S12-3	Nov 15/00
S12-2	Nov 15/00	S12-4	July 11/97

SERVICE BULLETIN CONFIGURATION LIST

The following is a list of Service Bulletins that are applicable to the operation of the airplane, and have been incorporated into this supplement. This list contains only those Service Bulletins that are currently active.

		Airplane		
		Unit	Revision	Incorporated
Number	Title	Effectivity	Incorporation	In Airplane

CANADIAN SUPPLEMENT

SECTION 1 GENERAL

This supplement is required for Canadian operation of Cessna Model 182S.

SECTION 2 LIMITATIONS

The following placard must be installed.

1. Near the fuel tank filler cap:

FUEL

100LL/ 100 MIN. GRADE AVIATION GASOLINE
CAP. 44.0 U.S. GAL. (166 LITRES) USABLE
CAP 32.5 U.S. GAL. (123 LITRES) USABLE
TO BOTTOM OF FILLER INDICATOR TAB

Nov 15/00 S12-3

SECTION 3 EMERGENCY PROCEDURES

There is no change to the airplane emergency procedures when used for Canadian operation.

SECTION 4 NORMAL PROCEDURES

There is no change to basic airplane normal operating procedures when used for Canadian operation.

SECTION 5 PERFORMANCE

There is no change to the airplane performance when used for Canadian operation.



Pilot's Operating Handbook and FAA Approved Airplane Flight Manual

CESSNA MODEL 182S AIRPLANES 18280454 AND ON SUPPLEMENT 13

BENDIX/KING KCS-55A SLAVED COMPASS SYSTEM
WITH KI-525A
HORIZONTAL SITUATION INDICATOR (HSI)

Member of GAMA
15 January 1999

Revision 1 - 15 November 2000

COPYRIGHT © 1999 CESSNA AIRCRAFT COMPANY WICHITA, KANSAS, USA

182SPHUS-S13-01

S13-1

BENDIX/KING KCS-55A SLAVED COMPASS SYSTEM WITH KI-525A HORIZONTAL SITUATION INDICATOR (HSI)

The following Log of Effective Pages provides the date of issue for original and revised pages, as well as a listing of all pages in the Supplement. Pages which are affected by the current revision will carry the date of that revision

Revision Level Date of Issue

0 (Original)

Jan. 15, 1999

Nov. 15, 2000

LOG OF EFFECTIVITY PAGE

PAGE	DATE	PAGE	DATE
Title (S13-1)	Nov 15/00	S13-5	Jan. 15/99
S13-2	Nov 15/00	S13-6	Jan. 15/99
S13-3	Nov 15/00	S13-7	Jan. 15/99
S13-4	Jan. 15/99	S13-8	Jan. 15/99

SERVICE BULLETIN CONFIGURATION LIST

The following is a list of Service Bulletins that are applicable to the operation of the airplane, and have been incorporated into this supplement. This list contains only those Service Bulletins that are currently active.

		Airplane		
		Unit	Revision	Incorporated
<u>Number</u>	<u>Title</u>	Effectivity	Incorporation	In Airplane

BENDIX/KING KCS-55A SLAVED COMPASS SYSTEM WITH KI-525A HORIZONTAL SITUATION INDICATOR (HSI)

SECTION 1 GENERAL

The Bendix/King KCS-55A Slaved Compass System with KI-525A HSI Indicator is an additional navigation indicator option. The KCS-55A compass system includes a slaving control and compensator unit, magnetic slaving transmitter and a remote directional gyro. The information obtained from the KCS-55A compass system is displayed on the KI-525A Indicator.

The panel-mounted KI-525A indicator combines the display functions of both the standard Directional Gyro (Heading Indicator) and the Course Deviation Indicator's VOR/LOC/Glideslope information to provide the pilot with a single visual presentation of the complete horizontal navigation situation.

This system also incorporates a slaving accessory and compensator unit. This unit indicates any difference between the displayed heading and the magnetic heading. Up deflection indicates a clockwise error of the compass card. Down deflection indicates a counterclockwise error of the compass card. Whenever the aircraft is in a turn and the compass card rotates, it is normal for this meter to show a full deflection to one side or the other.

Nov 15/00 S13-3




Figure 1. Horizontal Situation Indicator System (Sheet 1 of 2)

- HORIZONTAL SITUATION INDICATOR (HSI) -- Provides a pictorial presentation of aircraft deviation relative to VOR/GPS radials and localizer beams. It also displays glide slope deviations and gives heading reference with respect to magnetic north. The gyro is remote-mounted and electricdriven
- 2. NAV FLAG -- Flag is in view when the NAV receiver signal is inadequate.
- 3. HEADING REFERENCE (LUBBER LINE) -- Magnetic heading appears under this line when the compass card is slaved or slewed to the aircraft's magnetic heading.
- HEADING WARNING FLAG (HDG) -- When flag is in view, the heading display is invalid.
- 5. COURSE SELECT POINTER -- Indicates VOR/Localizer or GPS course on the compass card. The selected VOR radial or localizer heading remains set on the compass card when the compass card rotates.

- TO/FROM INDICATOR -- Indicates direction of VOR station relative to the selected course. Displays TO when a LOC frequency is selected.
- 7. DUAL GLIDE SLOPE POINTERS -- Displays deviation of airplane from an ILS glideslope. Full scale deflection of the glideslope pointers represents ±0.7 degrees. Pointers will be out of view if an invalid glideslope signal is received.
- 8. GLIDE SLOPE SCALES -- Indicates displacement from glide slope beam center. A glide slope deviation bar displacement of 2 dots represents full-scale (0.7°) deviation above or below glide slope beam centerline.
- 9. HEADING SELECTOR KNOB ()-- Positions the heading bug on compass card by rotating the heading selector knob. The bug rotates with the compass card.
- 10. COMPASS CARD -- Rotates to display heading of airplane with reference to lubber line on HSI.
- 11. COURSE SELECTOR KNOB ()-- Positions the course bearing pointer on the compass card by rotating the course selector knob.
- 12. COURSE DEVIATION BAR (D-BAR) The center portion of the omni bearing pointer moves laterally to pictorially indicate the relationship of airplane to the selected course. It indicates degrees of angular displacement from VOR radials and localizer beams, or displacement in nautical miles from GPS desired course.
- 13. COURSE DEVIATION SCALE -- A course deviation bar displacement of 5 dots represents full scale (VOR = ±10°, LOC = ±2-1/2°, GPS = 5nm enroute, GPS APR = .3nm) deviation from beam centerline.
- 14. HEADING BUG -- Moved by () knob to select desired heading.
- 15. SYMBOLIC AIRCRAFT -- Provides pictorial presentation of the airplane position and intercept angle relative to selected VOR Radial or localizer course.

Figure 1. Horizontal Situation Indicator System (Sheet 2 of 2)

Jan 15/99 S13-5




Figure 2. KA-51B Slaving Accessory and Compensator Unit

- 1. KA-51B SLAVING ACCESSORY AND COMPENSATOR UNIT -- Controls the KCS-55A Compass System.
- 2. MANUAL/AUTOMATIC (FREE/SLAVE) COMPASS SLAVE SWITCH -- Selects either the manual or automatic slaving mode for the Compass System.
- 3. CW/CCW COMPASS MANUAL SLAVE SWITCH -- With the manual/automatic compass slave switch in the FREE position, allows manual compass card slaving in either the clockwise or counterclockwise direction. The switch is spring loaded to the center position.
- 4. SLAVING METER -- Indicates the difference between the displayed heading and the magnetic heading. Up deflection indicates a clockwise error of the compass card. Down deflection indicates a counterclockwise error of the compass card.

SECTION 2 LIMITATIONS

There is no change to the airplane limitations when this instrument is installed.

SECTION 3 EMERGENCY PROCEDURES

There is no change to the airplane emergency procedures when this instrument is installed.

SECTION 4 NORMAL PROCEDURES

CAUTION

ELECTRICAL POWER MUST BE SUPPLIED TO THIS INSTRUMENT FOR PROPER FUNCTIONING. ABSENCE OF WHICH WILL RESULT IN UNRELIABLE HEADING INFORMATION.

Normal procedures for operation of this system differ little from those required for the more conventional Course Deviation Indicators. However, several small differences are worth noting.

The rectilinear movement of the course deviation bar in combination with the rotation of the compass card in response to heading changes, provides an intuitive picture of the navigation situation at a glance when tuned to an omni station. When tuned to a localizer frequency, the course select pointer <u>must</u> be set to the inbound front course for <u>both</u> front and back-course approaches to retain this pictorial presentation.

For normal procedures with autopilots, refer to the Autopilot Supplements in the Supplement section of this handbook. A description of course datum and autopilot procedures for course datum are incorporated in the appropriate autopilot supplements.

SECTION 5 PERFORMANCE

There is no change to the airplane performance when this instrument is installed.

S13-8 Jan 15/99



Pilot's Operating Handbook and FAA Approved Airplane Flight Manual

CESSNA MODEL 182S AIRPLANES 80001 AND ON SUPPLEMENT 14 ARGENTINE SUPPLEMENT



ARGENTINE SUPPLEMENT

The following Log of Effective Pages provides the date of issue for original and revised pages, as well as a listing of all pages in the Supplement. Pages which are affected by the current revision will carry the date of that revision

Revision Level	Date of Issue		
0 (Original)	March 9, 1999		

LOG OF EFFECTIVITY

PAGE	DATE	PAGE	DATE
Title (S14-1) S14-2 S14-3 S14-4	March 9/99 March 9/99 March 9/99 March 9/99	S14-7 S14-8 S14-9 S14-10	March 9/99 March 9/99 March 9/99 March 9/99
S14-5 S14-6	March 9/99 March 9/99	S14-11 S14-12 blank	March 9/99 March 9/99
	Maion 3/33	OIT-12 DIGITA	Maich 3/33

SERVICE BULLETIN CONFIGURATION LIST

The following is a list of Service Bulletins that are applicable to the operation of the airplane, and have been incorporated into this supplement. This list contains only those Service Bulletins that are currently active.

		Airplane		
		Unit	Revision	Incorporated
<u>Number</u>	<u>Title</u>	Effectivity	Incorporation	<u>In Airplane</u>

Original Issue - 9 Mar 1999

ARGENTINE AIRPLANE FLIGHT MANUAL / 9 MARCH 1999



Pilot's Operating Handbook

and

Argentine Airplane Flight Manual

The Cessna Aircraft Company

Model 182S

COPYRIGHT © 1999 The Cessna Aircraft Company Wichita, Kansas USA



Original Issue - 9 March 1999

ARGENTINE AIRPLANE FLIGHT MANUAL / 9 MARCH 1999

THIS MANUAL WAS PROVIDED FOR THE AIRPLANE IDENTIFIED ON THE TITLE PAGE ON ______.
SUBSEQUENT REVISIONS SUPPLIED BY THE CESSNA AIRCRAFT COMPANY MUST BE PROPERLY INSERTED.

The Cessna Aircraft Company, Aircraft Division

LOG OF REVISIONS

Revision Number and Date	Revised Pages	Description of Revision
Revision 1 (6/13/97)		All pages in Revision 1 were incorporated and this Argentine Airplane Flight Manual was provided in a current status at the time of issuance. Subsequent revisions and their affected pages will be recorded at the time of publication.

Original Issue - 9 Mar 1999

ARGENTINE SUPPLEMENT

SECTION 1 GENERAL

This supplement is required for Argentine operation of Cessna Model 182S.

SECTION 2 LIMITATIONS

The following information must be displayed in the form of composite or individual placards.

1. In full view of the pilot: (The "DAY-NIGHT-VFR-IFR" entry, shown on the example below, will vary as the airplane is equipped).

The markings and placards installed in this airplane contain operating limitations which must be complied with when operating this airplane in the Normal Category. Other operating limitations which must be complied with when operating this airplane in this category are contained in the Pilot's Operating Handbook and FAA Approved Airplane Flight Manual.

No acrobatic maneuvers, including spins, approved.

Flight into known icing conditions prohibited.

This airplane is certified for the following flight operations as of date of original airworthiness certificate:

DAY-NIGHT-VFR-IFR

2. On control lock:

CAUTION CONTROL LOCK REMOVE BEFORE STARTING ENGINE

Original Issue - 9 Mar 1999

3. On the fuel selector valve:

BOTH 88.0 GAL. TAKEOFF LANDING ALL FLIGHT ATTITUDES

> FUEL SELECTOF

PUSH DOWN ROTATE

LEFT 44.0 GAL. LEVEL FLIGHT ONLY

RIGHT 44.0 GAL LEVEL FLIGHT ONLY

OFF

4. Near the fuel tank filler cap:

COMBUSTIBLE

100LL/100 GRADO MINIMO COMBUSTIBLE DE AVIACION
CAPACIDAD 166 LTS. USABLE
CAPACIDAD 123 LTS. USABLE
HASTA LA PARTE INFERIOR DEL INDICADOR
DE TAPON DE LLENADO

5. On flap control indicator:

0° to 10°	140 KIAS	(Partial flap range with dark blue color code; also, mechanical detent at 10°.)
10° to 20°	120 KIAS	(Light blue color code; also mechanical detent at 20°)
20° to FULL	100 KIAS	(White color code)

Original Issue - 9 Mar 1999

ARGENTINE AIRPLANE FLIGHT MANUAL / 9 MARCH 1999

6. On baggage door:

54 KG MAXIMO. EQUIPAJE DELANTE DE LA PUERTA DE EQUIPAJE.

36 KG MAXIMO. EQUIPAJE POSTERIOR A TRABA DE LA PUERTA DE EQUIPAJE.

MAXIMO: 90 KG. COMBINADOS.

PARA INSTRUCCIONES DE CARGA
ADICIONALES, VER DATOS DE PESO Y BALANCEO.

- 7. A calibration card must be provided to indicate the accuracy of the magnetic compass in 30° increments.
- 8. On the oil filler cap:

OIL 9 QTS

9. Near airspeed indicator:

VITESSE INDIQUEE DE MANOEUVRE - 110 KIAS

10. On the upper right instrument panel:

SMOKING PROHIBITED

Original Issue - 9 Mar 1999

11. On auxiliary power plug door and second placard on battery box:

PRECAUCION 24 VOLTIOS D.C.
ESTA AERONAVE ESTA EQUIPADA CON
ALTERNADOR Y SISTEMA A TIERRA NEGATIVO.
OBSERVAR POLARIDAD CORRECTA
POLARIDAD OPUESTA CAUSÁ DAÑO
AL LOS COMPONENTES ELÉCTRICOS

CAUTION 24 VOLTS D.C.
THIS AIRCRAFT IS EQUIPPED WITH ALTERNATOR
AND A NEGATIVE GROUND SYSTEM.
OBSERVE PROPER POLARITY
REVERSE POLARITY WILL DAMAGE ELECTRICAL
COMPONENTS.

12. On Upper Right Side of the Aft Cabin Partition:

TRANSMISOR LOCALIZADOR DE EMERGENCIA INSTALADO DETRÁS ESTA DIVISIÓN DEBE CUMPLIR CON EL DNAR PARTE 91.207

13. Near the fuel flow gauge:

MAXIMUM POWER FUEL FLOW			
ALTITUDE S.L. 2000' 4000' 6000' 8000' 10000'	FUEL FLOW 20.5 GPH 19.0 GPH 17.5 GPH 16.5 GPH 15.5 GPH 14.5 GPH 13.5 GPH		

Original Issue - 9 Mar 1999

ARGENTINE AIRPLANE FLIGHT MANUAL / 9 MARCH 1999

SECTION 3 EMERGENCY PROCEDURES

There is no change to the airplane emergency procedures when used for Argentine operation.

SECTION 4 NORMAL PROCEDURES

There is no change to the airplane normal operating procedures when used for Argentine operation.

SECTION 5 PERFORMANCE

There is no change to the airplane performance when used for Argentine operation.

Original Issue - 9 Mar 1999

ARGENTINE AIRPLANE FLIGHT MANUAL / 9 MARCH 1999

•	₹)	e.	
			3



Pilot's Operating Handbook and FAA Approved Airplane Flight Manual

CESSNA MODEL 182S

AIRPLANES 18280165 AND ON OR AS MODIFIED BY MK182-22-01

SUPPLEMENT 15

BENDIX/KING KAP 140 2 AXIS AUTOPILOT

Member of GAMA

1 December 1997

COPYRIGHT © 1997 CESSNA AIRCRAFT COMPANY WICHITA, KANSAS, USA

182SPHUS-S15-01

Revision 1 - 31 December 1999

S15-1

BENDIX/KING KAP 140 2 AXIS AUTOPILOT

The following Log of Effective Pages provides the date of issue for original and revised pages, as well as a listing of all pages in the Supplement. Pages which are affected by the current revision will carry the date of that revision

Revision Level	Date of Issue
0 (Original)	Dec. 1, 1997
1	Dec. 31, 1999

LOG OF EFFECTIVITY PAGES

PAGE	DATE	PAGE	DATE
Title (S15-1) S15-2 S15-3 S15-4 (blank) S15-5 S15-6 S15-7 S15-8 S15-9 S15-10 S15-11	Dec 31/99 Dec 31/99 Dec 1/97 Dec 1/97 Dec 31/99 Dec 31/99 Dec 1/97 Dec 1/97 Dec 1/97 Dec 1/97 Dec 1/97	S15-17 S15-18 S15-19 S15-20 S15-21 S15-22 S15-23 S15-24 S15-25 S15-26 S15-27	Dec 31/99 Dec 31/99 Dec 31/99 Dec 31/99 Dec 31/99 Dec 31/99 Dec 31/99 Dec 31/99 Dec 31/99 Dec 31/99
S15-12 S15-13	Dec 31/99 Dec 31/99	S15-28 S15-29	Dec 31/99 Dec 31/99
S15-14 S15-15	Dec 31/99 Dec 31/99	S15-30 S15-31	Dec 31/99 Dec 31/99
S15-16	Dec 31/99	S15-32	Dec 31/99

S15-2 Dec 31/99

BENDIX/KING KAP 140 2 AXIS AUTOPILOT EXCLUDING FLAP LIMITATIONS

SERVICE BULLETIN CONFIGURATION LIST

The following is a list of Service Bulletins that are applicable to the operation of the airplane, and have been incorporated into this supplement. This list contains only those Service Bulletins that are currently active.

Number Title

<u> Airplane Unit</u> Effectivity

Revision Incorporation In Airplane

Incorporated

2:	*
	1,00

BENDIX/KING KAP 140 2 AXIS AUTOPILOT

SECTION 1 GENERAL

The KAP 140, 2 Axis Autopilot provides the pilot with the following features: Vertical Speed mode (VS); Altitude hold (ALT); Wing Level (ROL); Heading select (HDG); Approach (APR); ILS coupling to Localizer (LOC) and Glideslope (GS); and backcourse (REV) modes of operation. The optional KAP 140, 2 Axis Autopilot with Altitude Preselect (if installed) adds Altitude Alerter and Altitude Preselect capabilities.

The KAP 140, 2 Axis Autopilot has an electric trim system which provides autotrim during autopilot operation and manual electric trim (MET) for the pilot when the autopilot is not engaged. The electric trim system is designed to be fail safe for any single inflight trim malfunction. Trim faults are visually and aurally annunciated.

A lockout device prevents autopilot or MET engagement until the system has successfully passed preflight self test. Automatic preflight self-test begins with initial power application to the autopilot.

The following conditions will cause the Autopilot to disengage:

- A. Electric Power failure.
- B. Internal Autopilot System failure.

- C. Pitch accelerations in excess of +1.4g or less than +0.6g only when produced by a failure causing servo runaway. The pilot cannot maneuver the aircraft and trip the monitor.
- D. Turn coordinator failure (flagged gyro).
- E. Computer autopilot monitor that detects either the R (ROLL) or P (PITCH) axis annunciator.

Activation of A/P DISC/TRIM INT control wheel switch will also disconnect the autopilot.

The AVIONICS MASTER switch supplies power to the avionics bus bar of the radio circuit breakers and the autopilot circuit breaker. The AVIONICS MASTER switch also serves as an emergency AP/MET shutoff.

The following circuit breakers are used to protect the KAP 140 2-Axis Autopilot:

<u>LABEL</u>	<u>FUNCTIONS</u>
AUTO PILOT	Pull-off circuit breaker supplies power to the KC 140 Computer and the autopilot pitch, roll and pitch trim servos.
WARN	Supplies separate power for autopilot alerting (PITCH TRIM) on the ship's annunciator panel.





Figure 1. Bendix/King 2-Axis KAP 140 Autopilot Schematic (Sheet 1 of 5)



- 1. PITCH AXIS (P) ANNUNCIATOR -- When illuminated, indicates failure of pitch axis and will either disengage the autopilot or not allow engagement of the pitch axis. In turbulent air, will illuminate during abnormal vertical/accelerations.
- 2. AUTOPILOT ENGAGE/DISENGAGE (AP) BUTTON -- When pushed, engages autopilot if all preflight self-test conditions are met. The autopilot will engage in the basic roll (ROL) mode which functions as a wing leveler and the pitch axis vertical speed (VS) mode. The commanded vertical speed will be displayed in the upper right corner of autopilot display area. The captured VS will be the vertical speed present at the moment the AP button is pressed. The button may also be used to disengage the autopilot.
- 3. ROLL AXIS (R) ANNUNCIATOR -- When illuminated, indicates failure of the roll axis and disengages the autopilot.

Figure 1. Bendix/King 2-Axis KAP 140 Autopilot, Operating Controls and Indicators (Sheet 2 of 5)

- 4. HEADING (HDG) MODE SELECTOR BUTTON -- When pushed, will select the Heading mode, which commands the airplane to turn to and maintain the heading selected by the heading bug on the Directional Gyro. A new heading may be selected at any time and will result in the airplane turning to the new heading. The button can also be used to toggle between HDG and ROL modes. This button can also be used to engage the autopilot in HDG mode.
- 5. NAVIGATION (NAV) MODE SELECTOR BUTTON -- When pushed, will select the Navigation mode. This mode provides automatic beam capture and tracking of VOR, LOC, or GPS signals as selected for presentation on the #1 CDI. NAV mode is recommended for enroute navigation tracking.
- 6. APPROACH (APR) MODE SELECTOR BUTTON -- When pushed, will select the Approach mode. This mode provides automatic beam capture and tracking of VOR, GPS, LOC and Glideslope (GS) on an ILS, as selected for presentation on #1 CDI. APR mode tracking sensitivity is recommended for instrument approaches.
- 7. BACK COURSE APPROACH (REV) MODE BUTTON -- This button is active only when the coupled navigation receiver is tuned to a LOC/ILS frequency. When pushed will select the Back Course approach mode. This mode functions identically to the approach mode except that the autopilot response to LOC signals is reversed. Glideslope is locked out with REV mode.
- 8. ALTITUDE HOLD (ALT) MODE SELECT BUTTON -- When pushed, will select the altitude hold mode. This mode provides capture and tracking of the selected altitude. The selected altitude is the airplane altitude at the moment the ALT button is pressed. If the ALT button is pressed with an established VS rate present, there will be about a 10% (of VS rate) overshoot. The airplane will return positively to the selected altitude. This button may be used to engage the autopilot in the ALT mode.

Figure 1. Bendix/King 2-Axis KAP 140 Autopilot, Operating Controls and Indicators (Sheet 3 of 5)

Dec 1/97 S15-9


- 9. VERTICAL SPEED (UP/DN) MODE BUTTONS -- The action of these buttons depends on the vertical mode present when pressed. If VS mode is active (AP plus any lateral mode) and the UP button is pressed, the autopilot will modify the displayed VS command (FPM) in the up direction. Single momentary cycles on either the UP or DN button will increment the VS command by 100 FPM per cycle. When either button is continuously held in, it will modify the vertical speed command by 300 fpm per second.
 - If ALT mode is active, pressing the UP/DN buttons will modify the captured altitude by 20 feet per cycle, or if held continuously will command the airplane up or down at the rate of 500 FPM, synchronizing the ALT reference to the actual airplane altitude upon button release.
- 10. AUTO PILOT CIRCUIT BREAKER -- A 5-amp pull-off circuit breaker supplying 28 VDC to the KAP 140 system.
- 11. WARN C/B -- Power to the autopilot disconnect horn and the ship's annunciator panel (PITCH TRIM).
- 12. AUTOPILOT DISCONNECT (A/P DISC/TRIM INT) SWITCH -- When depressed will disengage the autopilot and interrupt manual electric trim (MET) power. An autopilot disconnect will be annunciated by a continuous 2 second tone accompanied by a flashing "AP" displayed on the autopilot computer.
- 13. MANUAL ELECTRIC TRIM (MET) SWITCHES -- When both switches are pressed in the same direction, will activate pitch trim in the selected direction. If only one switch is moved, the trim system will not operate. If only the right half of the MET switch assembly is held, simulating a stuck switch, for 3 seconds, the trim monitoring system will detect a switch failure resulting in a T annunciation on the autopilot display and the disabling of the electric trim system. If the stuck switch is corrected, the fault will clear. Use of manual electric trim during autopilot operation will disengage the autopilot.

Figure 1. Bendix/King 2-Axis KAP 140 Autopilot, Operating Controls and Indicators (Sheet 4 of 5)

- 14. OMNI BEARING SELECT (OBS) KNOB -- Selects the desired course to be tracked by the autopilot. (Note: The HDG bug must also be positioned to the proper course to capture and track the selected radial or desired track).
- 15. HEADING SELECT KNOB (HDG) -- Positions the heading bug on the compass card. Note that the position of the heading bug also provides course datum to the autopilot when tracking in NAV, APR, or REV (BC) modes. This is in addition to its more intuitive use in the HDG mode.
- 16. PITCH TRIM (PT) Annunciator -- Indicates the direction of required pitch trim. The annunciation will flash if auto trim has not satisfied the request for trim for a period of 10 seconds. A solid P without an arrowhead is an indication of a pitch trim fault. Refer to the EMERGENCY PROCEDURES for proper response to a pitch trim fault.
- 17. PITCH TRIM Annunciation -- Illuminates whenever the automated preflight self test detects a pitch trim fault or the continuous monitoring system detects a pitch trim fault in flight. Refer to the EMERGENCY PROCEDURES for proper response to a pitch trim fault.

Figure 1. Bendix/King 2-Axis KAP 140 Autopilot, Operating Controls and Indicators (Sheet 5 of 5)

Dec 1/97 S15-11



- 1. ROTARY KNOBS -- Used to set the altitude alerter reference altitude; or may be used immediately after pressing the BARO button, to adjust the autopilot baro setting to match that of the airplane's altimeter when manual adjustment is required. (In some systems, the baro setting may be automatically synched to that of the altimeter.)
- 2. BARO SET (BARO) BUTTON -- When pushed and released, will change the display from the altitude alerter selected altitude to the baro setting display (either IN HG or HPA) for 3 seconds. If pushed and held for 2 seconds, will change the baro setting display from IN HG to HPA or vice versa. Once the baro setting display is visible the rotary knobs may be used to adjust the baro setting.
- 3. ALTITUDE ARM (ARM) BUTTON -- When pushed, will toggle altitude arming on or off. When ALT ARM is annunciated, the autopilot will capture the altitude alerter displayed altitude (provided the aircraft is climbing or descending in VS to the displayed altitude). ALT hold arming when the autopilot is engaged is automatic upon altitude alerter altitude selection via the rotary knobs. Note that the alerter functions are independent of the arming process thus providing full time alerting, even when the autopilot is disengaged.



Figure 2. Bendix/King 2-Axis KAP 140 Autopilot with Altitude Preselect, Operating Controls and Indicators (Sheet 1 of 2)

4. ALTITUDE ALERTER/VERTICAL SPEED/BARO SETTING DISPLAY -- Normally displays the altitude alerter selected altitude. If the UP or DN button is pushed while in VS hold, the display changes to the command reference for the VS mode in FPM for 3 seconds. If the BARO button is pushed, the display changes to the autopilot baro setting in either IN HG or HPA for 3 seconds.

NOTE

This display may be dashed for up to 3 minutes on start up if a blind encoder is installed which requires a warm-up period.

5. ALTITUDE ALERT (ALERT) ANNUNCIATION -- Illuminates continuously in the region of from 200 to 1000 feet from the selected altitude if the airplane was previously outside of this region. Flashes (1) for two seconds the first time the airplane crossed the selected altitude and (2) continuously in the 200 to 1000 feet region if the airplane was previously inside of this region (i.e. at the selected altitude). Associated with the visual alerting is an aural alert (5 short tones) which occurs 1000 feet from the selected altitude upon approaching the altitude and 200 feet from the selected altitude on leaving the altitude.

Figure 2. Bendix/King 2-Axis KAP 140 Autopilot with Altitude Preselect, Operating Controls and Indicators (Sheet 2 of 2)

SECTION 2 LIMITATIONS

The following autopilot limitations must be adhered to:

- The entire preflight test procedure outlined under Section 4, paragraph A of this supplement, including steps 1 through 7, must be successfully completed prior to each flight. Use of the autopilot or manual electric trim system is prohibited prior to completion of these tests.
- 2. During autopilot operation, a pilot with seat belt fastened must be seated at the left pilot position.
- 3. The autopilot must be OFF during takeoff and landing.
- 4. The system is approved for Category I operation only (Approach mode selected).
- 5. Autopilot maximum airspeed limitation -- 160 KIAS. Autopilot minimum airspeed limitation -- 80 KIAS.
- Maximum flap extension -- 10°.
- 7. Maximum fuel imbalance with autopilot engaged -- 90 lbs.
- 8. The autopilot must be disengaged below 200 feet AGL during approach operations and below 800 feet AGL for all other phases of flight.
- 9. Overriding the autopilot to change pitch or roll attitude is prohibited. (Disengage with A/P DISC/TRIM INT or AP select button.)
- 10. The AUTO PILOT circuit breaker must be pulled following any inflight illumination of the red "PITCH TRIM" warning light, but only after first completing the Emergency Procedures (Section 3, paragraph 1.). The manual electric trim and autopilot autotrim systems will be disabled with the AUTO PILOT circuit breaker pulled.

SECTION 3 EMERGENCY PROCEDURES

The four step procedure listed under paragraph A should be among the basic airplane emergency procedures that are committed to memory. It is important that the pilot be proficient in accomplishing all four steps without reference to this manual.

- 1. In case of Autopilot, Autopilot Trim, or Manual Electric Trim malfunction (accomplish Items A and B simultaneously):
 - A. Airplane Control Wheel -- GRASP FIRMLY and regain aircraft control.
 - B. A/P DISC/TRIM INT Switch -- PRESS and HOLD throughout recovery.
 - C. AIRCRAFT -- RE-TRIM Manually as Needed.
 - D. AUTO PILOT Circuit Breaker -- PULL.

NOTE

The AVIONICS MASTER Switch may be used as an alternate means of removing all electric power from the autopilot and electric trim systems. If necessary perform steps 1A through 1C above, then turn the AVIONICS MASTER Switch OFF before locating and pulling the AUTO PILOT Circuit Breaker. Turn the AVIONICS MASTER Switch on as soon as possible to restore power to all other avionics equipment. Primary attitude, airspeed, directional compass, and altitude instruments will remain operational at all times.

WARNING

DO NOT ATTEMPT TO RE-ENGAGE THE AUTOPILOT FOLLOWING AN AUTOPILOT, AUTOTRIM, OR MANUAL ELECTRIC TRIM MALFUNCTION UNTIL THE CAUSE FOR THE MALFUNCTION HAS BEEN CORRECTED.

Maximum Altitude losses due to autopilot malfunction:

CONFIGURATION	ALT. LOSS
Cruise, Climb, Descent	250 ft.
Maneuvering	100 ft.
Approach	50 ft.

Dec 31/99 S15-15

AMPLIFIED EMERGENCY PROCEDURES

The following paragraphs are presented to supply additional information for the purpose of providing the pilot with a more complete understanding of the recommended course of action for an emergency situation.

 An autopilot or autotrim malfunction occurs when there is an uncommanded deviation in the airplane flight path or when there is abnormal control wheel or trim wheel motion. In some cases, and especially for autopilot trim, there may be little to no airplane motion, yet the red PITCH TRIM annunciator (ship's annunciator panel) may illuminate and an alert tone may sound.

The primary concern in reacting to an autopilot or autopilot trim malfunction, or to an automatic disconnect of the autopilot, is in maintaining control of the airplane. Immediately grasp the control wheel and press and hold down the A/P DISC/TRIM INT switch throughout the recovery. Manipulate the controls as required to safely maintain operation of the airplane within all of its operating limitations. Elevator trim should be used manually as needed to relieve control forces. Locate and pull the AUTO PILOT circuit breaker on the right hand circuit breaker panel to completely disable the autopilot system.

2. A manual electric trim malfunction may be recognized by illumination of the red **PITCH TRIM** annunciator, accompanied by an alert tone, or by unusual trim wheel motions with the autopilot OFF, without pilot actuation of the manual electric trim switches. As with an autopilot malfunction, the first concern following a manual electric trim malfunction is maintaining control of the airplane. Grasp the control wheel firmly and press and hold down the A/P DISC/TRIM INT switch. Locate and pull the AUTO PILOT circuit breaker on the right hand breaker panel.

- 3. Note that the emergency procedure for any malfunction is essentially the same: immediately grasp the control wheel and regain airplane control while pressing and holding the A/P DISC/TRIM INT switch down, and retrim the airplane as needed. After these steps have been accomplished secure the autopilot electric trim system by pulling the autopilot (AUTO PILOT) circuit breaker. As with any other airplane emergency procedure, it is important that the 4 steps of the emergency procedure located on Page 15 be committed to memory.
- 4. The AVIONICS MASTER switch may be used to remove all electric power from the Autopilot and Electric Trim systems while the circuit breaker is located and pulled. Return the AVIONICS MASTER switch to the ON position as soon as possible. With the AVIONICS MASTER switch off, all avionics and autopilot equipment will be inoperable.
- 5. It is important that all portions of the autopilot and electric trim system are preflight tested prior to each flight in accordance with the procedures published herein in order to assure their integrity and continued safe operation during flight.

WARNING

DO NOT RESET AUTOPILOT CIRCUIT BREAKER FOLLOWING AN AUTOPILOT/AUTOTRIM OR MANUAL ELECTRIC TRIM MALFUNCTION UNTIL THE CAUSE FOR THE MALFUNCTION HAS BEEN CORRECTED.

A flashing $\frac{\mathbf{P}}{\mathbf{T}}$ auto trim annunciation on the face of the autopilot indicates a failure of the auto trim function to relieve pitch servo loading in a timely manner. This condition should be temporary.

1. FLASHING P ANNUNCIATION -- OBSERVE aircraft pitch behavior. If pitch behavior is satisfactory, wait 5-10 seconds for the annunciation to stop.

- 2. If annunciation continues, Airplane Control Wheel -- GRASP FIRMLY, disengage the autopilot and check for an out of pitch trim condition. Manually retrim as required.
- 3. AUTOPILOT OPERATION -- CONTINUE if satisfied that the out of trim indication was temporary. DISCONTINUE if evidence indicates a failure of the auto trim function.

A red P or R on the face of the autopilot computer.

 A red P is an indication that the pitch axis of the autopilot has been disabled and cannot be engaged. DO NOT ENGAGE INTO A ROLL AXIS ONLY SYSTEM.

NOTE

If the red **P** lamp was the result of some abnormal accelerations on the airplane, the annunciation should be extinguished within approximately one minute and normal use of the autopilot will be reestablished.

2. A red **R** is an indication that the roll axis of the autopilot has been disabled and cannot be engaged. The autopilot cannot be reengaged.

Flashing mode annunciation in the display of the autopilot computer.

- 1. Flashing **HDG** -- Indicates a failed heading. **PRESS HDG** button to terminate flashing. ROL will be displayed.
- Flashing NAV, APR or REV -- Usually an indication of a flagged navigation source. PRESS the NAV, APR or REV button to terminate flashing. ROL will be displayed. (Select a valid navigation source.)

NOTE

A flashing NAV, APR or REV annunciation can also be caused by a failed heading valid input.

3. Flashing **GS** -- Indication of a flagged glideslope. (GS will rearm automatically if a valid GS signal is received.)

NOTE

To continue tracking the localizer, observe the appropriate minimums for a nonprecision approach. (Press ALT twice in rapid succession to terminate the flashing. Control the pitch axis in the default VS mode.)

NOTE

At the onset of mode annunciator flashing, the autopilot has already reverted to a default mode of operation, i.e., ROL and or VS mode. An immediate attempt to reengage to lost mode may be made if the offending navigation, glideslope or compass flag has cleared.

EXCEPTION

The HDG annunciation will flash for 5 seconds upon selection of NAV, APR, or REV modes to remind the pilot to set the HDG bug for use as course datum.

Effects of instrument losses upon autopilot operation:

- 1. Loss of the artificial horizon -- no effect on the autopilot.
- 2. Loss of the turn coordinator -- autopilot inoperative.
- 3. Loss of the Directional Gyro (DG)-- The directional gyro does not provide any system valid flag. If the DG fails to function properly the autopilot heading and navigation mode will not function correctly. Under these conditions, the only useable lateral mode is ROL.
- 4. Loss of Horizontal Situation Indicator (HSI) (if installed) -- If the HSI fails to function properly the autopilot heading and navigation mode will not function correctly. Under these conditions, the only usable lateral mode is ROL.
- Loss of Blind Altitude Encoder -- Altitude Alerter and Altitude Preselect function inoperative.

Dec 31/99 S15-19

SECTION 4 NORMAL PROCEDURES

- A. PREFLIGHT (PERFORM PRIOR TO EACH FLIGHT):
 - 1. AVIONICS MASTER -- ON.
 - 2. POWER APPLICATION AND SELF TEST -- A self test is performed upon power application to the computer. This test is a sequence of internal checks that validate proper system operation prior to allowing normal system operation. The sequence is indicated by "PFT" with an increasing number for the sequence steps. Successful completion of self test is identified by all display segments being illuminated (Display Test), external "Pitch Trim" (A/C System Annunciator Panel) being illuminated, and the disconnect tone sounding.

NOTE

Upon applying power to the autopilot, the red P warning on the face of the autopilot may illuminate indicating that the pitch axis cannot be engaged. This condition should be temporary, lasting approximately 30 seconds. The P will extinguish and normal operation will be available.

WARNING

IF PITCH TRIM LIGHT STAYS ON, THEN THE AUTOTRIM DID NOT PASS PREFLIGHT TEST. THE AUTOPILOT CIRCUIT BREAKER MUST BE PULLED. MANUAL ELECTRIC TRIM AND AUTOPILOT ARE INOPERATIVE.

3. MANUAL ELECTRIC TRIM -- TEST as follows: Press both halves of the split Manual Electric Trim (MET) switches to the nose down position, verify that the trim wheel and the trim tab position indicator are moving in the down direction. Repeat test for the nose up direction.

Press MET for nose up trim, press and hold the AP DISC/TRIM INT switch, verify that both the trim wheel and indicator are not moving, release the A/P DISC / TRIM INT switch while still holding MET trim up, the trim wheel and indicator should continue to move in the nose up direction.

- FLASHING BARO SETTING (if installed) -- SET proper baro setting manually (or press BARO to accept the present value).
- AUTOPILOT -- ENGAGE by pressing AP button.
- FLIGHT CONTROLS -- MOVE fore, aft, left and right to verify the autopilot can be overpowered.
- A/P DISC/TRIM INT Switch -- PRESS. Verify that the autopilot disconnects.
- TRIM -- SET to take off position manually.

WARNING

THE PILOT IN COMMAND MUST CONTINUOUSLY MONITOR THE AUTOPILOT WHEN IS ENGAGED. AND BE PREPARED TO DISCONNECT THE **AUTOPILOT AND TAKE** IMMEDIATE CORRECTIVE ACTION -- INCLUDING MANUAL CONTROL OF THE AIRPLANE AND/OR PERFORMANCE OF EMERGENCY PROCEDURES -- IF AUTOPILOT OPERATION IS NOT AS **EXPECTED OR IF AIRPLANE CONTROL IS NOT** MAINTAINED.

A WARNING

DURING ALL AUTOPILOT COUPLED OPER-ATIONS, THE PILOT IN COMMAND MUST USE PROPER AUTOPILOT COMMANDS AND USE THE PROPER ENGINE POWER TO ENSURE THAT THE AIRPLANE IS MAINTAINED BETWEEN 80 AND 160 KIAS, AND DOES NOT EXCEED OTHER BASIC AIRPLANE OPERATING LIMITATIONS.

Autopilot tracking performance will be degraded in turbulence.

- 1. BEFORE TAKEOFF:
 - a. A/P DISC/TRIM INT Switch -- PRESS.
 - b. BARO setting (if installed) -- CHECK.

A CAUTION

CONTINUE TO SET MANUALLY THROUGHOUT THE FLIGHT EACH TIME THE ALTIMETER BARO SETTING REQUIRES ADJUSTMENT. NO FURTHER REMINDERS (FLASHING) WILL BE GIVEN.

c. **ALTITUDE SELECT** KNOB (if installed) -- **ROTATE** until the desired altitude is displayed.

NOTE

An altitude alert is annunciated 1000 ft. prior to arrival at the selected altitude. Aircraft deviations greater than 200 feet above or below the selected altitude will produce an altitude alert. The alert annunciation is accompanied by a series of short tones.

2. AFTER TAKEOFF:

a. Elevator Trim -- **VERIFY** or **SET** to place the airplane in a trimmed condition prior to Autopilot engagement.

NOTE

Engaging the autopilot into a mistrim condition may cause unwanted attitude changes and a "TRIM FAIL" annunciation.

b. Airspeed and Rate of Climb -- STABILIZED.

Avoid autopilot engagement into a climb condition that either cannot be maintained, or is on the performance limits of the airplane for its power and weight configuration.

c. AP Button -- PRESS. Note ROL and VS annunciator on. If no other modes are selected the autopilot will operate in the ROL and VS modes.

WARNING

WHEN OPERATING AT OR NEAR THE BEST RATE OF CLIMB AIRSPEED, AT CLIMB POWER SETTINGS, AND USING VERTICAL SPEED (VS) MODE, CONTINUED OPERATION IN VERTICAL SPEED MODE CAN RESULT IN AN AIRPLANE STALL. IF NECESSARY, DISCONNECT THE AUTO PILOT AND RETURN THE AIRPLANE TO A STABILIZED CLIMB PRIOR TO RE-ENGAGMENT.

A WARNING

WHEN OPERATING AT OR NEAR THE MAXIMUM AUTOPILOT SPEED, IT WILL BE NECESSARY TO REDUCE POWER IN ORDER TO MAINTAIN THE DESIRED RATE OF DESCENT AND NOT EXCEED THE MAXIMUM AUTOPILOT SPEED.

WARNING

DO NOT HELP THE AUTOPILOT OR HAND-FLY WITH THE AIRPLANE **AUTOPILOT** ENGAGED AS THE AUTOPILOT WILL RUN THE PITCH TRIM TO OPPOSE CONTROL WHEEL MOVEMENT. A MISTRIM OF THE AIRPLANE. WITH ACCOMPANYING LARGE ELEVATOR CONTROL FORCES, MAY RESULT IF THE PILOT MANIPULATES THE CONTROL WHEEL MANUALLY WHILE THE AUTOPILOT ENGAGED.

3. CLIMB OR DESCENT:

- a. BARO setting (if installed) -- CHECK.
- b. Using Vertical Trim:
 - 1) **VERTICAL SPEED** Control -- **PRESS** either the **UP** or **DN** button to select aircraft vertical speed within the command limits of ±2000 ft./min.
 - 2) **VERTICAL SPEED** Control -- **RELEASE** when desired vertical speed is displayed. The autopilot will maintain the displayed vertical speed.

NOTE

Avoid selecting a climb rate that either cannot be maintained or is on the performance limit of the airplane for its power and weight configuration.

4. ALTITUDE HOLD:

- a. Capture preselected altitudes (if installed):
 - 1) ALTITUDE SELECT knob -- ROTATE until the desired altitude is displayed. Note ARM annunciation occurs automatically with altitude selection when the autopilot is engaged.
 - 2) ALTITUDE SELECT MODE (ARM) button -- PUSH to alternately disarm or arm altitude capture.
 - 3) Airplane -- **ESTABLISH** vertical speed necessary to intercept the selected altitude.

NOTE

It may be possible to observe minor difference between the autopilots' selected altitude and the aircraft altimeter after an altitude capture. Not inputing the proper barometric setting into the autopilot computer will produce inaccuracies.

S15-24 Dec 31/99

Altitude preselect captures are not recommended on nonprecision approaches to capture the MDA. Glideslope coupling will preclude a preselect altitude capture on an ILS.

- b. Altitude (ALT) Hold Button:
 - ALT Hold Selector Button -- PRESS. Note ALT hold annunciator ON. Autopilot will maintain the selected altitude.

NOTE

It is recommended by the FAA (AC00-24B) to use basic "PITCH ATTITUDE HOLD" mode during operation in severe turbulence. However, since this autopilot does <u>not</u> use the attitude gyro as a pitch reference, it is recommended that the autopilot be disconnected and that the airplane be flown by hand in severe turbulence.

- c. Changing altitudes:
 - 1) Using Vertical Speed (Recommended for altitude changes less than 100 ft.)
 - a) **VERTICAL SPEED** Control -- **PRESS** and **HOLD** either the **UP** or **DN** button. Vertical Speed will seek a rate of change of about 500 fpm.
 - b) **VERTICAL SPEED** Control -- **RELEASE** when desired altitude is reached. The autopilot will maintain the desired altitude.

NOTE

As an alternative, a series of quick momentary presses on the **UP** or **DN** button will program either an increase or decrease of the altitude reference, 20 feet each time the button is pressed.

5. HEADING HOLD:

- a. Heading Selector Knob -- SET BUG to desired heading.
- b. **HDG** Mode Selector Button -- **PRESS**. Note **HDG** mode annunciator **ON**. Autopilot will automatically turn the aircraft to the selected heading.

NOTE

Aircraft heading may change in ROL mode due to turbulence.

c. Heading Selector Knob -- MOVE BUG to the desired heading. Autopilot will automatically turn the aircraft to the new selected heading.

6. NAV COUPLING:

ı

- a. When equipped with DG:
 - 1) OBS Knob -- SELECT desired course.
 - NAV Mode Selector Button -- PRESS. Note NAVARM annunciated.
 - Heading Selector Knob -- ROTATE BUG to agree with OBS course.

NOTE

When NAV is selected, the autopilot will flash HDG for 5 seconds to remind the pilot to reset the HDG bug to the OBS course. IF HDG mode was in use at the time of NAV button selection, a 45° intercept angle will then be automatically established based on the position of the bug.

All angle intercepts compatible with radar vectors may be accomplished by selecting ROL mode <u>PRIOR</u> to pressing the NAV button. The HDG bug must still be positioned to agree with the OBS course to provide course datum to the autopilot when using a DG (Directional Gyro).

- a) If the D-Bar is greater than 2 to 3 dots, the autopilot will annunciate NAVARM. When the computed capture point is reached the ARM annunciator will go out and the selected course will be automatically captured and tracked.
- b) If the D-Bar is less than 2 to 3 dots, the HDG mode will disengage upon selecting NAV mode. The NAV annunciator will then illuminate and the capture/track sequence will automatically begin.
- b. When equipped with HSI:
 - 1) Course Bearing Pointer **SET** to desired course.
 - Heading Selector Knob -- SET BUG to provide desired intercept angle and engage HDG mode.
 - 3) NAV Mode Selector Button -- PRESS.
 - a) If the D-Bar is greater than 2 to 3 dots, the autopilot will annunciate NAVARM. When the computed capture point is reached the ARM annunciator will go out and the selected course will be automatically captured and tracked.
 - b) If the D-Bar is less than 2 to 3 dots, the HDG mode will disengage upon selecting NAV mode. The NAV annunciator will then illuminate and the capture/track sequence will automatically begin.

- 7. APPROACH (APR) COUPLING: (To enable glideslope coupling on an ILS and more precise tracking on instrument approaches).
 - a. When equipped with DG:
 - 1) BARO setting -- CHECK (if installed).
 - 2) **OBS** Knob -- **SELECT** desired approach course. (For a localizer, set it to serve as a memory aid.)
 - 3) APR Mode Selector Button -- PRESS. Note APRARM annunciated.
 - 4) Heading Selector Knob -- ROTATE BUG to agree with desired approach.

When APR is selected, the autopilot will flash HDG for 5 seconds to remind the pilot to reset the HDG bug to the approach course. If HDG mode was in use at the time of APR button selection, a 45° intercept angle will then be automatically established based on the position of the bug.

NOTE

All angle intercepts compatible with radar vectors may be accomplished by selecting ROL mode <u>PRIOR</u> to pressing the APR button. The HDG bug must still be positioned to agree with the desired approach course to provide course datum to the autopilot when using a DG.

- a) If the D-Bar is greater than 2 to 3 dots: the autopilot will annunciate **APRARM**; when the computed capture point is reached the **ARM** annunciator will go out and the selected course will be automatically captured and tracked.
- b) If the D-Bar is less than 2 to 3 dots: the HDG mode will disengage upon selecting APR mode; the APR annunciator will illuminate and the capture/track sequence will automatically begin.

- b. When equipped with HSI:
 - 1) BARO Setting (if installed) -- CHECK.
 - 2) Course Bearing Pointer -- SET to desired course.
 - Heading Selector Knob -- SET BUG to provide desired intercept angle.
 - 4) APR Mode Selector Button -- PRESS.
 - a) If the D-Bar is greater than 2 to 3 dots: the autopilot will annunciate APRARM; when the computed capture point is reached the ARM annunciator will go out and the selected course will be automatically captured and tracked.
 - b) If the D-Bar is less than 2 to 3 dots: the HDG mode will disengage upon selecting APR mode; the APR annunciator will illuminate and the capture/track sequence will automatically begin.
 - 5) Airspeed -- MAINTAIN 100 KIAS minimum during coupled autopilot approaches (recommended).
- 8. BACK COURSE (REV) APPROACH COUPLING (i.e., reverse localizer):
 - a. When equipped with DG:
 - 1) BARO setting (if installed) -- CHECK.
 - OBS Knob -- SELECT the localizer course to the <u>front</u> <u>course inbound</u> (as a memory aid).
 - 3) REV Mode Selector Button -- PRESS.
 - 4) Heading Selector Knob -- **ROTATE BUG** to the heading corresponding to the localizer front course inbound.

When REV is selected, the autopilot will flash HDG for 5 seconds to remind the pilot to reset the HDG bug to the localizer FRONT COURSE INBOUND heading. If heading mode was in use at the time of REV button selection, a 45° intercept angle will then be automatically established based on the position of the bug.

NOTE

All angle intercepts compatible with radar vectors may be accomplished by selecting ROL mode <u>PRIOR</u> to pressing the REV button. The HDG bug must still be positioned to the localizer <u>FRONT COURSE INBOUND</u> heading to provide course datum to the autopilot when using a DG.

- a) If the D-Bar is greater than 2 to 3 dots: the autopilot will annunciate REVARM; when the computed capture point is reached the ARM annunciator will go out and the selected back course will be automatically captured and tracked.
- b) If the D-Bar is less than 2 to 3 dots: the HDG mode will disengage upon selecting **REV** mode; the **REV** annunciator will illuminate and the capture/track sequence will automatically begin.
- b. When equipped with HSI:
 - 1) BARO Setting (if installed) -- CHECK.
 - 2) Course Bearing pointer -- **SET** to the ILS <u>front_course</u> inbound heading.
 - 3) Heading Selector Knob -- **SET BUG** to provide desired intercept angle and engage HDG mode.
 - 4) **REV** Mode Selector Button -- **PRESS**.

- a) If the D-Bar is greater than 2 to 3 dots: the autopilot will annunciate REVARM; when the computed capture point is reached the ARM annunciator will go out and the selected back course will be automatically captured and tracked.
- b) If the D-Bar is less than 2 to 3 dots: the HDG mode will disengage upon selecting **REV** mode; the **REV** annunciator will illuminate and the capture/track sequence will automatically begin.
- 5) Airspeed -- **MAINTAIN** 100 KIAS minimum during autopilot coupled approaches (recommended).

9. GLIDESLOPE COUPLING

a. APR Mode -- ENGAGED, Note GSARM annunciated.

NOTE

Glideslope coupling is inhibited when operating in NAV or REV modes. With NAV 1 selected to a valid ILS, glideslope armed and coupling occurs automatically in the APR mode when tracking a localizer.

b. At Glideslope centering -- note ARM annunciator goes out.

NOTE

Autopilot can capture glideslope from above or below the beam.

c. Airspeed -- MAINTAIN 100 KIAS minimum during autopilot coupled approaches (recommended).

損

10. MISSED APPROACH

- a. A/P DISC/TRIM INTER Switch PRESS to disengage AP.
- b. MISSED APPROACH EXECUTE.
- c. If autopilot is desired:
 - 1) Elevator Trim -- VERIFY or SET.
 - 2) Airspeed and Rate of Climb -- STABILIZED.

NOTE

Avoid autopilot engagement into a climb condition that either cannot be maintained, or is on the performance limits of the airplane for its power and weight configuration.

3) AP Button -- PRESS. Note ROL and VS annunciators on. If no other modes are selected the autopilot will operate in the ROL and VS modes. Verify that the aircraft Vertical Speed Indicator (VSI) and the Autopilot VS agree.

NOTE

If tracking the ILS course outbound as part of the missed approach procedure is desired, use the NAV mode to prevent inadvertent GS coupling.

11. BEFORE LANDING

a. A/P DISC/TRIM INT Switch -- PRESS to disengage AP.

SECTION 5 PERFORMANCE

There is no change to the airplane performance when the KAP 140, 2 Axis Autopilot is installed.



Pilot's Operating Handbook and FAA Approved Airplane Flight Manual

CESSNA MODEL 182S

AIRPLANES 18280687 AND ON

SUPPLEMENT 19

BENDIX/KING KLN 94 GLOBAL POSITIONING SYSTEM (IFR)

> Member of GAMA 6 November 2000

COPYRIGHT © 2000 CESSNA AIRCRAFT COMPANY WICHITA, KANSAS, USA

182SPHUS-S19-02

Revision 2 - 15 January 2001

S19-1

SUPPLEMENT 19

BENDIX/KING KLN 94 GLOBAL POSITIONING SYSTEM (IFR)

The following Log of Effective Pages provides the date of issue for original and revised pages, as well as a listing of all pages in the Supplement. Pages which are affected by the current revision will carry the date of that revision

Revision Level	Date of Issue
0 (Original)	November 6, 2000
1	December 18, 2000
2	January 15, 2001

LOG OF EFFECTIVITY PAGES

PAGE	DATE	PAGE	DATE
Title (S19-1) S19-2 S19-3 S19-4 S19-5 S19-6 S19-7 S19-8 S19-9	Jan 15/01 Jan 15/01 Nov 6/00 Jan 15/01 Jan 15/01 Nov 6/00 Nov 6/00 Nov 6/00	\$19-10 \$19-11 \$19-12 \$19-13 \$19-14 \$19-15 \$19-16 \$19-17 \$19-18	Jan 15/01 Jan 15/01 Jan 15/01 Nov 6/00 Nov 6/00 Nov 6/00 Nov 6/00 Nov 6/00

SUPPLEMENT 19

BENDIX/KING KLN 94 GLOBAL POSITIONING SYSTEM (IFR)

SERVICE BULLETIN CONFIGURATION LIST

The following is a list of Service Bulletins that are applicable to the operation of the airplane, and have been incorporated into this supplement. This list contains only those Service Bulletins that are currently active.

Number Title

Airplane Unit Revision Incorpora

Incorporation In Airplane

Incorporated

S19-3 Nov 6/00

SUPPLEMENT

BENDIX/KING KLN 94 GLOBAL POSITIONING SYSTEM (IFR)

SECTION 1

GENERAL

The KLN 94 GPS (Global Positioning System) is a three-dimensional precision navigation system based on 24 earth orbiting satellites. Receiver Autonomous Integrity Monitoring (RAIM) is a function that every IFR-certified GPS receiver must continuously perform to assure position accuracy. RAIM is available when 5 or more of these satellites are in view, or 4 satellites are in view and a barometrically corrected altitude input from the airplane's altimeter is made. Annunciation is provided if there are not enough satellites in view to assure position integrity.

Operational guidance for the KLN 94 GPS Navigation System is provided with the Bendix/King KLN 94 Pilot's Guide (supplied with the airplane). This Pilot's Guide should be thoroughly studied and VFR operations conducted so that you are totally familiar with GPS navigation before actually using this equipment in IFR conditions.

The database card is an electronic memory containing information on airports, navaids, intersections, DP's, STAR's, instrument approaches, special use airspace, and other items of interest to the pilot.

Every 28 days, Bendix/King receives new aeronautical database information from Jeppesen Sanderson for each database region. This information is processed and downloaded onto the database cards. Bendix/King makes these database card updates available to KLN 94 GPS users.

A CAUTION

THE DATABASE MUST BE UPDATED ONLY WHILE THE AIRCRAFT IS ON THE GROUND. THE KLN 94 DOES NOT PERFORM ANY NAVIGATION FUNCTION WHILE THE DATABASE IS BEING UPDATED.

NOTE

A current database is required by regulation in order to use the KLN 94 GPS system for non-precision approaches.

Provided the KLN 94 navigation system is receiving adequate usable signals, it has been demonstrated capable of and has been shown to meet the accuracy specifications of: VFR/IFR en route oceanic and remote, en route domestic, terminal, and instrument approach (GPS, Loran-C, VOR, VOR-DME, TACAN, NDB, NDB-DME, RNAV) operation within the U.S. National Airspace System, North Atlantic Minimum Navigation Performance Specifications (MNPS) Airspace and latitudes bounded by 74° North and 60° South using the WGS-84 (or NAD 83) coordinate reference datum in accordance with the criteria of AC 20-138, AC 91-49, and AC 120-33. Navigation data is based upon use of only the global positioning system (GPS) operated by the United States.

Jan 15/01 S19-5

13


Aircraft using GPS for oceanic IFR operations may use the KLN 94 to replace one of the other approved means of long range navigation. A single KLN 94 GPS installation may also be used on short oceanic routes which require only one means of long-range navigation.

NOTE

FAA approval of the KLN 94 does not necessarily constitute approval for use in foreign airspace.

NOTE

The KLN 94 is qualified for BRNAV (Basic Area Navigation) operation in the European region in accordance with the criteria of AC 90-96. (Reference ICAO Doc 7030 Regional Supplementary Procedures, JAA Technical Guidance Leaflet AMJ20X2 and Eurocontrol RNAV Standard Doc 003-93 Area Navigation Equipment Operational Requirements and Functional Requirements (RNAV).)



- 1. GPS MESSAGE (MSG) ANNUNCIATOR LIGHT -- MSG will begin flashing whenever the message prompt (a large "M" on the left side of the screen) on the KLN 94 GPS unit begins flashing to alert the pilot that a message is waiting. Press the Message (MSG) key on the GPS to display the message. If a message condition exists which requires a specific action by the pilot, the message annunciator will remain on but will not flash.
- 2. GPS WAYPOINT (WPT) ANNUNCIATOR LIGHT -- GPS WAYPOINT annunciator will begin to flash approximately 36 seconds prior to reaching a Direct-To waypoint. Also, when turn anticipation is enabled in the KLN 94 GPS unit, the annunciator will begin to flash 20 seconds prior to the beginning of turn anticipation, then illuminate steady at the very beginning of turn anticipation.

Figure 1. GPS Annunciator/Switch (Sheet 1 of 3)

Nov 6/00 S19-7

WARNING

TURN ANTICIPATION IS AUTOMATICALLY DISABLED FOR FAF WAYPOINTS AND THOSE USED EXCLUSIVELY IN DP/STARS WHERE OVERFLIGHT IS REQUIRED. FOR WAYPOINTS SHARED BETWEEN DP/STARS AND PUBLISHED EN ROUTE SEGMENTS (REQUIRING OVERFLIGHT IN THE DP/STARS), PROPER SELECTION ON THE PRESENTED WAYPOINT PAGE IS NECESSARY TO PROVIDE ADEQUATE ROUTE PROTECTION ON THE DP/STARS.

- 3. GPS APPROACH (GPS, APR) SWITCH -- Pressing the GPS APPROACH switch manually selects or disarms the approach ARM mode and also cancels the approach ACTV mode after being automatically engaged by the KLN 94 GPS system. The white background color of the GPS APPROACH annunciator makes it visible in daylight.
- 4. ARM ANNUNCIATOR LIGHT -- ARM annunciator will illuminate when the KLN 94 GPS system automatically selects the approach ARM mode or when the approach ARM mode is manually selected. The approach ARM mode will be automatically selected when the airplane is within 30 NM of an airport, and an approach is loaded in the flight plan for that airport. The approach ARM mode can manually be selected at a greater distance than 30 NM from the airport by pressing the GPS APPROACH switch; however, this will not change the CDI scale until the airplane reaches the 30 NM point. The approach ARM mode can also be disarmed by pressing the GPS APPROACH switch.
- 5. ACTIVE (ACTV) ANNUNCIATOR LIGHT -- ACTV annunciator will illuminate when the KLN 94 GPS system automatically engages the approach ACTV mode (the ACTV mode can only be engaged by the KLN 94 GPS system which is automatic.) To cancel the approach ACTV mode, press the GPS APPROACH switch; this will change the mode to the approach ARM mode and illuminate the ARM annunciator.

Figure 1. GPS Annunciator/Switch (Sheet 2 of 3)

6. NAV/GPS SWITCH -- Toggles from Nav 1 to GPS and vice versa to control the type of navigation data to be displayed on the CDI (Course Deviation Indicator). The No. 1 CDI Omni Bearing Selector (OBS) provides analog course input to the KLN 94 in OBS mode when the NAV/GPS switch/annunciator is in GPS. When the NAV/GPS switch annunciation is in NAV, GPS course selection in OBS mode is digital through the use of the controls and display at the KLN 94.

NOTE

Manual CDI course centering in **OBS** mode using the control knob can be difficult, especially at long distances. Centering the Course Deviation Indicator (CDI) needle can best be accomplished by pressing the Direct-To button and then manually setting the No. 1 CDI course to the course value prescribed in the KLN 94 displayed message.

NOTE

The Directional Indicator heading (HDG) bug must also be set to provide proper course datum to the autopilot if coupled to the KLN 94 in **LEG** or **OBS**. (When the optional HSI is installed, the HSI course pointer provides course datum to the autopilot.)

- 7. NAVIGATION SOURCE (NAV) ANNUNCIATOR -- The NAV annunciator will illuminate steady to inform the pilot that NAV 1 information is being displayed on the NAV 1 CDI.
- 8. NAVIGATION SOURCE (**GPS**) ANNUNCIATOR -- The **GPS** annunciator will illuminate steady to inform the pilot that GPS information is being displayed on the NAV 1 CDI.

Figure 1. GPS Annunciator/Switch (Sheet 3 of 3)

Nov 6/00 S19-9

SECTION 2 LIMITATIONS

- 1. The KLN 94 GPS Pilot's Guide, P/N 006-18207-0000, dated September 2000 (or later applicable revision) must be available to the flight crew whenever IFR GPS navigation is used. The Operational Revision Status (ORS) of the Pilot's Guide must match the ORS level annunciated on the Self Test page.
- 2. Navigation is prohibited within 60 nautical miles of the North and South Poles (i.e., at greater than 89° north and south latitude).
- 3. IFR Navigation is restricted as follows:
 - a. The system must utilize ORS level 01 or later FAA approved revision.
- b. The data on the Self-Test page must be verified prior to use.
 - c. IFR en route and terminal navigation is prohibited unless the pilot verifies the currency of the database or verifies each selected waypoint for accuracy by reference to current approved data.
 - d. Instrument approaches must be accomplished in accordance with approved instrument approach procedures that are retrieved from the KLN 94 database. The KLN 94 aeronautical database must incorporate the current update cycle.
- The KLN 94 Quick Reference, P/N 006-18228-0000, Revision 1, dated August 2000 (or later applicable revision) must be available to the flight crew during instrument approach operations.
 - 2) Instrument approaches must be conducted in the approach mode and RAIM must be available at the Final Approach Fix.

- 3) APR ACTV mode must be annunciated at the Final Approach Fix.
- 4) Accomplishment of ILS, LOC, LOC-BC, LDA, SDF, and MLS approaches are not authorized.
- 5) When an alternate airport is required by the applicable operating rules, it must be served by an approach based on other than GPS or Loran-C navigation.
- 6) The KLN 94 can only be used for approach guidance if the reference coordinate datum system for the instrument approach is WGS-84 or NAD-83. (All approaches in the KLN 94 database use the WGS-84 or the NAD-83 geodetic datum).
- e. For BRNAV operations in the European region:
 - 1) With 23 (24 if the altitude input to the KLN 94 is not available) or more satellites projected to be operational for the flight, the aircraft can depart without further action.
 - 2) With 22 (23 if the altitude input to the KLN 94 is not available) or fewer satellites projected to be operational for the flight, the availability of the GPS integrity (RAIM) should be confirmed for the intended flight (route and time). This should be obtained from a prediction program run outside of the aircraft. The prediction program must comply with the criteria of Appendix 1 of AC90-96. In the event of a predicted continuous loss of RAIM of more than 5 minutes for any part of the intended flight, the flight should be delayed, cancelled, or rerouted on a track where RAIM requirements can be met.
- f. If a "RAIM NOT AVAILABLE" message is displayed in the en route or terminal phase of flight, continue to navigate using the KLN 94 or revert to an alternate means of navigation appropriate to the route and phase of flight. When continuing to use the KLN 94 for navigation, position must be verified every 15 minutes (or as required by applicable country's operating rules) using another IFR approved navigation system.

Jan 15/01 S19-11

Honeywell's Preflight, Version 2.0 or later computer based prediction program may be used for the RAIM prediction. Alternate methods should be submitted for approval in accordance with Advisory Circular AC90-96.

g. The aircraft must have other approved navigation equipment appropriate to the route of flight installed and operational.

SECTION 3 EMERGENCY PROCEDURES

There are no changes to the basic airplane emergency procedures when the KLN 94 GPS is installed.

- 1. If the KLN 94 GPS information is not available or invalid, utilize remaining operational navigation equipment as required.
- 2. If a "RAIM NOT AVAILABLE" message is displayed while conducting an instrument approach, terminate the approach. Execute a missed approach if required.
- 3. If a "RAIM NOT AVAILABLE" message is displayed in the en route or terminal phase of flight, continue to navigate using the KLN 94 or revert to an alternate means of navigation appropriate to the route and phase of flight. When continuing to use the KLN 94 for navigation, position must be verified every 15 minutes (or as required by applicable country's operating rules) using another IFR approved navigation system.
- 4. Refer to the KLN 94 Pilot's Guide, Appendices B and C, for appropriate pilot actions to be accomplished in response to annunciated messages.

SECTION 4 NORMAL PROCEDURES

OPERATION

Normal operating procedures are outlined in the KLN 94 GPS Pilot's Guide, P/N 006-18207-0000, dated September 2000 (or later applicable revision). A KLN 94 Quick Reference, P/N 006-18228-0000, dated August 2000 (or later applicable revision) containing an approach sequence, operating tips and approach related messages is intended as well for cockpit use by the pilot familiar with KLN 94 operations when conducting instrument approaches.

AUTOPILOT COUPLED OPERATION

The KLN 94 may be coupled to the KAP 140 autopilot by first selecting **GPS** on the NAV/GPS switch. Manual selection of the desired track on the pilot's DG heading bug is required to provide course datum to the KAP 140 autopilot. (Frequent course datum changes may be necessary, such as in the case of flying a DME arc.) The autopilot approach mode (APR) should be used when conducting a coupled GPS approach.

NOTE

NAV or APR coupled DME arc intercepts can result in excessive overshoots (aggravated by high ground speeds and/or intercepts from inside the arc).

APPROACH MODE SEQUENCING AND RAIM PREDICTION

WARNING

FAMILIARITY WITH THE EN ROUTE OPERATION OF THE KLN 94 DOES NOT CONSTITUTE PROFICIENCY IN APPROACH OPERATIONS. DO NOT ATTEMPT APPROACH OPERATIONS IN IMC (INSTRUMENT METEOROLOGICAL CONDITIONS) PRIOR TO ATTAINING PROFICIENCY IN THE USE OF THE KLN 94.

The special use airspace alert will automatically be disabled prior to flying an instrument approach to reduce the potential for message congestion.

- 1. Prior to arrival, select a STAR if appropriate from the APT 7 page. Select an approach and an initial approach fix (IAF) from the APT 8 page. The most efficient means of getting to these pages is initiated by pressing the PROC (PROCEDURE) button on the KLN 94.
 - a. Press PROC button.
 - b. Select Approach, Arrival or Departure.
 - c. Select the airport from the list or enter the desired airport identifier.
 - d. The APT 7 or APT 8 page will be displayed as appropriate.

NOTE

To delete or replace a DP, STAR or approach, select FPL 0 page. Place the cursor over the name of the procedure, press ENT to change it, or CLR then ENT to delete it.

2. En route, check for RAIM availability at the destination airport ETA on the **OTH 3** page.

NOTE

RAIM must be available at the FAF in order to fly an instrument approach. Be prepared to terminate the approach upon loss of RAIM.

- 3. At or within 30 nm from the airport:
 - a. Verify automatic annunciation of APRARM.
 - b. Note automatic CDI needle scaling change from ±5.0 nm to ±1.0 nm over the next 30 seconds.
 - c. Update the KLN 94 altimeter baro setting as required.
 - d. Internally the KLN 94 will transition from en route to terminal integrity monitoring.
- 4. Select NAV 4 page to fly the approach procedure.
 - a. If receiving radar vectors, or need to fly a procedure turn or holding pattern, fly in OBS until inbound to the FAF.

OBS navigation is TO-FROM (like a VOR) without waypoint sequencing.

- b. If receiving radar vectors, choose VECTORS as the IAF, activate vectors when the first vector for the approach is received and leave the unit in LEG mode.
- c. **NoPT** routes including DME arc's are flown in **LEG**. <u>LEG</u> is mandatory from the FAF to the MAP.

NOTE

NAV or APR coupled DME arc intercepts can result in excessive overshoots (aggravated by high ground speeds and/or intercepts from <u>inside</u> the arc).

A WARNING

FLYING FINAL OUTBOUND FROM AN OFF-AIRPORT VORTAC ON AN OVERLAY APPROACH; BEWARE OF THE DME DISTANCE INCREASING ON FINAL APPROACH, AND THE GPS DISTANCE-TO-WAYPOINT DECREASING, AND NOT MATCHING THE NUMBERS ON THE APPROACH PLATE.

- 5. At or before 2 nm from the FAF inbound:
 - a. Select the FAF as the active waypoint, if not accomplished already.
 - b. Select LEG operation.
- 6. Approaching the FAF inbound (within 2 nm):
 - a. Verify APR ACTV.
 - b. Note automatic CDI needle scaling change from ±1.0 nm to ±0.3 nm over the 2 nm inbound to the FAF.
 - c. Internally the KLN 94 will transition from terminal to approach integrity monitoring.
- 7. Crossing the FAF and APR ACTV is not annunciated:
 - a. Do not descend.
 - b. Execute the missed approach.
- 8. Missed Approach:
 - a. Climb.
 - b. Navigate to the MAP (in APR ARM if APR ACTV is not available).

There is no automatic LEG sequencing at the MAP.

c. After climbing in accordance with the published missed approach procedure, press the Direct To button, verify or change the desired holding fix and press **ENT**.

GENERAL NOTES

- The aeronautical database must be up to date for instrument approach operation.
- Only <u>one</u> approach can be in the flight plan at a time.
- Checking RAIM prediction for your approach while en route using the AUX 3 page is recommended. A self check occurs automatically within 2 nm of the FAF. APR ACTV is inhibited without RAIM.
- Data cannot be altered, added to or deleted from the approach procedures contained in the database. (DME arc intercepts may be relocated along the arc through the NAV 4 or the FPL 0 pages).
- Some approach waypoints do not appear on the approach plates (including in some instances the FAF).
- · Waypoint suffixes in the flight plan:

i -- IAF

f -- FAF

m -- MAP

h -- missed approach holding fix.

•The DME arc IAF (arc intercept waypoint) will be on your present position radial off the arc VOR when you load the IAF into the flight plan, or the beginning of the arc if currently on a radial beyond the arc limit. To adjust the arc intercept to be compatible with a current radar vector, bring up the arc IAF waypoint in the NAV 4 page scanning field or under the cursor on the FPL 0 page, press CLR, then ENT. Fly the arc in LEG. Adjust the heading bug (if autopilot coupled) and CDI course with reference to the desired track value on the NAV 4 page (it will flash to remind you). Left/right CDI needle information is relative to the arc. Displayed distance is not along the arc but direct to the active waypoint. (The DME arc radial is also displayed in the lower right corner of the NAV 4 page.)

Nov 6/00 S19-17

SECTION 9 - SUPPLEMENTS SUPPLEMENT 19 - FAA APPROVED

- The DME arc IAF identifier may be unfamiliar. Example: D098G where 098 stands for the 098° radial off the referenced VOR, and G is the seventh letter in the alphabet indicating a 7 DME arc.
- APRARM to APR ACTV is automatic provided that:
 - a. You are in APRARM (normally automatic).
 - b. You are in LEG mode.
 - c. The **FAF** is the active waypoint.
 - d. Within 2 nm of the FAF.
 - e. Outside of the FAF.
 - f. Inbound to the FAF.
 - g. RAIM is available.
- Direct-To operation between the FAF and MAP cancels APR ACTV. Fly the missed approach in APRARM.
- Flagged navigation inside the FAF may automatically bring up the message page stating:

PRESS PROC BUTTON NOW FOR NAVIGATION

Pressing the **PROC** button will usually restore navigation (not guaranteed) by changing from APR **ACTV** to APR **ARM**. Fly the missed approach.

• The instrument approach using the KLN 94 may be essentially automatic starting 30 nm out (with a manual baro setting update) or it may require judicious selection of the OBS and LEG modes.

SECTION 5 PERFORMANCE

There is no change to the airplane performance when this avionics equipment is installed. However, installation of an externally-mounted antenna or related external antennas, will result in a minor reduction in cruise performance.